

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [AIRHEAD](#) /

› AIRHEAD SUP Anchor Kit User Manual

AIRHEAD SUP Anchor Kit

AIRHEAD SUP Anchor Kit User Manual

Model: SUP Anchor Kit

INTRODUCTION

The AIRHEAD SUP Anchor Kit is designed to provide a reliable anchoring solution for stand-up paddleboards (SUPs) and kayaks. This kit includes a 1.5-pound grapnel anchor, a 15-foot anchor line with a stainless spring hook, and a padded nylon storage bag. It is ideal for temporary anchoring in calm waters, allowing users to pause for activities such as fishing, yoga, or simply relaxing without drifting.

This manual provides essential information for the safe and effective use, setup, operation, and maintenance of your AIRHEAD SUP Anchor Kit.

SAFETY INFORMATION

- Always check local regulations regarding anchoring in specific areas.
- This anchor is intended for temporary use in calm, shallow waters. It is not designed for strong currents, heavy winds, or deep water conditions.
- Ensure the anchor line is free of tangles and obstructions before deployment.
- Never anchor in or near navigation channels or areas with heavy boat traffic.
- Be aware of underwater hazards such as rocks, debris, or marine life that could snag the anchor or line.
- Always maintain a safe distance from other watercraft and shorelines when anchoring.
- Do not use this anchor as a primary safety device in emergency situations.
- Regularly inspect the anchor, line, and hardware for wear or damage. Replace components as needed.

SETUP INSTRUCTIONS

The AIRHEAD SUP Anchor Kit comes pre-assembled for immediate use. Follow these steps to prepare your anchor for deployment:

1. **Unpack the Kit:** Remove the grapnel anchor, anchor line, and stainless spring hook from the padded nylon storage bag.
2. **Inspect Components:** Visually inspect the anchor for any damage or deformities. Ensure the anchor line is securely attached to the anchor and the spring hook. Check the line for fraying or weak spots.

3. **Unfold the Anchor:** The grapnel anchor features four flukes that fold for compact storage. Gently pull the anchor shaft upwards to extend the flukes into their open, locked position. Ensure all four flukes are fully extended and locked before use.
4. **Attach to Watercraft:** Use the stainless spring hook to attach the free end of the anchor line to a secure point on your SUP or kayak. This could be a D-ring, handle, or other designated attachment point. Ensure the connection is firm and will not accidentally detach.





Image: The AIRHEAD SUP Anchor Kit components, including the red grapnel anchor, coiled yellow anchor line with a stainless spring hook, and the black padded nylon storage bag.

OPERATING INSTRUCTIONS

Deploying the Anchor

1. **Choose Your Spot:** Select a calm area with a suitable bottom (sand, mud, or light gravel) and away from hazards. Ensure the water depth is appropriate for the 15-foot anchor line.
2. **Prepare the Line:** Uncoil the anchor line completely, ensuring there are no knots or tangles that could impede deployment or retrieval.
3. **Lower the Anchor:** Gently lower the anchor into the water. Do not throw the anchor, as this can cause the line to tangle or damage the anchor. Allow the anchor to sink to the bottom.
4. **Set the Anchor:** Once the anchor reaches the bottom, slowly move your SUP or kayak away from the anchor's position until the line becomes taut. This action helps the anchor flukes dig into the bottom, securing your position.
5. **Verify Hold:** Lightly test the anchor's hold by attempting to paddle away. If the anchor drags, retrieve it and re-deploy in a slightly different spot or adjust the scope (length of line deployed relative to depth).

Retrieving the Anchor

1. **Approach the Anchor:** Paddle or pull your watercraft directly over the anchor's position. This reduces the angle of the line, making retrieval easier.
2. **Pull the Line:** Steadily pull the anchor line upwards. The grapnel anchor's flukes are designed to release easily when pulled vertically.
3. **Clean and Stow:** Once retrieved, shake off any debris or mud from the anchor. Coil the anchor line neatly and fold the anchor flukes for compact storage. Place all components back into the padded nylon storage bag.



Image: The black padded nylon storage bag, designed for convenient storage and transport of the anchor kit.

MAINTENANCE

- **Rinse After Use:** After each use, especially in saltwater, rinse the anchor, line, and spring hook with fresh water to remove salt, sand, and debris. This prevents corrosion and extends product life.
- **Dry Thoroughly:** Ensure all components are completely dry before storing them in the bag to prevent mildew and odors.
- **Inspect Regularly:** Periodically check the anchor for rust or damage, the anchor line for fraying, cuts, or weak spots, and the spring hook for proper function and corrosion.
- **Proper Storage:** Store the anchor kit in its padded nylon bag in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Anchor is not holding:

- **Insufficient Scope:** Ensure enough anchor line is deployed. A general rule is 5-7 times the water depth. With a 15-foot line, this anchor is best suited for shallow waters (e.g., 2-3 feet deep).
- **Bottom Type:** The anchor may not be suitable for very soft mud, thick vegetation, or hard rock bottoms. Try moving to an area with sand or gravel.
- **Anchor Not Set:** Ensure the anchor flukes have properly dug into the bottom. Try slowly pulling on the line to help it set.
- **Current/Wind:** This lightweight anchor is designed for calm conditions. In strong currents or winds, it may not hold effectively. Consider a heavier anchor or a different anchoring method for such conditions.

Anchor line is tangled:

- **Improper Coiling:** Always coil the line neatly after each use before storing.
- **Deployment Method:** Avoid throwing the anchor. Gently lower it to prevent tangles.

Anchor is stuck:

- **Pull Vertically:** Paddle directly over the anchor and pull the line straight up. Grapnel anchors are designed to release when pulled from directly above.
- **Change Angle:** If pulling vertically doesn't work, try moving your watercraft in a circle around the anchor while maintaining tension on the line. This can sometimes dislodge it.
- **Snagged:** If the anchor is severely snagged on an underwater obstruction, it may be necessary to cut the line as a last resort. Always prioritize your safety.

SPECIFICATIONS

Product Type	Paddleboard Anchor Kit
Brand	AIRHEAD
Anchor Weight	1.5 Pounds (0.68 kg)
Anchor Type	Grapnel (folding flukes)
Anchor Line Length	15 feet (4.57 meters)
Anchor Line Material	Nylon
Included Components	Grapnel anchor, 15 ft anchor line, stainless spring hook, padded nylon storage bag
Recommended Use	Stand-up paddleboards, kayaks, calm and shallow waters
Color	Multicolor (Red anchor, Yellow line, Black bag)

WARRANTY INFORMATION

This AIRHEAD SUP Anchor Kit comes with a **1-year LIMITED WARRANTY**. For specific details regarding warranty coverage, terms, and conditions, please refer to the official AIRHEAD website or contact customer support.

CUSTOMER SUPPORT

For further assistance, product inquiries, or to report any issues with your AIRHEAD SUP Anchor Kit, please visit the official AIRHEAD website or contact their customer service department. Contact information can typically be found on the manufacturer's website or product packaging.

AIRHEAD Official Website: www.airhead.com