

[Manuals.plus](#) /

› [Yale](#) /

› Yale YP2/23/128/1G Standard Security Luggage Combination Padlock User Manual

Yale YP2/23/128/1G

Yale YP2/23/128/1G Standard Security Luggage Combination Padlock

User Instruction Manual

INTRODUCTION

This manual provides essential instructions for the setup, operation, and maintenance of your Yale YP2/23/128/1G Standard Security Luggage Combination Padlock. Please read these instructions carefully before using the product to ensure proper function and security.



Image 1: The Yale YP2/23/128/1G Standard Security Luggage Combination Padlock, shown in its grey finish with the default combination of 0-0-0 visible on the dials.

SETUP: SETTING YOUR COMBINATION

Your Yale combination padlock is factory preset to **0-0-0**. Follow these steps to set your personal combination:

1. Ensure the padlock is open. If it is closed, dial **0-0-0** and pull up the shackle.
2. Rotate the shackle 90 degrees (a quarter turn) counter-clockwise from its open position.
3. Press the shackle down firmly into the padlock body, ensuring it is fully depressed.
4. While holding the shackle down, set your desired 3-digit combination by rotating the dials. Choose a memorable combination.
5. Once your new combination is set, release the shackle.
6. Rotate the shackle back to its original open position (another 90 degrees clockwise).
7. Close the shackle and scramble the dials to lock the padlock. Test your new combination to ensure it opens correctly.

Important: Do not release the shackle while setting the combination, as this may cause the combination to be set incorrectly. Remember your combination, as there is no master key or override function.

OPERATING THE PADLOCK

Opening the Padlock

1. Align the three numerical dials to your personal 3-digit combination.
2. Pull the shackle upwards to release it from the padlock body. The padlock is now open.

Closing and Securing the Padlock

1. With the shackle in the open position, insert it back into the padlock body.
2. Press the shackle down until it clicks into place.
3. Scramble the numerical dials to a random sequence. The padlock is now securely locked.

MAINTENANCE

The Yale YP2/23/128/1G padlock requires minimal maintenance to ensure long-lasting performance.

- **Cleaning:** Wipe the padlock body and shackle with a soft, dry cloth to remove dust and dirt. Avoid using abrasive cleaners or solvents, as these can damage the finish or internal mechanisms.
- **Lubrication:** If the shackle movement becomes stiff over time, a small amount of graphite powder or a silicone-based lubricant can be applied to the shackle entry points. Do not use oil-based lubricants, as they can attract dirt.
- **Storage:** Store the padlock in a dry environment when not in use to prevent corrosion.

TROUBLESHOOTING

- **Padlock will not open:**
 - Ensure the correct 3-digit combination is precisely aligned on the dials.
 - Verify that the shackle was fully depressed when the combination was initially set. If not, the combination may be different than intended.
 - If you have forgotten your combination, there is no factory reset or master key for this type of padlock. You may need to try common combinations or consider replacing the padlock.
- **Shackle is stiff or difficult to operate:**
 - Apply a small amount of graphite powder or silicone lubricant to the shackle entry points and work the shackle several times to distribute the lubricant.
 - Check for any visible debris obstructing the shackle mechanism.

SPECIFICATIONS

Model	YP2/23/128/1G
Type	Standard Security Luggage Combination Padlock
Combination	3-digit resettable

Shackle Diameter	4mm
Body Width	23mm
Body Height	34mm (approximate, excluding shackle)
Body Depth	12mm
Color	Grey

STANDARD PROTECTION



Image 2: Detailed dimensions of the Yale YP2/23/128/1G padlock, showing a shackle diameter of 4mm, body width of 23mm, body height of 34mm, and body depth of 12mm.

WARRANTY INFORMATION

Specific warranty details for the Yale YP2/23/128/1G Standard Security Luggage Combination Padlock are not included in this manual. For comprehensive warranty terms and conditions, please refer to the official Yale website or contact your point of purchase.

CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your Yale YP2/23/128/1G padlock, please visit the official Yale website for contact information or consult the retailer from whom the product was purchased.

© 2023 Yale. All rights reserved. Information in this manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question