Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Tweezerman 1404-LLT

Tweezerman Precision Folding Razor User Manual

Model: 1404-LLT

1. Product Overview

The Tweezerman Precision Folding Razor is designed for precise removal of fine hairs on areas such as the brow, face, or bikini line. Its finely crafted blade and soft, ergonomic handle provide comfortable and controlled use. The folding design allows for compact storage and travel.

Key Features:

- Foldable soft grip handle for secure handling and compact storage.
- Integrated brush on the handle for cleaning the razor blade.
- Precision-crafted cutting edge for effective fine hair removal.
- Travel-ready design.



Image 1.1: The Tweezerman Precision Folding Razor in its compact, folded state, ready for storage or travel.

2. Setup

Before first use, ensure the razor is clean and dry. To prepare the razor for use:

1. Gently unfold the razor handle until it locks into the open position.
2. Inspect the blade for any damage or debris.



Image 2.1: The Tweezerman Precision Folding Razor fully unfolded, showing the blade and the cleaning brush at the opposite end of the handle.

3. Operating Instructions

Follow these steps for effective and safe hair removal:

1. **Prepare the Skin:** Ensure the skin area to be treated is clean and dry. For best results, some users prefer to apply a light layer of facial oil or shaving cream, though it can also be used on dry skin.
2. **Position the Razor:** Hold the razor at a slight angle (approximately 45 degrees) against the skin.
3. **Gentle Strokes:** Using light, short, downward strokes, gently glide the razor over the skin in the direction of hair growth. Avoid applying excessive pressure.
4. **Targeted Areas:** For eyebrows, use small, precise strokes to shape and remove stray hairs. For facial hair, use gentle, even strokes across the desired area.
5. **Clean as You Go:** Periodically use the built-in brush on the handle to clear any accumulated hair from the blade.
6. **Post-Use Care:** After hair removal, rinse the treated area with water and apply a soothing moisturizer if

desired.



Image 3.1: A woman demonstrating the use of the Tweezerman Precision Folding Razor for eyebrow shaping.



Image 3.2: A close-up view illustrating the precise application of the razor for fine hair removal around the eyebrow area.



Image 3.3: A visual comparison showing the appearance of eyebrows before and after using the Tweezerman Precision Folding Razor for grooming.

4. Maintenance

Proper care ensures the longevity and hygiene of your razor:

- **Cleaning:** After each use, gently brush any hair from the blade using the integrated brush. Rinse the blade under warm running water.

- **Drying:** Ensure the blade is completely dry before folding and storing to prevent rust. Pat dry with a soft cloth.
- **Storage:** Fold the razor into its compact position and store it in a dry, safe place away from moisture and out of reach of children.
- **Blade Replacement:** The blade is not designed for replacement. Replace the entire razor when the blade becomes dull to maintain optimal performance and prevent skin irritation.

5. Troubleshooting

If you encounter issues with your Tweezerman Precision Folding Razor, consider the following:

- **Ineffective Hair Removal:** If the razor is not removing hair efficiently, the blade may be dull. It is recommended to replace the razor.
- **Skin Irritation/Nicks:** Ensure you are using light, gentle strokes and holding the razor at the correct angle (approximately 45 degrees). Avoid pressing too hard. If irritation persists, discontinue use.
- **Razor Not Folding/Unfolding Smoothly:** Check for any debris or obstruction in the hinge mechanism. Clean gently if necessary. Do not force the mechanism.

6. Specifications

Attribute	Detail
Product Dimensions	4 x 2 x 4.5 inches (folded)
Item Weight	1.41 ounces
Model Number	1404-LLT
UPC	038097009491, 038097123012
Manufacturer	Fab Products

7. Warranty and Support

For information regarding warranty coverage or product support, please refer to the official Tweezerman website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

Tweezerman Official Website: www.tweezerman.com

© 2023 Tweezerman. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00JVPO2Q8

More documents and user manuals: **https://manuals.plus/**