

Sunbeam HD3005-005

Sunbeam HD3005-005 1875 Watt Folding Hand-Held Hair Dryer Instruction Manual

1. INTRODUCTION

Thank you for choosing the Sunbeam HD3005-005 1875 Watt Folding Hand-Held Hair Dryer. This compact and powerful hair dryer is designed for efficient hair drying and styling, featuring a convenient folding handle for easy storage and portability. Please read this manual thoroughly before use to ensure safe and optimal performance.



Figure 1: Sunbeam HD3005-005 Hair Dryer (Unfolded)

2. IMPORTANT SAFETY INFORMATION

WARNING: To reduce the risk of electric shock, fire, or injury, always follow these basic safety precautions.

- Always unplug the hair dryer from the power outlet when not in use.
- Keep the power plug and cord away from heated surfaces to prevent fire hazards.
- Never use the hair dryer while bathing or near water sources to avoid electric shock.
- Do not operate any appliance with a damaged cord or plug, or if the appliance malfunctions or has been dropped or damaged in any manner.
- Do not block the air openings or place the hair dryer on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.

3. PRODUCT FEATURES

- **Folding Handle:** Designed for fast and easy storage, making it ideal for travel and small spaces.

- **Powerful Motor:** Delivers 1875 Watts of drying power with a smooth, quiet operation.
- **Multiple Settings:** Features two heat and air speed settings (High, Low) for versatile styling.
- **Cool Shot Button:** A dedicated button to set hairstyles with a smooth finish.
- **Long Power Cord:** Equipped with a 6 ft. power cord for extended reach.
- **Convenient Hook:** Includes a built-in hook for easy hanging and storage.
- **Protection Pads:** Rubber protection pads minimize scratching and help prevent the dryer from sliding off surfaces.



Figure 2: Sunbeam HD3005-005 Hair Dryer (Folded)

4. SETUP

1. **Unpack:** Carefully remove the hair dryer from its packaging. Retain packaging for future storage or transport.
2. **Inspect:** Check the hair dryer for any visible damage. Ensure the power cord and plug are intact.
3. **Unfold Handle:** If the handle is folded, gently pull it until it locks into the upright position.
4. **Plug In:** Insert the power plug into a standard electrical outlet. Ensure the outlet is compatible with the dryer's voltage (120V AC).

5. OPERATING INSTRUCTIONS

The Sunbeam HD3005-005 features intuitive controls for ease of use.



Figure 3: Control Panel (High, Low, Off, Cool Shot)

1. **Power On:** After plugging in, slide the switch to your desired setting: **LOW** for gentle drying or **HIGH** for fast drying.
2. **Cool Shot:** To set your hairstyle with a smooth finish, press and hold the blue **Cool Shot** button. This will temporarily provide a burst of cool air. Release the button to return to the selected heat setting.
3. **Drying Technique:** For best results, towel-dry hair to remove excess moisture. Section hair and direct airflow from roots to ends.
4. **Power Off:** When finished, slide the switch to the **OFF** position.
5. **Unplug:** Always unplug the hair dryer from the power outlet after each use.

6. MAINTENANCE

- **Cleaning:** Ensure the hair dryer is unplugged and completely cool before cleaning. Wipe the exterior with a damp cloth. Do not use abrasive cleaners or solvents.
- **Air Intake Filter:** Regularly check the rear air intake filter for lint and dust buildup. Gently clean with a soft brush or vacuum cleaner attachment to maintain optimal airflow and prevent overheating.
- **Storage:** For compact storage, fold the handle. Utilize the convenient hanging hook if available. Store the appliance in a dry, safe location away from children.
- **Cord Care:** Do not wrap the cord around the appliance. This can cause premature wear and breakage of the cord. Always store the cord loosely coiled.

7. TROUBLESHOOTING

If your Sunbeam HD3005-005 hair dryer is not functioning as expected, please review the following common issues:

- **No Power:** Ensure the hair dryer is securely plugged into a working electrical outlet. Check if the

outlet is active by testing it with another appliance. If the plug has a reset button, press it.

- **Reduced Airflow or Overheating:** The air intake filter at the back of the dryer may be blocked by lint or hair. Unplug the dryer and clean the filter as described in the Maintenance section. Allow the dryer to cool down before resuming use.
- **Unusual Noise:** Unplug the dryer and check for any foreign objects in the air intake or exhaust grilles. Remove any obstructions carefully. If the noise persists, discontinue use and contact customer support.

If these steps do not resolve the issue, please refer to the Warranty and Support section.

8. SPECIFICATIONS







Specification	Detail
Model Number	HD3005-005
Brand	Sunbeam
Wattage	1875 watts
Power Source	Corded Electric
Color	Black
Material	Rubber (protection pads)
Product Dimensions	9.9 x 6.2 x 3.3 inches
Weight	1 Pound
UPC	027045773812

9. WARRANTY AND SUPPORT

The Sunbeam HD3005-005 1875 Watt Folding Hand-Held Hair Dryer comes with a **Three Year Limited Warranty** from the date of purchase. This warranty covers defects in material or workmanship under normal household use.

For warranty claims, technical support, or any questions regarding your product, please contact Sunbeam Customer Service. Keep your proof of purchase for warranty validation.

For more information, please visit the official Sunbeam website or refer to the contact details provided with your product packaging.

	<p>Sunbeam 1632 Series Wall Mount Hair Dryer - Instruction Manual</p> <p>Official instruction manual for the Sunbeam 1632 Series Wall Mount Hair Dryer (1200-1500 Watts). Includes safety instructions, mounting guide, operating procedures, care and maintenance tips, and warranty information.</p>
	<p>Sunbeam Hospitality Wall Mount 1500-Watt Hair Dryer (HD3002, HD3003) - User Manual</p> <p>Comprehensive instruction manual for the Sunbeam Hospitality Wall Mount 1500-Watt Hair Dryer (Models HD3002, HD3003). Includes safety instructions, mounting, operation, maintenance, and warranty information.</p>
	<p>Sunbeam Mixmaster Hand Mixer JMP2000BK User Guide</p> <p>Comprehensive user guide for the Sunbeam Mixmaster Hand Mixer model JMP2000BK, covering safety precautions, features, usage instructions, mixing tips, speed guide, care, cleaning, and recipes.</p>
	<p>Sunbeam Mixmaster Hand Mixer User Manual and Safety Guide</p> <p>User manual and safety guide for the Sunbeam Mixmaster Hand Mixer (Models 2524, 2526, 2545). Learn about features, operating instructions, and care for your kitchen appliance.</p>
	<p>Sunbeam Fresh Start™ Juice Extractor JE6400: User Manual, Features, and Recipes</p> <p>Get the most out of your Sunbeam Fresh Start™ Juice Extractor (JE6400 series) with this comprehensive instruction manual. Learn about safety, features, operating tips, juicing benefits, and discover a variety of healthy juice recipes.</p>
	<p>Sunbeam Mixmaster Combo Pro Hand & Stand Mixer User Guide MXP1000WH</p> <p>Comprehensive user guide for the Sunbeam Mixmaster Combo Pro Hand & Stand Mixer (Model MXP1000WH). Includes safety precautions, detailed features, operating instructions, mixing guide, care and cleaning tips, and a variety of recipes.</p>