

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [HARBOR BREEZE](#) /

› [Harbor Breeze Classic Style 52 inch Black Finish Energy Star Ceiling Fan User Manual](#)

HARBOR BREEZE 080629179936

Harbor Breeze Classic Style 52 inch Black Finish Energy Star Ceiling Fan User Manual

Model: 080629179936

INTRODUCTION

Thank you for choosing the Harbor Breeze Classic Style 52 inch Black Finish Energy Star Ceiling Fan. This manual provides detailed instructions for the safe installation, operation, and maintenance of your new ceiling fan. Please read this manual thoroughly before beginning installation and keep it for future reference.



An image showing the complete Harbor Breeze Classic Style 52 inch Black Finish Energy Star Ceiling Fan, featuring five black blades and a central motor housing with a pull chain.

This 52-inch ceiling fan is designed for indoor use, providing up to 5,187-CFM airflow, making it ideal for large rooms up to 400 square feet. It features a matte black finish with reversible blades and is Energy Star certified for efficiency. The fan is adaptable with any universal light kit (sold separately) and can be controlled via a pull chain or remote control.

IMPORTANT SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or personal injury, always follow these instructions.

- Read all instructions and safety information before installing your new fan.
- All wiring must be in accordance with national and local electrical codes. If you are unfamiliar with wiring, consult a qualified electrician.
- Ensure the installation site allows the fan blades to rotate without obstruction. Maintain a minimum clearance of 7 feet from the floor to the bottom of the blades.
- The outlet box and support structure must be securely mounted and capable of reliably supporting a minimum of 35 lbs (15.9 kg). Use only UL Listed outlet boxes marked "FOR FAN SUPPORT."
- Do not operate the fan with damaged power cords or plugs.
- Do not insert objects into the path of the fan blades while the fan is operating.
- Always turn off the power at the main circuit breaker before working on the fan.

PACKAGE CONTENTS

Carefully unpack your fan and check the contents. You should have the following items:

- Fan Motor Housing Assembly
- Fan Blades (5)
- Blade Brackets (5)
- Downrod and Hanger Ball Assembly
- Mounting Bracket
- Canopy and Canopy Cover
- Hardware Pack (screws, washers, wire nuts)
- Pull Chain and Fob
- Remote Control and Receiver (if included with specific model variant)
- Instruction Manual

Note: A universal light kit is sold separately and is not included in this package.

SETUP AND INSTALLATION

Before you begin, ensure the power is turned off at the circuit breaker. It is recommended that two people install this fan.

1. **Mounting the Bracket:** Secure the mounting bracket to the outlet box (not included) using the screws provided with the outlet box. Ensure the outlet box is securely fastened to the building structure and can support the fan's weight.
2. **Assembling the Downrod:** Insert the downrod through the canopy and canopy cover. Feed the motor wires through the downrod. Secure the downrod to the fan motor housing with the provided pin and screw.
3. **Hanging the Fan:** Carefully lift the fan assembly and place the hanger ball into the mounting bracket opening. Rotate the fan until the groove in the hanger ball engages the tab on the mounting bracket.
4. **Wiring Connections:** Connect the electrical wires according to the wiring diagram provided in the full installation guide (refer to local electrical codes). Typically, this involves connecting the fan's live wire to the house live wire, the fan's neutral wire to the house neutral wire, and the ground wire to the house ground wire. Use the provided wire nuts.
5. **Attaching Blades:** Attach each fan blade to a blade bracket using the blade screws. Then, attach the assembled blade and bracket to the fan motor housing. Ensure all screws are tightened securely.
6. **Securing the Canopy:** Slide the canopy up against the ceiling and secure it to the mounting bracket with the provided screws.
7. **Light Kit Installation (Optional):** If installing a universal light kit (sold separately), follow the instructions provided with the light kit.

For detailed wiring diagrams and specific installation steps, please refer to the comprehensive installation guide included in your product packaging or available on the manufacturer's website.

OPERATING INSTRUCTIONS

Your Harbor Breeze ceiling fan can be operated using the integrated pull chain or an optional remote control (if installed).

Using the Pull Chain:

- **Fan Speed Control:** Pull the chain once for HIGH speed, twice for MEDIUM speed, three times for LOW speed, and four times to turn the fan OFF.
- **Light Control (if applicable):** If a light kit is installed, a separate pull chain (or the same chain with different pulls) will control the light. Refer to your light kit's instructions.

Using the Remote Control (Optional):

If you have installed a remote control receiver, refer to the remote control's specific instructions for pairing and operation. Typical functions include:

- Power ON/OFF button.
- Fan Speed buttons (High, Medium, Low).
- Light ON/OFF/Dimming buttons.
- Reverse Function button (changes blade direction for summer/winter use).

Reverse Function:

Most ceiling fans have a reverse switch on the motor housing (or a button on the remote). This allows you to change the direction of the fan blades:

- **Summer Operation (Counter-clockwise):** Airflow creates a wind-chill effect, making the room feel cooler.
- **Winter Operation (Clockwise):** Airflow pushes warm air down from the ceiling, helping to distribute heat more evenly.

Always turn off the fan and wait for the blades to stop completely before changing the direction of rotation.

CARE AND MAINTENANCE

Regular maintenance will ensure the longevity and optimal performance of your ceiling fan.

- **Cleaning:** Periodically clean the fan with a soft, damp cloth. Do not use abrasive cleaners or solvents, as they may damage the finish.
- **Blade Cleaning:** Dust the blades regularly to prevent dust buildup, which can cause wobbling.
- **Tightening Screws:** Check all screws, especially those on the blade attachments and mounting bracket, at least twice a year. Tighten any loose screws to prevent wobbling and noise.
- **Lubrication:** This fan features permanently lubricated bearings and does not require additional oiling.
- **Electrical Connections:** Ensure all electrical connections remain secure. If you notice any loose wires, turn off power at the circuit breaker and re-secure them.

Always turn off the power at the main circuit breaker before performing any cleaning or maintenance.

TROUBLESHOOTING

Before attempting any repairs, ensure the power is turned off at the circuit breaker.

| Problem | Possible Cause | Solution |
|---------------------|---|---|
| Fan will not start. | No power to the fan. Loose wire connections. Remote control battery dead. | Check circuit breaker/fuse. Verify all wire connections are secure. Replace remote control battery. |
| Fan wobbles. | Loose blade screws. Unbalanced blades. Loose mounting bracket. | Tighten all blade screws. Check blade balance (use a balancing kit if necessary). Ensure mounting bracket is securely fastened. |

| Problem | Possible Cause | Solution |
|------------------------|---|--|
| Fan is noisy. | Loose screws. Motor hum. Blades hitting an obstruction. | Tighten all screws. Some motor hum is normal; ensure fan is properly grounded. Check for obstructions in the blade path. |
| Light kit not working. | Bulb burned out. Loose wire connection. Incorrect light kit installation. | Replace bulb. Check light kit wiring. Refer to light kit instructions for proper installation. |

SPECIFICATIONS

| Feature | Detail |
|----------------------|--|
| Brand | HARBOR BREEZE |
| Model Name | Classic Style |
| Model Number | 080629179936 |
| Fan Size | 52 inches |
| Finish Type | Matte Black |
| Air Flow Capacity | 5187 Cubic Feet Per Minute (CFM) |
| Room Type | Living Room, Bedroom (up to 400 sq ft) |
| Power Source | Corded Electric |
| Voltage | 120 Volts (AC) |
| Control Method | Pull Chain, Remote (optional) |
| Efficiency | Energy Star Certified |
| Included Components | Light Kit (adaptable, sold separately) |
| Item Weight | 16.78 pounds |
| Indoor/Outdoor Usage | Indoor |

WARRANTY INFORMATION

Harbor Breeze products are manufactured to high-quality standards. For specific warranty details regarding your Classic Style 52 inch Ceiling Fan, please refer to the warranty card included in your product packaging or visit the official Harbor Breeze website. Keep your proof of purchase for warranty claims.

CUSTOMER SUPPORT

If you have any questions or require assistance with your Harbor Breeze ceiling fan, please contact customer support:

- **Website:** Visit the official Harbor Breeze website for FAQs, troubleshooting guides, and contact information.
- **Phone:** Refer to your product packaging or the manufacturer's website for customer service phone numbers.

Please have your model number (080629179936) and date of purchase ready when contacting support.