Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Catnapper 64549712159

Catnapper Griffey Power Recliner User Manual

Model: 64549712159

Introduction

Thank you for choosing the Catnapper Griffey Power Recliner. This manual provides essential information for the safe assembly, operation, and maintenance of your new recliner. Please read all instructions carefully before use and retain this manual for future reference.

Safety Information

- **Read all instructions:** Ensure you understand all assembly and operating instructions before using the recliner.
- **Keep children and pets away:** Do not allow children or pets to play on or around the recliner, especially during operation. Moving parts can cause injury.
- **Avoid obstructions:** Ensure there are no obstructions around the recliner when operating the reclining mechanism.
- **Proper use:** This recliner is designed for adult use for relaxing. Do not stand on the recliner or use it as a step stool.
- **Power cord safety:** Do not place the power cord under the recliner or in a position where it could be pinched or damaged. Keep the cord away from heat sources and sharp edges.
- **Unplug when not in use:** Always unplug the recliner from the power outlet before cleaning or if it will be left unattended for an extended period.
- **Weight limit:** Do not exceed the recommended weight limit for the recliner.

Package Contents

Before beginning assembly, ensure all parts are present. If any parts are missing or damaged, do not attempt to assemble or use the recliner. Contact customer support immediately.

- Catnapper Griffey Power Recliner (Main Body)
- Backrest (if separate)
- Power Cord
- Remote Control (if applicable)



Image: The Catnapper Griffey Power Recliner, showcasing its brown microfiber upholstery and robust design.

Setup Instructions

Follow these steps to set up your Catnapper Griffey Power Recliner:

1. **Unpack Components:** Carefully remove all components from the packaging. Place them on a soft, clean surface to prevent damage.
2. **Attach Backrest (if separate):** If the backrest is separate, align the metal brackets on the backrest with the receivers on the main seat frame. Slide the backrest down firmly until it locks into place. You should hear a click.
3. **Connect Power:** Locate the power cord. Plug one end into the power port on the recliner (usually at the back or underneath) and the other end into a standard wall outlet. Ensure the outlet is easily accessible.
4. **Position Recliner:** Place the recliner in your desired location, ensuring there is sufficient space behind and in front of it for full reclining operation.
5. **Test Functionality:** Once plugged in, test the reclining mechanism using the control buttons.

Operating Instructions

Your Catnapper Griffey Power Recliner features an easy-to-use power reclining mechanism for optimal comfort.

Using the Power Recline Function

- **Locate Controls:** The power recline controls are typically located on the side of the recliner, often as a set of buttons or a toggle switch.
- **Recline Back:** To recline, press and hold the button or toggle in the direction that moves the backrest backward and extends the footrest. Release the button when you reach your desired position.
- **Return Upright:** To return to the upright position, press and hold the button or toggle in the opposite direction. The footrest will retract, and the backrest will move forward. Release the button when fully upright.
- **Smooth Operation:** The power mechanism allows for smooth, incremental adjustments, enabling you to find your perfect comfort angle.



Image: An individual enjoying the reclined position of the Catnapper Griffey Power Recliner, highlighting its comfort and functionality.

Maintenance

Proper care will extend the life and appearance of your recliner.

- **Spot Cleaning:** For spills or stains, immediately blot the affected area with a clean, dry cloth. For stubborn stains, use a mild soap solution and a damp cloth, then blot dry. Always test any cleaning solution on an inconspicuous area first.
- **Regular Dusting:** Dust the recliner regularly with a soft, dry cloth.
- **Vacuuming:** Use a vacuum cleaner with a soft brush attachment to remove crumbs and debris from crevices.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the upholstery and finish.
- **Inspect Power Cord:** Periodically check the power cord for any signs of damage. If damaged, discontinue use and contact customer support.

Troubleshooting

If you encounter issues with your recliner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Recliner does not operate.	Not plugged in; power outlet issue; loose connection.	Ensure power cord is securely plugged into both the recliner and a working wall outlet. Check circuit breaker.
Recliner operates slowly or with difficulty.	Obstruction; low power; mechanism needs lubrication.	Check for obstructions around moving parts. Ensure the power cord is fully inserted. Contact customer support if issue persists.
Unusual noises during operation.	Loose hardware; foreign object in mechanism.	Inspect for loose bolts or screws and tighten if necessary. Check for any objects caught in the mechanism.

If troubleshooting steps do not resolve the issue, please contact Catnapper customer support.

Specifications

Brand	Catnapper
Model Number	64549712159
UPC/GTIN	720368838854
Color	Brown
Upholstery Material	Microfiber
Frame Material	Wood
Fill Material	Foam
Product Dimensions (D x W x H)	43"D x 45"W x 46"H
Item Weight	112 pounds

Recommended Use	Relaxing
Care Instructions	Spot Clean

Warranty and Support

For specific warranty information regarding your Catnapper Griffey Power Recliner, please refer to the documentation provided at the time of purchase or visit the official Catnapper website. For technical support, replacement parts, or any other inquiries, please contact Catnapper customer service directly.
Manufacturer: DSI Systems, Inc.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00K72VG9U

More documents and user manuals: **https://manuals.plus/**