

## Svago SV-1001

# Svago Zero Gravity Recliner Model SV-1001 User Manual

Comprehensive instructions for your Svago Zero Gravity Recliner.

## 1. INTRODUCTION

---

This manual provides essential information for the safe and effective use of your Svago Zero Gravity Recliner, Model SV-1001. Please read these instructions thoroughly before assembly and operation to ensure proper function and longevity of your product.

The Svago Zero Gravity Recliner is designed to provide a comfortable and supportive reclining experience, featuring zero-gravity positioning, massage, and heat functions, an independently adjustable footrest, and an articulating headrest.

## 2. SAFETY INFORMATION

---

- **Weight Warning:** The recliner weighs approximately 99 pounds. Do not attempt to move or assemble the chair by yourself. Always seek assistance to prevent injury or damage.
- **Indoor Use Only:** This product is designed for indoor use in a dry environment. Do not expose to moisture or extreme temperatures.
- **Careful Operation:** Use all adjustable functions, including recline, footrest, massage, and heat, with care. Ensure no obstructions are present before adjusting.
- **Children and Pets:** Keep children and pets away from the recliner's moving parts to prevent injury.
- **Power Cord:** Ensure the power cord is not pinched, tangled, or placed under the chair where it could be damaged. Disconnect from power when not in use or before cleaning.
- **Cleaning:** Refer to the maintenance section for proper cleaning instructions. Do not use abrasive cleaners or solvents.

## 3. SETUP AND ASSEMBLY

---

The Svago Zero Gravity Recliner typically arrives in three main parts and requires minimal assembly. It is recommended that two adults perform the assembly due to the weight of the components.

### 3.1 Unpacking

1. Carefully open the packaging and remove all components. Retain packaging materials for potential future transport or returns.
2. Verify all parts are present according to the packing list (not provided in this manual, refer to product packaging).
3. Place the main chair frame in the desired location, ensuring sufficient space for reclining.

### 3.2 Assembly Steps

1. Attach the backrest to the main seat frame. Align the connection points and secure them firmly.
2. Connect the footrest assembly to the main seat frame. Ensure all locking mechanisms are engaged.
3. Connect the power cord to the recliner's power input, typically located at the rear or underside of the chair. Plug the power adapter into a standard electrical outlet.
4. Place the removable Sensitemp Head & Lumbar Pillows as desired for personalized comfort.



Figure 1: Recliner Dimensions. This image illustrates the overall dimensions of the recliner, including its height, width, and depth, which are 46", 42", and 31.5" respectively.

## 4. OPERATING INSTRUCTIONS

---

Your Svago Zero Gravity Recliner offers several features for enhanced comfort and relaxation.

#### 4.1 Reclining and Zero Gravity Position

- Use the remote control or integrated side panel controls to adjust the recline angle.
- Gradually recline the chair until you reach your desired position. The chair is designed to transition smoothly into a zero-gravity position, which elevates your legs above your heart, promoting relaxation and reducing pressure on the spine.
- The footrest can be adjusted independently for optimal leg support.



Figure 2: Recliner in Zero Gravity Position. This image displays the recliner fully extended into its zero-gravity position, highlighting the elevated leg and headrest for optimal comfort.

#### 4.2 Massage and Heat Functions

- Activate the massage function using the dedicated buttons on the remote or control panel. You may be able to select different massage modes or intensities.
- Turn on the heat function for soothing warmth. The heat is typically concentrated in the lumbar area.
- Refer to the specific remote control diagram (if available with your product) for detailed button functions.

#### 4.3 Articulating Headrest

The headrest can be adjusted to provide optimal neck and head support. Manually adjust its angle or use controls if motorized, to find the most comfortable position.



Figure 3: Recliner in Upright Position. A user is shown seated in the recliner in an upright position, illustrating its comfortable design for general use.

## 5. MAINTENANCE AND CARE

---

Proper care will extend the life and appearance of your Svago Zero Gravity Recliner.

### 5.1 Cleaning the Bonded Leather

- **Regular Cleaning:** Dust the leather surface regularly with a soft, dry cloth.
- **Spot Cleaning:** For spills, immediately blot with a clean, dry cloth. For stubborn spots, use a slightly damp cloth with a mild, pH-neutral soap solution. Test on an inconspicuous area first.
- **Avoid:** Do not use harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the bonded leather.

### 5.2 General Maintenance

- **Inspections:** Periodically check all connections and fasteners to ensure they are secure. Tighten if necessary.
- **Power Cord:** Inspect the power cord for any signs of damage. If damaged, discontinue use and contact customer support.
- **Moving Parts:** Keep moving parts free from obstructions. Do not force the chair into any position.

## 6. TROUBLESHOOTING

---

If you encounter issues with your recliner, refer to the following common problems and solutions.

- **Chair Does Not Recline/Power On:**
  - Ensure the power cord is securely plugged into both the chair and a working electrical outlet.
  - Check the circuit breaker in your home.

- Verify that the power adapter is functioning correctly.
- **Remote Control Not Responding:**
  - Check if the remote control requires batteries and replace them if necessary.
  - Ensure there are no obstructions between the remote and the chair's receiver.
  - If the remote still does not work, contact customer support for a replacement or further assistance.
- **Unusual Noises During Operation:**
  - Ensure no objects are caught in the moving mechanisms of the chair.
  - Check that all assembly bolts are tightened.
  - If noises persist, discontinue use and contact customer support.

## 7. SPECIFICATIONS

---

<b>Brand</b>	Svago
<b>Model Number</b>	SV-1001
<b>Color</b>	Ivory
<b>Product Dimensions (D x W x H)</b>	31.5"D x 42"W x 46"H
<b>Item Weight</b>	99 pounds
<b>Material</b>	Bonded Leather
<b>Special Features</b>	Adjustable, Removable Sensitemp Head & Lumbar Pillows, Massage, Heat, Independently Adjustable Footrest, Articulating Headrest
<b>UPC</b>	612058872609

## 8. WARRANTY AND SUPPORT

---

For warranty information, technical support, or to inquire about replacement parts, please contact Svago customer service. Details regarding your specific warranty coverage can typically be found in the documentation included with your purchase or on the official Svago website.

When contacting support, please have your model number (SV-1001) and purchase date available.

**Contact Information:** Refer to the official Svago website or your purchase receipt for the most current customer service contact details.