

[Manuals.plus](#) /

› [Eva-Dry](#) /

› Eva-Dry E-150 Moisture Eliminator Pouch Instruction Manual

Eva-Dry E-150

Eva-Dry E-150 Moisture Eliminator Pouch Instruction Manual

Brand: Eva-Dry | Model: E-150

1. INTRODUCTION

The Eva-Dry E-150 Moisture Eliminator Pouch is designed to remove excess moisture from damp and humid environments. Utilizing safe, non-toxic micro-absorbing silica gel technology combined with activated charcoal for odor protection, this product helps prevent the growth of mold and mildew. Each package contains two 8-ounce pouches, providing effective moisture control for up to 60 days.



Figure 1: Front view of the Eva-Dry E-150 Moisture Eliminator Pouch twin pack packaging.

2. PRODUCT FEATURES

- **Effective Moisture Protection:** Designed for small enclosed spaces.
- **100% Silent Operation:** Works without noise.
- **Long-Lasting:** Provides protection for approximately 45-60 days.
- **Activated Charcoal:** Includes activated charcoal for enhanced odor protection.
- **No Messy Spills:** Designed to prevent leaks or spills.
- **Child and Pet Safe:** Formulated with non-toxic materials.
- **Compact and Portable:** Easy to place in various locations.

3. IMPORTANT SAFETY INFORMATION

Please read and adhere to the following safety guidelines to ensure proper and safe use of the Eva-Dry E-150 Moisture Eliminator Pouch:

- **DO NOT MICROWAVE** the pouches.
- **DO NOT OPEN POUCHES.** The contents are designed to work within the sealed pouch.
- **DO NOT EAT** the contents of the pouches.

- **KEEP OUT OF REACH OF CHILDREN.** Store in a safe place away from children and pets.



Figure 2: Back of the Eva-Dry E-150 packaging, showing safety warnings and instructions.

4. SETUP AND PLACEMENT

Follow these steps to set up and place your Eva-Dry E-150 Moisture Eliminator Pouch:

1. Carefully remove one or both pouches from the main resealable foil-lined packaging. The pouches are perforated and do not need to be opened.
2. Locate the "Installed" and "Replace By" section on the pouch. Write down the current date in the "Installed" field and calculate a date 60 days from the installation date to write in the "Replace By" field. This will help you track when to replace the pouch for optimal performance.
3. Place the pouch in your desired location. The E-150 is suitable for areas up to 150 cubic feet.

Recommended Placement Areas:

- Briefcases
- Shoes and shoe storage
- Cars and other vehicles
- Golf bags
- Purses
- Storage bins
- Boat cabins

- Household rooms
- Camera bags and equipment cases
- Closets
- Gun cases
- File storage
- Computer areas
- Home safes
- Pantries and refrigerators

Compact & Portable.

The E-150 convenient and disposable moisture absorbing pouch design lets you conveniently place it ANYWHERE. Perfect to combat moisture in: pantries, cars, closets, refrigerators, purses, instrument cases, camera cases, storage containers, and so much more!

 Closets
  Pantries
  Refrigerators
  Vehicles
  Purses



Figure 3: Examples of compact and portable placement areas for the Eva-Dry E-150 pouch, including closets, pantries, refrigerators, vehicles, and purses.

5. OPERATION

The Eva-Dry E-150 Moisture Eliminator Pouch operates passively. Once placed in the desired location, the micro-absorbing silica gel and activated charcoal within the pouch will begin to absorb excess moisture and odors from the surrounding air. No power source or activation is required. The pouch works silently to maintain a drier environment.

6. MAINTENANCE AND REPLACEMENT

The Eva-Dry E-150 Moisture Eliminator Pouch is a disposable product designed for single use over its lifespan. It does not require recharging or emptying. The pouch will absorb moisture until its capacity is reached.

- **Lifespan:** Each pouch is effective for approximately 45 to 60 days, depending on the humidity levels of the environment it is placed in.
- **Replacement Indicator:** Refer to the "Replace By" date you marked on the pouch during setup. When this date is reached, or if you notice a decrease in moisture absorption effectiveness, it is time to replace the pouch.
- **Disposal:** Dispose of used pouches in regular household waste.

7. SPECIFICATIONS

Brand	Eva-Dry
Model Name	E-150
Model Number	E-150
Capacity	4 ounces (per pouch)

Item Weight	8 ounces (total for twin pack)
Product Dimensions	3"D x 5"W x 5"H
Material	Carbon (activated charcoal), Desiccant (silica gel)
Special Feature	Activated Charcoal for odor protection
Operation Mode	Continuous, passive absorption
Recommended Use	Residential, small enclosed areas up to 150 cubic feet
Included Components	2 moisture eliminator pouches

8. CONTACT AND SUPPORT

For questions, comments, or support regarding your Eva-Dry E-150 Moisture Eliminator Pouch, please contact Eva-Dry directly:

Address: 12157 West Linebaugh Ave #152, Tampa, Florida 33626

Phone: 1-877-382-3790

Operating Hours: Monday - Friday, 9:00 AM - 6:00 PM EST

Website: www.eva-dry.com