

[Manuals.plus](#) /

› [ART+SOUND](#) /

› AR+SOUND AR1004 38-inch Bluetooth Tower Speaker User Manual

ART+SOUND AR1004

AR+SOUND AR1004 38-inch Bluetooth Tower Speaker User Manual

Model: AR1004

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your AR+SOUND AR1004 38-inch Bluetooth Tower Speaker. Please read this manual thoroughly before using the product to ensure proper function and to prevent damage.

IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury. Keep this manual for future reference.

- Do not expose this appliance to rain or moisture.
- Do not block any ventilation openings.
- Ensure the power cord is not walked on or pinched.
- Unplug the appliance during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- AR+SOUND AR1004 Tower Speaker
- Remote Control
- Power Adapter
- User Manual (this document)

PRODUCT OVERVIEW

The AR+SOUND AR1004 is a 38-inch tower speaker featuring Bluetooth connectivity, ambient blue LED lights, a built-in radio, and a docking station for mobile devices. It delivers stereo sound and comes with a remote control for convenient

operation.



Image: Front view of the AR+SOUND AR1004 Tower Speaker, showcasing its sleek black design and four speaker drivers with blue LED accents.



Image: Close-up of the top panel of the AR+SOUND AR1004 Tower Speaker, showing control buttons, a USB port, and the docking slot for mobile devices.

SETUP

1. Unpacking

Carefully remove all components from the packaging. Retain the packaging materials for future transport or storage.

2. Assembly (Attaching the Base)

If the base is not pre-attached, align the base with the bottom of the tower speaker and secure it using the provided screws. Ensure the speaker is stable before proceeding.

3. Power Connection

1. Connect the power adapter to the DC IN port on the back of the speaker.
2. Plug the other end of the power adapter into a standard wall outlet.
3. The speaker is now ready for operation.

OPERATING INSTRUCTIONS

1. Power On/Off

Press the **POWER** button on the top panel or the remote control to turn the speaker on or off.

2. Mode Selection

Press the **MODE** button on the top panel or remote control to cycle through available input modes: Bluetooth, FM Radio, AUX, USB.

3. Bluetooth Pairing

1. Turn on the speaker and select Bluetooth mode. The speaker will indicate it is in pairing mode (e.g., a voice prompt or flashing LED).
2. Enable Bluetooth on your mobile device (smartphone, tablet, etc.).
3. Search for "AR+SOUND AR1004" or a similar name in your device's Bluetooth settings.
4. Select the speaker to pair. Once paired, the speaker will confirm the connection.
5. You can now play audio from your device through the speaker.

4. FM Radio Operation

1. Switch the speaker to FM Radio mode.
2. Press the **SCAN** button (or similar, refer to remote) to automatically scan and save available FM stations.
3. Use the **PREV/NEXT** buttons to navigate through saved stations.

5. Auxiliary Input (AUX)

1. Connect an external audio device (e.g., MP3 player, TV) to the AUX IN port on the speaker using a 3.5mm audio cable (not included).
2. Switch the speaker to AUX mode.
3. Audio from the connected device will now play through the speaker.

6. USB Playback

1. Insert a USB flash drive containing MP3 audio files into the USB port on the top panel.
2. Switch the speaker to USB mode.
3. The speaker will automatically begin playing audio files from the USB drive. Use the playback controls (Play/Pause, Next, Previous) on the speaker or remote.

7. Docking Station

The top slot serves as a convenient docking station to hold your smartphone or tablet while it is connected via Bluetooth or AUX. This slot does not provide a direct electrical connection for audio playback or charging.

8. LED Lights Control

The ambient blue LED lights can be manually turned on or off using a dedicated button on the top panel or remote control (if available). Refer to the remote control diagram for the specific button.

9. Remote Control

The included remote control allows for convenient operation of all speaker functions from a distance. Ensure the remote has working batteries and is pointed towards the speaker's sensor.

MAINTENANCE

Cleaning

Wipe the speaker's exterior with a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents. Ensure the speaker is unplugged before cleaning.

Storage

If storing the speaker for an extended period, unplug it from the power outlet and store it in a cool, dry place, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cord not connected; outlet not working	Ensure power cord is securely plugged in; test outlet with another device.
No sound	Volume too low; incorrect input mode; device not connected	Increase volume; select correct input mode (Bluetooth, AUX, etc.); ensure device is properly paired/connected.
Bluetooth not pairing	Speaker not in pairing mode; device Bluetooth off; too far from speaker	Ensure speaker is in Bluetooth pairing mode; enable Bluetooth on your device; move device closer to speaker (within 10 meters).
Radio static	Poor signal reception	Adjust speaker position; extend antenna if available.

SPECIFICATIONS

- **Model:** AR1004
- **Product Dimensions:** 26.16 x 22.2 x 106.1 cm
- **Item Weight:** 4.51 kg
- **Connectivity:** Bluetooth
- **Special Features:** Bluetooth, Ambient Blue-LED Lights, Built-In Radio, USB Playback, AUX Input
- **Color:** Black

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the warranty card included with your product or contact ART+SOUND customer service. Keep your proof of purchase for warranty claims.
For further assistance, visit the official ART+SOUND website or contact their support channels.

© 2023 ART+SOUND. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B00K8AH6AE>

More documents and user manuals: <https://manuals.plus/>