

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Michael Kors](#) /
- › [Michael Kors Darci Women's Watch \(Model MK3298\) Instruction Manual](#)

Michael Kors MK3298

Michael Kors Darci Women's Watch (Model MK3298) Instruction Manual

Stainless Steel and Pavé Crystal Watch

1. INTRODUCTION

Welcome to your new Michael Kors Darci Women's Watch, Model MK3298. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your timepiece. Please read these instructions carefully to ensure proper use and longevity of your watch.



Image: Front view of the Michael Kors Darci Women's Watch, featuring a silver and rose gold two-tone bracelet, a pavé crystal bezel, and a minimalist dial.

2. SETUP

2.1 Setting the Time

1. **Pull out the crown:** Gently pull the crown (the small knob on the side of the watch case) out to the first position.
2. **Adjust the hands:** Turn the crown clockwise or counter-clockwise to move the hour and minute hands to the correct time.
3. **Push in the crown:** Once the time is set, push the crown back into its normal position to start the watch movement.

2.2 Adjusting the Bracelet

The stainless steel bracelet may need adjustment to fit your wrist comfortably. This typically involves adding or removing links. It is recommended to have this procedure performed by a qualified jeweler or watch technician to avoid damaging the watch or bracelet.



Image: The Michael Kors Darci watch worn on a wrist, showcasing its elegant fit and design.

3. OPERATING YOUR WATCH

Your Michael Kors Darci watch is powered by a reliable Quartz movement, ensuring accurate timekeeping. It features a simple analog display with hour and minute hands.

3.1 Water Resistance

This watch has a water resistance depth of 165 feet (50 meters), making it suitable for short periods of recreational swimming. However, it is **not** recommended for diving or prolonged water activities. Always ensure the crown is fully pushed in before any contact with water.

Your browser does not support the video tag.

Video: A 21-second overview of the Michael Kors Women's Darci Two-Tone Watch (MK3298), showcasing its design and features.

4. MAINTENANCE

4.1 Cleaning

- Wipe the watch case and bracelet regularly with a soft, dry cloth to remove dust and smudges.
- For more thorough cleaning, especially after exposure to saltwater or chlorine, use a soft brush and mild soapy water. Rinse thoroughly with fresh water and dry completely.
- Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the watch's finish and seals.

4.2 Battery Replacement

Your watch is powered by a 1 AA battery (included). When the watch stops running, it indicates that the battery needs to be replaced. It is highly recommended to have the battery replaced by a professional watchmaker or authorized service center to ensure the water resistance seal is properly maintained.

4.3 Storage

When not wearing your watch, store it in a cool, dry place, away from direct sunlight and extreme temperatures. The original watch box provides excellent protection.



Image: The white Michael Kors watch box, suitable for storing your watch when not in use.

5. TROUBLESHOOTING

5.1 Watch Not Running

- **Check the crown:** Ensure the crown is fully pushed in. If it's pulled out, the watch will not run.
- **Battery:** The battery may be depleted. Refer to section 4.2 for battery replacement.

5.2 Incorrect Time

- **Reset the time:** Follow the steps in section 2.1 to reset the time.
- **Impact:** A strong impact may affect the watch's movement. If the issue persists, professional inspection is recommended.

Your browser does not support the video tag.

Video: A 21-second video demonstrating the Michael Kors Darci Two-Tone Women's Watch, highlighting its features

and aesthetic.

6. SPECIFICATIONS

Feature	Detail
Model Number	MK3298
Brand	Michael Kors
Case Material	Stainless Steel
Band Material	Stainless Steel
Case Diameter	26 Millimeters
Band Width	12 Millimeters
Case Thickness	7 Millimeters
Crystal Type	Mineral
Movement Type	Quartz
Display Type	Analog
Water Resistance Depth	165 Feet (50 Meters)
Closure Type	Fold-over-clasp-with-double-push-button-safety
Embellishment	Crystal
Item Weight	59 Grams

Your browser does not support the video tag.

Video: A 13-second video showcasing the Michael Kors Petite Darci Three-Hand Watch with Glitz Accents, 26mm, highlighting its compact size and sparkling details.

7. WARRANTY AND SUPPORT

7.1 Manufacturer's Warranty

Your Michael Kors Darci watch comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration of coverage. Keep your proof of purchase for warranty claims.

7.2 Customer Support

For any questions, service needs, or further assistance not covered in this manual, please contact Michael Kors customer service or an authorized service center. Contact information can typically be found on the official Michael Kors website or in your watch's packaging.

