Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > Tchibo /
- Tchibo Saeco Cafissimo Latte Capsule Machine User Manual

Tchibo 301239

Tchibo Saeco Cafissimo Latte Capsule Machine User Manual

Model: 301239

INTRODUCTION

Welcome to the user manual for your new Tchibo Saeco Cafissimo Latte Capsule Machine. This machine is designed to provide a convenient way to prepare various coffee specialties, including espresso, Caffé Crema, filter coffee, latte macchiato, and cappuccino, using the patented three-pressure brewing system. Please read this manual carefully before first use to ensure proper operation, maintenance, and safety.

IMPORTANT SAFETY INSTRUCTIONS

- Always connect the appliance to a grounded power outlet.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Keep the appliance out of reach of children.
- Unplug the machine before cleaning and when not in use for extended periods.
- Do not operate the machine if the power cord or plug is damaged.
- Use only Tchibo Cafissimo capsules with this machine.
- Be cautious of hot surfaces and steam during operation.

PACKAGE CONTENTS

Upon unpacking, please ensure all components are present:

- Tchibo Saeco Cafissimo Latte Capsule Machine
- · Removable Milk Frother Nozzle
- Fold-out Espresso Table
- · Removable Drip Tray
- Water Tank (1.2L capacity)
- User Manual (this document)

PRODUCT OVERVIEW

Familiarize yourself with the main components of your Cafissimo Latte machine.



Figure 1: Front view of the Tchibo Saeco Cafissimo Latte Capsule Machine, showing the control panel, capsule slot, and milk container on the right.



Figure 2: Side view of the machine highlighting the detachable milk container, which is essential for preparing milk-based coffee specialties.



Figure 3: Close-up view of the integrated capsule collection drawer, which stores used capsules after brewing.

Control Panel Buttons:

- Power Button: Turns the machine on/off.
- Espresso Button: For brewing espresso.
- Caffé Crema Button: For brewing Caffé Crema.
- Filter Coffee/Tea Button: For brewing filter coffee or tea.
- Latte Macchiato Button: For preparing Latte Macchiato.
- Cappuccino Button: For preparing Cappuccino.
- Milk Froth Button: For dispensing frothed milk only.

INITIAL SETUP

1. **Unpack:** Remove all packaging materials and stickers from the machine.

- 2. **Clean Components:** Wash the water tank, milk container, drip tray, and espresso table with warm water and a mild detergent. Rinse thoroughly and dry.
- 3. **Fill Water Tank:** Fill the water tank with fresh, cold drinking water up to the MAX level. Place it back into the machine.
- 4. Connect Power: Plug the power cord into a suitable grounded electrical outlet (230V).
- 5. First Rinse Cycle:
 - Place a large container (at least 500ml) under the coffee spout.
 - Press the Power button to turn on the machine. The buttons will flash.
 - Once the buttons illuminate steadily, press the Filter Coffee/Tea button to initiate a rinse cycle. The machine will dispense hot water.
 - Repeat this process 2-3 times to thoroughly clean the internal system.
- 6. **Prepare Milk Container (if using milk functions):** Fill the milk container with fresh, cold milk (dairy or plant-based) up to the MAX line. Attach it to the machine.

OPERATING INSTRUCTIONS

Brewing Coffee (Espresso, Caffé Crema, Filter Coffee):

- 1. Ensure the water tank is filled.
- 2. Open the capsule lever and insert one Tchibo Cafissimo capsule into the capsule slot. Close the lever firmly.
- 3. Place a cup on the drip tray. For espresso, you can fold out the espresso table for optimal cup height.
- 4. Press the desired coffee button (Espresso, Caffé Crema, or Filter Coffee/Tea). The machine will start brewing.
- 5. The brewing process will stop automatically. Remove your cup.
- 6. Open the capsule lever to eject the used capsule into the internal collection drawer. Close the lever.




Figure 4: An assortment of Tchibo Cafissimo capsules, designed for use with this machine. Ensure to use only compatible capsules.

Preparing Milk-Based Specialties (Latte Macchiato, Cappuccino):

- 1. Ensure the water tank is filled and the milk container is filled with cold milk and properly attached.
- 2. Open the capsule lever and insert one Tchibo Cafissimo capsule. Close the lever firmly.
- 3. Place a suitable glass or cup under the milk frother nozzle and coffee spout.
- 4. Press the desired milk specialty button (Latte Macchiato or Cappuccino). The machine will first froth and dispense milk, then brew the coffee.
- 5. The process will stop automatically. Remove your drink.
- 6. Open the capsule lever to eject the used capsule. Close the lever.



Figure 5: A freshly prepared Latte Macchiato, demonstrating the layered appearance achieved by the machine's milk frothing function.

Dispensing Frothed Milk Only:

- 1. Ensure the milk container is filled with cold milk and properly attached.
- 2. Place a cup under the milk frother nozzle.
- 3. Press the Milk Froth button. The machine will dispense frothed milk.
- 4. Press the Milk Froth button again to stop dispensing.

The machine features an automatic shut-off function after 7 minutes of inactivity to save energy.

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and longevity of your machine.

Daily Cleaning:

- **Drip Tray and Capsule Container:** Empty and rinse the drip tray and the used capsule container daily. The drip tray has a float indicator to show when it needs emptying.
- Milk System: After each milk preparation, perform a quick rinse of the milk frother nozzle. For thorough cleaning, detach the milk container and disassemble the frother nozzle components. Wash them with warm water and mild detergent. The milk container can be stored in the refrigerator with remaining milk for a short period, but daily cleaning is recommended.
- Exterior: Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners.

Descaling:

The machine has an integrated descaling reminder. When the descaling indicator lights up, it's time to descale. Descaling regularly (e.g., every 3-6 months depending on water hardness and usage) is crucial for maintaining machine performance and preventing damage.

- 1. Empty the water tank, drip tray, and capsule container.
- 2. Fill the water tank with a descaling solution according to the descaler manufacturer's instructions.
- 3. Place a large container (at least 1.5L) under the coffee spout and milk frother nozzle.
- 4. Follow the specific descaling procedure outlined in the full manual (usually involves pressing a combination of buttons or holding a button for a few seconds to start the descaling program).
- 5. After the descaling cycle, rinse the water tank thoroughly and fill it with fresh water. Run 2-3 rinse cycles to remove any descaler residue.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Machine does not turn on.	No power supply.	Check if the power cord is securely plugged into the outlet and the machine. Check the fuse/circuit breaker.
No coffee is dispensed.	Water tank empty; capsule not inserted correctly; machine needs descaling.	Fill water tank; ensure capsule lever is firmly closed; descale the machine.
Milk does not froth properly.	Milk container not clean; milk too warm; milk frother nozzle clogged.	Clean milk container and nozzle thoroughly; use cold milk; check for blockages in the nozzle.
Water leaks under the machine.	Drip tray full; water tank not seated correctly; internal leak.	Empty drip tray; ensure water tank is properly inserted; if leak persists, contact customer support.
Machine is unusually loud.	Air in the system; machine needs descaling.	Run a rinse cycle to prime the pump; descale the machine.

If the problem persists after attempting these solutions, please contact Tchibo customer support.

TECHNICAL SPECIFICATIONS

Feature	Detail
Brand	Tchibo
Model Number	301239

Feature	Detail
Color	Black
Dimensions (L x W x H)	30 x 20 x 40 cm
Weight	1 Kilogram
Water Tank Volume	1.2 Liters
Voltage	230 Volts
Max. Pump Pressure	12.5 Bar
Automatic Shut-off	Yes (after 7 minutes)
Special Features	Milk Frother, Patented Three-Pressure Brewing System




Figure 6: Diagram illustrating the dimensions of the Tchibo Saeco Cafissimo Latte Capsule Machine, with a height of 29.5 cm shown.



Figure 7: Graphic illustrating the patented three-pressure brewing system, which allows for optimal preparation of three different coffee types.

WARRANTY AND SUPPORT

Your Tchibo Saeco Cafissimo Latte Capsule Machine comes with a standard manufacturer's warranty. Please refer to the warranty card included in your original packaging for specific terms and conditions, including warranty period and coverage details.


For technical support, spare parts, or warranty claims, please contact Tchibo customer service. Contact information can typically be found on the Tchibo official website or on your purchase receipt.

Online Support: Visit the official Tchibo website for FAQs, troubleshooting guides, and contact forms.

Customer Service Hotline: Refer to your product documentation or the Tchibo website for the relevant customer service telephone number in your region.

© 2025 Tchibo. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.



Comprehensive guide to operating and maintaining the Tchibo Cafissimo pure+ coffee machine, including setup, usage instructions, cleaning, and troubleshooting. Tchibo Cafissimo pure+ Coffee Machine: User Manual & Warranty User manual and warranty guide for the Tchibo Cafissimo pure+ coffee machine. Learn about setup, operation, brewing coffee, machine care, descaling, troubleshooting, and warranty details for Tchibo Cafissimo pure+ Kaffeemaschine Bedienungsanleitung und Garantie Umfassende Bedienungsanleitung und Garantieinformationen für die Tchibo Cafissimo pure+ Kaffeemaschine (Modell MCA21102). Enthält Anweisungen zur Inbetriebnahme, Zubereitung, Tchibo Esperto Latte Automatic Coffee Machine User Manual and Warranty Comprehensive user manual and warranty guide for the Tchibo Esperto Latte automatic coffee machine. Includes safety instructions, operation, cleaning, maintenance, and troubleshooting. Tchibo Cafissimo pure+ User Manual and Instructions This document provides comprehensive instructions for the Tchibo Cafissimo pure+ coffee machine, covering setup, operation, safety, maintenance, descaling, and troubleshooting. Learn how to make perfect coffee, espresso, and caffè crema. Tchibo Cafissimo pure+ Coffee Machine User Manual Comprehensive user manual for the Tchibo Cafissimo pure+ coffee machine, covering setup, operation, maintenance, descaling, troubleshooting, and warranty information for optimal coffee preparation.