

Vestil LC-803

Vestil LC-803 Multi-Function Luggage Cart Instruction Manual

Model: LC-803

1. INTRODUCTION

This manual provides essential instructions for the safe and effective use, setup, operation, and maintenance of your Vestil LC-803 Multi-Function Luggage Cart. Please read this manual thoroughly before operating the product and retain it for future reference.

The Vestil LC-803 is designed to transport luggage and other items, and can also convert into a portable seat. Its robust construction ensures durability and reliability for various applications.

2. SAFETY INFORMATION

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- Do not exceed the maximum load capacity of 225 pounds (102 kg).
- Ensure all locking mechanisms are securely engaged before use, both as a cart and as a chair.
- Distribute weight evenly on the cart to maintain stability.
- Do not use on uneven or excessively sloped surfaces.
- Keep hands and fingers clear of moving parts during folding and unfolding.
- This product is not intended for use by children without adult supervision.
- Inspect the cart for any damage or loose parts before each use. Do not use if damaged.

3. SETUP AND ASSEMBLY

The Vestil LC-803 Multi-Function Luggage Cart comes pre-assembled and requires minimal setup for initial use.

3.1 Unfolding for Cart Use

1. Place the folded cart on a flat, stable surface.
2. Gently pull the handle upwards until the main frame extends.

3. Lower the base plate until it locks into position. Ensure it is fully extended and stable.
4. Extend the telescopic handle to your desired height. Ensure the locking pins or buttons engage securely.





Figure 1: The Vestil LC-803 Multi-Function Luggage Cart in its compact, folded state, ready for storage or transport. The handle is retracted, and the base plate is folded upwards.

3.2 Converting to Chair Use

1. Ensure the cart is in its fully unfolded position as described in Section 3.1.
2. Locate the release mechanism for the base plate (often a lever or button).
3. Carefully pivot the base plate downwards and outwards to form the seat.
4. Extend the support legs until they lock into place, ensuring the chair is stable on all four points.
5. The backrest will automatically position itself as the seat is formed.



Figure 2: The Vestil LC-803 Multi-Function Luggage Cart transformed into a portable chair. The base plate has been lowered to form the seat, and the support legs are extended for stability.

4. OPERATING INSTRUCTIONS

4.1 Using as a Luggage Cart

- Ensure the cart is fully unfolded and the handle is extended to a comfortable height.
- Place items securely on the base plate. For taller items, use bungee cords or straps (not included) to secure them to the frame.
- Tilt the cart slightly backward to engage the wheels and pull or push the cart.
- Avoid sudden movements or overloading to prevent tipping.

4.2 Using as a Portable Chair

- Ensure the cart is fully converted to chair mode with all support legs locked.
- Verify the chair is stable on a flat, level surface before sitting.
- Sit gently and avoid sudden shifts in weight.
- Do not stand on the chair or use it as a step stool.

5. MAINTENANCE

- **Cleaning:** Wipe down the frame and plastic components with a damp cloth and mild detergent. Avoid abrasive cleaners.
- **Lubrication:** Periodically apply a silicone-based lubricant to moving parts (hinges, telescopic handle mechanism) to ensure smooth operation.
- **Inspection:** Regularly check for loose screws, bolts, or damaged components. Tighten any loose fasteners. Replace damaged parts immediately.
- **Storage:** Store the cart in a clean, dry place when not in use. Fold it into its compact form for efficient storage.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Cart does not fold/unfold smoothly.	Dirt or debris in hinges; lack of lubrication; bent frame.	Clean hinges and apply lubricant. If frame is bent, contact support.
Handle does not lock at desired height.	Locking pins/buttons obstructed or damaged.	Clear any obstructions. Inspect locking mechanism for damage.
Chair feels unstable.	Support legs not fully extended/locked; uneven surface.	Ensure all legs are locked. Move to a flat, level surface.
Wheels are stiff or squeaky.	Dirt/debris in wheel bearings; lack of lubrication.	Clean wheels and axles. Apply a small amount of lubricant if accessible.

7. SPECIFICATIONS

Feature	Detail
Model Name	LC-803

Feature	Detail
Brand	Vestil
Material	Blend (Metal frame, Plastic components)
Color	Multicolor (typically black and chrome)
Wheel Type	Plastic
Load Capacity	225 Pounds (102 kg)
Item Dimensions (LxWxH)	16.5 x 12 x 32.5 inches (approx. 41.9 x 30.5 x 82.5 cm)
Package Dimensions (LxWxH)	28.35 x 12.52 x 3.86 inches (approx. 72 x 31.8 x 9.8 cm)
Package Weight	8.9 Pounds (approx. 4.0 kg)
UPC	691215026383

8. WARRANTY INFORMATION

Vestil Manufacturing Co. products are designed and manufactured to high-quality standards. For specific warranty details, including coverage period and terms, please refer to the warranty card included with your purchase or visit the official Vestil website. Keep your proof of purchase for any warranty claims.


9. CUSTOMER SUPPORT






If you have any questions, require assistance with setup, operation, or maintenance, or need to report a problem, please contact Vestil customer support.

- **Website:** www.vestil.com (for general inquiries and product information)
- **Contact Information:** Refer to the Vestil website or your product packaging for the most current customer service contact details (phone number, email).

When contacting support, please have your model number (LC-803) and purchase date available.

Related Documents - LC-803

	<p>Vestil FORK-R-54 Fork Extension Storage Rack Instruction Manual</p> <p>Official instruction manual for the Vestil FORK-R-54 Fork Extension Storage Rack. Includes specifications, safety, assembly, usage, maintenance, and warranty information.</p>
---	--

	<p>Vestil Limited Warranty - Product Information</p> <p>Official limited warranty document from Vestil Manufacturing Corporation detailing product coverage, warranty periods, exclusions, and service request procedures.</p>
	<p>Vestil DRUM-55S Portable Drum Jack Operation and Service Manual</p> <p>This manual provides comprehensive operational, service, and maintenance guidelines for the Vestil DRUM-55S Portable Drum Jack. It includes detailed specifications, safety warnings, operating procedures, troubleshooting tips, a complete parts list, and warranty information.</p>
	<p>Vestil SWA-50, SWA-70, SWA-51-AR Semi-Automatic Stretch Wrap Machine Instruction Manual</p> <p>Official instruction manual for Vestil Manufacturing's SWA-50, SWA-70, and SWA-51-AR semi-automatic stretch wrap machines. Covers installation, operation, maintenance, troubleshooting, and safety.</p>
	<p>Vestil OLA-4 Series Balanced Load Lifters - User and Maintenance Manual</p> <p>This comprehensive manual provides detailed instructions for the safe operation, maintenance, and specifications of Vestil OLA-4 series balanced load lifters, including models OLA-4-42, OLA-4-36-DLX, and OLA-4-42-DLX. It covers essential safety guidelines, adjustment procedures, load testing, inspections, and warranty information for industrial material handling applications.</p>
	<p>Vestil E-TUG-HD Series Electric Powered Tugger Operation and Maintenance Manual</p> <p>Comprehensive operation and maintenance manual for the Vestil E-TUG-HD Series Electric Powered Tugger, covering safety, usage, troubleshooting, and warranty information for models E-TUG-HD-30, E-TUG-HD-50, E-TUG-HD-70, and E-TUG-HD-100.</p>