

[Manuals.plus](#) /

› [Razor](#) /

› Razor E100 Glow Electric Scooter User Manual

Razor E100 Glow

Razor E100 Glow Electric Scooter User Manual

Model: E100 Glow | Brand: Razor

INTRODUCTION

This manual provides essential information for the safe assembly, operation, and maintenance of your Razor E100 Glow Electric Scooter. Please read this manual thoroughly before use to ensure proper function and to maximize your riding experience. The Razor E100 Glow Electric Scooter is designed for riders aged 8 and up, featuring a light-up deck and an 8-inch air-filled front tire for a smooth ride.



Figure 1: The Razor E100 Glow Electric Scooter, showcasing its sleek design and light-up deck.

SETUP AND INITIAL PREPARATION

1. Assembly

Some assembly is required for the Razor E100 Glow Electric Scooter. Carefully follow the instructions provided in the separate assembly guide to attach the handlebars and ensure all connections are secure. Verify that all bolts and fasteners are tightened before first use.



Figure 2: Detail of the handlebar assembly, including the twist-grip throttle and hand-operated brake lever.

2. Initial Charging

Before the first ride, fully charge the scooter's battery. The initial charging time is approximately 12 hours. Ensure the scooter is turned off during charging. The battery should always be left at a full charge when not in use to prolong its lifespan. Recharge monthly if stored for extended periods, and avoid freezing temperatures.



Figure 3: Location of the retractable kickstand, charging port, and power on/off switch on the scooter's deck.

3. Pre-Ride Checks

- **Tires:** Check the pneumatic front tire for proper inflation.
- **Brakes:** Test the hand-operated front brake to ensure it functions correctly.
- **Connections:** Verify all cables and connections are secure and undamaged.
- **Safety Gear:** Always wear appropriate safety gear, including a helmet and knee/elbow pads, before riding.

OPERATING INSTRUCTIONS

1. Starting the Scooter

The Razor E100 Glow Electric Scooter features a kick-to-start motor. To engage the motor, first turn on the power switch located on the underside of the deck. Then, push off with your foot to reach a speed of approximately 3 miles per hour (5 km/h) before twisting the acceleration control on the handlebar. The motor will then engage, providing electric power.



Figure 4: A rider demonstrating the kick-to-start motion on the Razor E100 Glow Electric Scooter.

2. Riding and Control

- **Acceleration:** Use the twist-grip acceleration control on the right handlebar to control your speed. The scooter can reach speeds up to 10 mph (16 km/h).
- **Braking:** The hand-operated front brake on the left handlebar allows for controlled stopping. Apply gentle pressure to slow down or stop.
- **Light-Up Deck:** The LED lights on the deck illuminate when the throttle is twisted, enhancing visibility and adding a unique glow to your ride.
- **Ride Time:** Enjoy up to 40 minutes of continuous ride time on a full charge, depending on rider weight, terrain, and riding style.



Figure 5: The glowing LED lights integrated into the scooter's deck, active during operation.

3. Official Product Video

Your browser does not support the video tag.

Video 1: Official "E100 Glow Ride Video" by Razor USA LLC, demonstrating the scooter's features and riding experience.

MAINTENANCE

1. Battery Care

The scooter uses lead-acid batteries. To ensure optimal battery life and performance:

- Always fully charge the battery after each use, even for short rides.
- Do not leave the battery discharged for extended periods.
- Recharge the battery monthly if the scooter is not in regular use to prevent self-discharge.
- Store the scooter and battery in a heated area during cold winter months, as freezing temperatures can damage lead-acid batteries.

2. Tire and Brake Inspection

Regularly inspect the 8-inch pneumatic front tire for proper inflation and signs of wear. Check the hand-operated brake for responsiveness and adjust if necessary to ensure effective stopping power. The rear wheel is urethane and generally requires less maintenance.

3. General Cleaning and Inspection

Keep the scooter clean by wiping it down with a damp cloth. Avoid using harsh chemicals. Periodically inspect the entire scooter for loose parts, damaged cables, or any other signs of wear that may affect its safe operation. The all-steel frame and

fork construction are designed for durability.

TROUBLESHOOTING

Motor Not Engaging

If the motor does not engage when the throttle is twisted, ensure the scooter has been kick-started to at least 3 miles per hour (5 km/h). The motor is designed to engage only after a certain initial speed is achieved for safety and efficiency. Verify the power switch is in the "ON" position and the battery is sufficiently charged.

Reduced Performance or Short Ride Time

This can often be attributed to battery issues. Refer to the "Battery Care" section under Maintenance. Ensure the battery is fully charged for 12 hours before use. Factors such as rider weight, riding surface, incline, ambient temperature, and riding style (frequent stopping/starting) can also affect performance and range.

Brake Issues

If the hand-operated brake feels loose or ineffective, it may need adjustment. Consult the assembly guide for instructions on adjusting the brake cable tension. If the issue persists, contact customer support.

SPECIFICATIONS

Brand	Razor
Model Name	E100 Glow
Color	Glow Black
Age Range (Description)	Kid (8 and up)
Weight Limit	120 Pounds
Product Dimensions (LxWxH)	33.1"L x 16.1"W x 35.7"H
Item Weight	26 Pounds
Number of Wheels	2
Wheel Material	Polyurethane
Front Tire Type	8" Pneumatic
Frame Material	Alloy Steel
Special Feature	Lights, Adjustable Handlebar Height
Brake Style	Front Braking (Hand-operated)
Charging Time	12 Hours
Maximum Distance Range	Up to 65 Miles (Note: Varies based on factors)

WARRANTY AND SUPPORT

Warranty Information

The Razor E100 Glow Electric Scooter comes with a 90-day Limited Manufacturer Warranty. Please retain your proof of purchase for any warranty claims. This warranty covers manufacturing defects and does not cover damage due to misuse, accidents, or normal wear and tear.

Additional Resources

For further assistance, detailed FAQs, or to purchase replacement parts, please visit the official Razor website. You can also refer to the digital user guides available:

- [User Guide \(PDF\)](#)
- [User Manual \(PDF\)](#)