

[Manuals.plus](#) /

> [hansgrohe](#) /

> Hansgrohe 98504000 Chrome Bathtub Faucet Replacement Part User Manual

hansgrohe 98504000

Hansgrohe 98504000 Chrome Bathtub Faucet Replacement Part User Manual

Model: 98504000

1. INTRODUCTION

This manual provides essential information for the installation, operation, maintenance, and troubleshooting of your Hansgrohe 98504000 Chrome Bathtub Faucet Replacement Part. Please read these instructions carefully before beginning installation or use to ensure proper function and longevity of the product. This component is designed to replace specific parts within a Hansgrohe bathtub faucet system.



Image 1.1: The Hansgrohe 98504000 Chrome replacement part, a component for bathtub faucets.

2. SETUP AND INSTALLATION

Installation of the Hansgrohe 98504000 replacement part should be performed by a qualified professional or an individual with appropriate plumbing experience. Ensure all necessary tools are available and follow local plumbing codes.

2.1 Before You Begin

- **Turn off Water Supply:** Locate the main water shut-off valve for your home or the specific bathroom and turn it off completely.
- **Gather Tools:** You may need a wrench, screwdriver, plumber's tape, and a bucket.
- **Inspect Existing Faucet:** Identify the part to be replaced and ensure it matches the Hansgrohe 98504000.

2.2 Installation Steps

1. **Drain Water:** Open the existing faucet to drain any remaining water from the lines.
2. **Remove Old Part:** Carefully remove the old or damaged component from the bathtub faucet assembly. Refer to your specific faucet model's diagram for precise removal instructions.
3. **Clean Area:** Clean any debris or mineral buildup from the area where the new part will be installed.
4. **Install New Part:** Position the Hansgrohe 98504000 replacement part into the faucet body. Ensure it is seated

correctly and securely.

- 5. **Tighten Connections:** Hand-tighten any connections first, then use a wrench to gently tighten, being careful not to overtighten.
- 6. **Restore Water Supply:** Slowly turn the main water supply back on.
- 7. **Check for Leaks:** Inspect all connections for any signs of leaks. If leaks are present, turn off the water supply and re-tighten connections.

3. OPERATING INSTRUCTIONS

As a replacement part, the Hansgrohe 98504000 itself does not have direct operating controls. Its function is to restore the proper operation of your existing Hansgrohe bathtub faucet. Once installed correctly, the faucet should operate as intended by its original design.

- **Water Flow:** The replacement part ensures correct water flow and temperature regulation through the faucet.
- **Handle Functionality:** If the part relates to the handle mechanism, its proper installation will restore smooth and precise control of water.

4. CARE AND MAINTENANCE

Proper care and maintenance will extend the life and preserve the finish of your Hansgrohe product.

- **Cleaning:** Clean the chrome finish regularly with a soft cloth and a mild, non-abrasive cleaner. Avoid using harsh chemicals, abrasive sponges, or cleaners containing alcohol, ammonia, or bleach, as these can damage the finish.
- **Water Spots:** To prevent water spots, wipe the surface dry after each use.
- **Inspection:** Periodically inspect the connections for any signs of wear or leaks. Address any issues promptly to prevent further damage.

5. TROUBLESHOOTING

This section addresses common issues you might encounter after installing the replacement part.

Problem	Possible Cause	Solution
Leakage at connections	Loose connections, damaged O-rings/gaskets, improper installation.	Turn off water supply. Check and tighten all connections. Replace O-rings or gaskets if damaged. Ensure plumber's tape was used where appropriate.
Reduced water flow	Debris in water lines, partially closed shut-off valve, aerator blockage (if applicable to the faucet).	Check if the main water supply valve is fully open. Clean the aerator of the faucet. Flush water lines if debris is suspected.
Faucet not operating smoothly	Incorrect installation of the replacement part, internal component misalignment.	Review installation steps. If the issue persists, professional assistance may be required to diagnose internal faucet issues.

6. SPECIFICATIONS

Key specifications for the Hansgrohe 98504000 Chrome Bathtub Faucet Replacement Part:

- **Manufacturer:** Hansgrohe

- **Part Number:** 98504000
- **Item Weight:** 2.88 pounds
- **Package Dimensions:** 7 x 4 x 4 inches
- **Color:** Chrome
- **Item Package Quantity:** 1
- **Batteries Required?:** No
- **ASIN:** B00KCNC74W
- **Date First Available:** October 24, 2014

7. WARRANTY INFORMATION

Hansgrohe products are manufactured to the highest quality standards. For specific warranty terms and conditions applicable to the 98504000 replacement part, please refer to the official Hansgrohe warranty documentation provided with your original faucet purchase or visit the official Hansgrohe website. Generally, Hansgrohe offers a limited lifetime warranty on many of its products, covering manufacturing defects under normal use.

Please retain your proof of purchase for warranty claims.

8. CUSTOMER SUPPORT

If you require further assistance or have questions regarding your Hansgrohe 98504000 replacement part, please contact Hansgrohe customer service.

- **Website:** Visit the official Hansgrohe website for support resources, FAQs, and contact information.
- **Contact:** Refer to the packaging or the Hansgrohe website for phone numbers or email contacts for your region.

When contacting support, please have your product model number (98504000) and purchase details ready.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B00KCNC74W>

More documents and user manuals: <https://manuals.plus/>