

Manuals.plus /

- › Kokido /
- › Kokido Venturi Classic Pool Cleaner with 1.22m Pole Instruction Manual

Kokido K189CS/NA

Kokido Venturi Classic Pool Cleaner with 1.22m Pole Instruction Manual

INTRODUCTION

The Kokido Venturi Classic Pool Cleaner is a manual cleaning device designed for efficient debris removal from above-ground pools that do not have a dedicated filtration system. Utilizing the Venturi effect, this cleaner operates by connecting to a standard garden hose, eliminating the need for an external pump or electrical power. It is an ideal solution for maintaining a clean pool bottom with minimal effort.

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your Kokido Venturi Classic Pool Cleaner to ensure optimal performance and longevity.

SAFETY INFORMATION

- Always read and understand all instructions before using the product.
- Ensure all connections are secure before operating the cleaner.
- Do not use the cleaner if any parts are damaged. Contact customer support for replacement parts.
- Keep children and pets away from the pool area during cleaning operations.
- Store the cleaner in a safe, dry place when not in use.

PACKAGE CONTENTS

Please verify that all components are present before assembly:

- Venturi Classic Cleaner Head
- 1.22m (48 inch) Telescopic Pole
- Debris Collection Bag
- Hose Adapter (for standard garden hose connection)

SETUP

1. **Assemble the Pole:** Connect the sections of the 1.22m telescopic pole firmly. Ensure the locking mechanisms (if present) are engaged.
2. **Attach Cleaner Head:** Securely attach the Venturi Classic cleaner head to the end of the assembled pole. The connection should be snug to prevent detachment during use.
3. **Connect Debris Bag:** Attach the debris collection bag to the designated area on the cleaner head. Ensure it is properly seated to capture all debris.
4. **Connect Garden Hose:** Attach a standard garden hose to the hose adapter on the cleaner head. Tighten the connection to prevent leaks.





Image: The Kokido Venturi Classic Pool Cleaner fully assembled with its pole, demonstrating its approximate total length of 55 inches (139 cm) for scale.

OPERATING INSTRUCTIONS

The Venturi Classic cleaner operates using water pressure from your garden hose to create a suction effect.

1. **Submerge the Cleaner:** Slowly lower the assembled cleaner into the pool, ensuring the cleaner head is fully submerged.
2. **Turn on Water:** Turn on the water supply to your garden hose. Water will flow through the cleaner head, creating a powerful suction that lifts debris from the pool bottom into the collection bag.
3. **Clean the Pool Bottom:** Gently guide the cleaner head across the bottom of your pool. Move it slowly to allow the suction to effectively pick up dirt, leaves, and other debris.
4. **Monitor Debris Bag:** Periodically check the debris collection bag. If it becomes full, turn off the water, remove the cleaner from the pool, and empty the bag.
5. **Finish Cleaning:** Once the pool bottom is clean, turn off the water supply and carefully remove the cleaner from the pool.

MAINTENANCE

- **Rinse After Use:** After each use, rinse the cleaner head, pole, and debris bag thoroughly with fresh water to remove any chemical residue or remaining debris.
- **Clean Debris Bag:** Empty and clean the debris collection bag regularly. A clean bag ensures maximum suction efficiency.
- **Inspect for Damage:** Periodically inspect all components for signs of wear or damage. Replace any worn or broken parts immediately to maintain performance and safety.
- **Proper Storage:** Store the cleaner in a cool, dry place away from direct sunlight and extreme temperatures. Disassemble the pole if desired for more compact storage.

TROUBLESHOOTING

- **Poor Suction:**
 - Ensure the garden hose is fully turned on and providing adequate water pressure.
 - Check if the debris collection bag is full and needs emptying.
 - Inspect the cleaner head for any blockages or large debris obstructing the water flow.

- Verify that the hose connection is tight and not leaking.
- **Debris Not Collecting:**
 - Ensure the debris collection bag is properly attached and not torn.
 - Confirm sufficient water pressure is being supplied.
- **Cleaner Head Not Moving Smoothly:**
 - Check the pool bottom for large obstacles.
 - Ensure the pole is securely assembled and not bending excessively.

SPECIFICATIONS

Model Name	Venturi Classic
Item Model Number	K189CS/NA
Brand	Kokido
Product Type	Pool Bottom Cleaner
Material	Composite
Color	Multicolored
Pole Length	1.22 meters (48 inches)
Power Source	Water pressure from standard garden hose
Special Feature	Operates in above-ground pools without a dedicated purifier/filtration system
Product Dimensions (L x W x H)	17.78 x 2.54 x 17.78 cm (cleaner head only); 680 grams (total weight)
UPC	877039001380

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Kokido website. Keep your purchase receipt as proof of purchase for any warranty claims.