CubicFun MC178H

CubicFun 3D Puzzle MC178H Masjid Al-Haram

Instruction Manual

Introduction

This manual provides detailed instructions for the assembly and care of your CubicFun 3D Puzzle, model MC178H, depicting Masjid Al-Haram. This 249-piece puzzle is designed for an engaging and educational building experience. Please read all instructions carefully before beginning assembly.

Safety Information

- **Choking Hazard:** This product contains small parts and is not suitable for children under 3 years of age.
- **Recommended Age:** This puzzle is recommended for ages 8 and up.
- **Adult Supervision:** Adult supervision is recommended during assembly, especially for younger children.

Setup and Assembly

The CubicFun 3D Puzzle is designed for easy assembly without the need for scissors or glue. The estimated construction time is approximately 4 hours or more, depending on individual pace.

1. **Unpack Components:** Carefully open the box and remove all puzzle sheets and the instruction booklet. Identify the different sheets of puzzle pieces.
2. **Familiarize with Pieces:** Review the included booklet for a visual guide to the puzzle pieces and their corresponding numbers. Each piece is pre-cut and can be gently pushed out from the foam board.
3. **Follow Illustrated Steps:** The assembly process is sequential. Refer to the detailed illustrations in the included booklet for step-by-step guidance. Each step will show which pieces to detach and how to connect them.
4. **Connect Pieces:** Pieces are designed to interlock. Align the tabs and slots carefully and press gently to secure them. Do not force pieces if they do not fit, as this may cause damage. Double-check the orientation and piece numbers.
5. **Build Sections:** The puzzle is typically built in sections, which are then combined to form the complete

structure. Pay attention to the order of assembly for each section.




Image: Step-by-step visual guide for assembling the 3D puzzle, illustrating the progression from individual sheets to connected components.

Continue following the instructions in the booklet until all 249 pieces are assembled to complete the Masjid Al-Haram model.



Image: The fully assembled CubicFun 3D Puzzle of Masjid Al-Haram, showcasing its intricate details and overall dimensions.

Operating (Display)

Once assembled, your CubicFun 3D Puzzle is ready for display. Place the completed model on a stable, flat surface. The model is designed for indoor use.

Maintenance

- **Cleaning:** To clean the model, gently dust it with a soft, dry cloth or a soft brush. Avoid using water or cleaning solutions, as they may damage the paper and EPS foam core material.
- **Storage:** Keep the model away from direct sunlight, high humidity, and extreme temperatures to prevent fading, warping, or damage to the materials.
- **Handling:** Handle the model with care to avoid accidental damage to delicate parts.

Troubleshooting

- **Pieces Not Fitting:** Ensure you are using the correct pieces for the current step by checking their numbers and shapes against the instruction booklet. Verify the orientation of the pieces. Do not force pieces together.
- **Missing or Damaged Pieces:** If you find any pieces are missing or damaged upon opening the package,

please contact CubicFun customer support for assistance.

- **Model Instability:** Ensure all connections are securely fastened. If a section feels loose, re-examine the connections to ensure pieces are fully interlocked.

Specifications

Feature	Detail
Model Number	MC178H
Number of Pieces	249
Assembled Dimensions (L x W x H)	61 x 47 x 27.5 cm (24.0" x 18.5" x 10.8")
Material	Paper & EPS Foam Core
Recommended Age	8 years and up
Approximate Construction Time	4+ hours
Assembly Required	Yes (manual assembly)
Batteries Required	No

Warranty Information

Specific warranty details for this CubicFun product are not provided in the available information. Please refer to the product packaging or contact the retailer/manufacturer directly for any warranty-related inquiries.

Customer Support

For further assistance, missing parts, or inquiries regarding your CubicFun 3D Puzzle, please refer to the contact information provided on the product packaging or visit the official CubicFun website.

© 2023 CubicFun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question