



[Manuals.plus](#) /

› [HAND](#) /

› [HAND No.2 Square Ink Box User Manual](#)

HAND No.2 Square Ink Box

HAND No.2 Square Ink Box User Manual

Model: No.2 Square Ink Box

INTRODUCTION

Thank you for choosing the HAND No.2 Square Ink Box. This manual provides essential information for the proper setup, operation, and maintenance of your new ink box. Please read these instructions carefully before use to ensure optimal performance and longevity of the product.



Image: Two HAND No.2 Square Ink Boxes. One box is open, revealing its black plastic construction and the 'Shun Lai' branding in white. The second box is still sealed in clear plastic packaging, also showing the 'Shun Lai' branding. Both boxes are square and black.

SETUP

1. **Unpacking:** Carefully remove the ink box from its packaging. Inspect for any signs of damage.
2. **Initial Inspection:** Open the ink box lid. The ink pad should be securely seated within the box.
3. **Refilling (Optional):** The HAND No.2 Square Ink Box comes with an ink pad that can be refilled. If the pad appears dry or you wish to use a specific ink color, apply a small amount of ink evenly across the pad surface. Allow the ink to soak in completely before use. Do not overfill.

OPERATING INSTRUCTIONS

Using the HAND No.2 Square Ink Box is straightforward:

1. **Open the Lid:** Gently lift the lid of the ink box to expose the ink pad.
2. **Apply Stamp:** Press your stamp firmly and evenly onto the ink pad. Ensure the entire surface of the stamp that you wish to ink makes contact with the pad.
3. **Stamp Surface:** Press the inked stamp onto your desired surface (e.g., paper, fabric). Apply even pressure for a clear impression.
4. **Close Lid:** After use, securely close the lid of the ink box to prevent the ink pad from drying out.

MAINTENANCE

- **Storage:** Always store the ink box with the lid securely closed in a cool, dry place away from direct sunlight. This prevents the ink pad from drying prematurely.
- **Refilling:** When the ink pad starts to produce faint impressions, it's time to refill. Use a compatible ink type for best results. Apply ink sparingly and evenly.
- **Cleaning:** The plastic casing can be wiped clean with a damp cloth. Avoid using harsh chemicals that may damage the plastic or affect the ink pad. Do not attempt to wash the ink pad itself.

TROUBLESHOOTING

Problem: Ink pad appears dry or produces faint impressions.

Solution: The ink pad likely needs refilling. Apply a small amount of compatible ink evenly over the pad surface. Ensure the lid is closed tightly after each use to prevent drying.

Problem: Stamp impressions are uneven or blurry.

Solution: Ensure you are pressing the stamp firmly and evenly onto both the ink pad and the stamping surface. Check if the ink pad has enough ink and is evenly distributed. Clean your stamp if there is any residue affecting the impression.

SPECIFICATIONS

Model: HAND No.2 Square Ink Box

Material: Plastic

Dimensions (L x W x H): Approximately 80 x 80 x 20 mm (3.15 x 3.15 x 0.79 inches)

Weight: Approximately 28 Grams

Shape: Square

Refillable: Yes

WARRANTY INFORMATION

No specific warranty information is provided for this product. Please refer to the retailer's return policy for details regarding returns or exchanges.

CUSTOMER SUPPORT

For further assistance or inquiries, please contact the retailer or the manufacturer directly. Contact information may be available on the product packaging or the retailer's website.