Caddytek CaddyLite 11.5 V3

Caddytek CaddyLite 11.5 V3 Golf Push Cart User Manual

Model: CaddyLite 11.5 V3 | Brand: Caddytek

1. Introduction

This manual provides essential instructions for the safe and efficient assembly, operation, and maintenance of your Caddytek CaddyLite 11.5 V3 Golf Push Cart. Please read this manual thoroughly before using the product and retain it for future reference.

2. Safety Information

- Always ensure the cart is fully unfolded and locked before attaching your golf bag.
- Engage the foot brake when parking the cart, especially on inclines.
- Do not overload the cart beyond its intended capacity.
- Keep hands and fingers clear of moving parts during folding and unfolding operations.
- Regularly inspect the cart for any signs of wear or damage. Do not use if damaged.

3. Package Contents

Verify that all components are present in the package:

- Foldable frame with front wheel
- 2 Rear wheels
- Umbrella holder + mount
- Drink holder
- Handle mesh net
- Magnetic steel pad
- Adjustment tools
- User manual (this document)

4. Setup and Assembly

Follow these steps to assemble your CaddyLite 11.5 V3 Golf Push Cart:

1. **Unfolding the Frame:**

   Place the folded cart on a flat surface. Release any locking mechanisms and gently pull the frame apart until it fully extends and locks into the open position. Ensure all joints are securely engaged.

Image: The CaddyLite 11.5 V3 Golf Push Cart shown in both its compact folded configuration and its fully extended, ready-to-use state.

2. **Attaching the Rear Wheels:**

   Locate the two rear wheels. Press the quick-release button on the wheel hub and slide the wheel onto the axle until it clicks securely into place. Repeat for the second rear wheel.

3. **Installing Accessories:**
   - **Umbrella Holder:** Insert the umbrella holder into its designated slot on the handle assembly and tighten the securing knob.
   - **Drink Holder:** Attach the drink holder to the handle as desired.
   - **Mesh Net:** Secure the mesh net to the handle area for additional storage.

Image: Detailed view of the cart's handle area, highlighting the integrated drink holder, umbrella holder, mesh net for storage, and a dedicated golf ball slot.

5. Operating Instructions

5.1 Attaching Your Golf Bag

Place your golf bag onto the cart's bag supports. Use the elastic upper and lower straps to securely fasten the bag to the cart. Ensure the bag is centered and stable.

Image: A close-up illustrating the specialized lower support on the cart, designed to perfectly accommodate stand bags and other golf bag types.

5.2 Adjusting the Handle

The ergonomic TPR handle can be adjusted to suit your height. Locate the handle adjustment mechanism (typically a lever or knob) and release it. Adjust the handle to your desired height and then secure the mechanism firmly.

Image: The CaddyLite 11.5 V3 demonstrating its adjustable handle, capable of being set at various heights for user comfort.

5.3 Using the Foot Brake

To engage the brake, press down on the red foot pedal located near one of the rear wheels. To release the brake, lift the pedal upwards. Always engage the brake when the cart is stationary.

Image: A detailed view of the foot brake system on the CaddyLite 11.5 V3, indicating its position and operation for secure parking.

5.4 Folding for Storage

The CaddyLite 11.5 V3 features a quad-fold system for compact storage. Follow the specific folding sequence outlined in the quick-start guide or on the cart itself. Ensure all accessories are removed before folding. The cart will collapse into a compact size for easy transport and storage.

Image: Comparison of the CaddyLite 11.5 V3 in its full, unfolded state versus its compact, folded dimensions, illustrating its space-saving design.

6. Maintenance

- **Cleaning:** Wipe down the cart with a damp cloth after each use to remove dirt and debris. Avoid harsh chemicals.
- **Wheel Care:** Periodically check the wheels for debris and ensure they spin freely. The EVA wheels are maintenance-free.
- **Storage:** Store the cart in a dry, cool place, away from direct sunlight and extreme temperatures.
- **Fasteners:** Occasionally check all screws and fasteners to ensure they are tight. Do not overtighten.

7. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Cart does not fold/unfold smoothly.	Locking mechanisms engaged; debris in joints.	Ensure all locks are disengaged. Clear any obstructions from joints.
Wheels wobble or are loose.	Wheels not fully engaged; axle nut loose.	Press quick-release button and re-seat wheels until they click. Check axle nuts with provided tools.
Brake not holding.	Brake mechanism misaligned or worn.	Inspect the brake pedal and mechanism for obstructions or damage. Contact support if issue persists.

8. Specifications

Feature	Detail
Model	CaddyLite 11.5 V3
Part Number	CP-115-3BLK
Material	Aluminum
Item Weight	13.8 Pounds (6.25 kg)
Unfolded Dimensions (LxWxH)	53.5 x 27 x 45 inches (approximate, handle adjustable)
Folded Dimensions (LxWxH)	28" L x 16.5" W x 16.1" H (71.1cm L x 41.9cm W x 40.9cm H)
Wheel Type	EVA (Maintenance-free)
Wheel Size (Rear)	11.5 inches
Wheel Size (Front)	10.5 inches
Brake System	Foot-activated
Included Accessories	Umbrella holder, drink holder, mesh net, magnetic pad

Image: Technical drawing of the CaddyLite 11.5 V3, displaying key dimensions for both its operational and folded configurations.

9. Warranty and Support

9.1 Limited Warranty

The Caddytek CaddyLite 11.5 V3 Golf Push Cart is backed by a**1-Year Limited Warranty**. This warranty covers manufacturing defects and workmanship under normal use. Please retain your proof of purchase for warranty claims.

9.2 Customer Support

For technical assistance, warranty claims, or replacement parts, please contact Caddytek customer support. Refer to the official Caddytek website for the most current contact information.
You can visit the Caddytek Store for more information:Caddytek Official Store

© 2025 Caddytek. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question