

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Logitech](#) /

› [Logitech Multimedia 2.1 Speakers Z213 User Manual](#)

Logitech Z213

Logitech Multimedia 2.1 Speakers Z213 User Manual

INTRODUCTION

The Logitech Multimedia 2.1 Speakers Z213 system provides clear audio with enhanced bass for your PC, smartphone, or tablet. This compact speaker system includes two satellite speakers, a down-firing subwoofer, and a wired control pod for convenient access to volume and power. Designed for ease of use, the Z213 delivers a rich audio experience for music, movies, and games.



Figure 1: Logitech Multimedia 2.1 Speakers Z213 system, showing the two satellite speakers, the subwoofer, and the wired control pod.

Key Features:

- **Down-firing Subwoofer:** Features an adjustable bass control knob for deeper, richer low-end audio.
- **14W Peak Power (7W RMS):** Delivers loud, clear stereo sound for all audio entertainment.
- **Convenient Control Pod:** Allows easy power on/off, volume adjustment, and includes a headphone jack for private listening.
- **Compact Satellite Speakers:** Inclined design directs sound effectively without occupying excessive desk

space.

- **Plug-and-Play Setup:** Simple wired connection to audio devices with a 3.5mm output.

SETUP INSTRUCTIONS

Follow these steps to correctly set up your Logitech Z213 speaker system.



Figure 2: Unpacked components of the Z213 speaker system.

1. **Position the Subwoofer:** Place the subwoofer on the floor or a stable surface near your computer or audio source. Ensure the down-firing port is not obstructed.
2. **Position the Satellite Speakers:** Place the two satellite speakers on either side of your monitor or listening area. The inclined design helps direct sound towards you.
3. **Connect Satellite Speakers to Subwoofer:** Plug the cables from the satellite speakers into the corresponding ports on the back of the subwoofer.
4. **Connect Control Pod to Subwoofer:** Plug the wired control pod's cable into the designated port on the back of the subwoofer.
5. **Connect to Audio Source:** Plug the 3.5mm audio cable from the control pod into the headphone jack or audio output port of your PC, smartphone, or tablet.
6. **Connect to Power:** Plug the subwoofer's power cable into a wall outlet.



Figure 3: The wired control pod for power, volume, and headphone connection.

OPERATING INSTRUCTIONS

Learn how to use your Logitech Z213 speakers for optimal audio performance.

Power On/Off:

Locate the **ON/OFF** switch on the wired control pod. Slide the switch to the 'ON' position to power on the speakers. A green LED indicator on the control pod will illuminate. Slide to 'OFF' to power down.

Adjusting Volume:

Use the large slider control on the wired control pod to adjust the overall volume of the speaker system. Slide up to increase volume and down to decrease it.

Adjusting Bass:

The bass level can be adjusted using the dedicated control knob located on the back of the subwoofer. Turn the knob clockwise to increase bass and counter-clockwise to decrease it. Adjust to your preferred level for music, movies, or games.



Figure 4: Rear of the subwoofer with the bass control knob.

Using the Headphone Jack:

For private listening, plug your headphones into the 3.5mm headphone jack located on the side of the wired control pod. The speaker audio will automatically mute when headphones are connected.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your speakers.

- **Cleaning:** Use a soft, dry cloth to wipe down the speaker surfaces. Avoid using liquid cleaners or abrasive materials, as these can damage the finish or internal components.
- **Ventilation:** Ensure the subwoofer's port and the back panel are not obstructed to allow for proper airflow and prevent overheating.
- **Cable Management:** Keep cables tidy and untangled to prevent damage and ensure a stable connection.
- **Storage:** If storing the speakers for an extended period, disconnect them from power and store them in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your Z213 speakers, refer to the following common solutions.

No Sound:

- Ensure the speakers are powered on (green LED on control pod).
- Check all cable connections, especially the 3.5mm audio cable to your device and the power cable.
- Verify the volume on the control pod is turned up.

- Confirm your audio source (PC, smartphone) is playing audio and its volume is not muted or too low.
- If headphones are plugged into the control pod, unplug them to enable speaker output.

Distorted or Unclear Sound:

- Reduce the volume on both the control pod and your audio source. High volume levels can cause distortion.
- Check for loose connections.
- Ensure the speakers are not placed too close to other electronic devices that might cause interference.

No Bass or Weak Bass:

- Adjust the bass control knob on the back of the subwoofer.
- Ensure the subwoofer is properly connected to the satellite speakers and power.
- Check the subwoofer's placement; obstructions or placement in a corner can affect bass output.

SPECIFICATIONS

Feature	Detail
Model Name	Z213 Speaker
Item Model Number	980-000941
Speaker Type	Multimedia, Subwoofer, Satellite
Surround Sound Channel Configuration	2.1
Power Output (RMS)	7W
Peak Power	14W
Frequency Response	65 Hz
Subwoofer Diameter	4 Inches
Impedance	4 Ohms
Connectivity Technology	Wired (3.5mm audio input)
Compatible Devices	Smartphone, Tablet, MP3 Player, Desktop, Laptop
Control Method	Wired Control Pod (Volume, Power, Headphone Jack)
Product Dimensions (LxWxH)	9"D x 10.8"W x 5.3"H
Item Weight	3.9 Pounds
Power Source	AC

WARRANTY INFORMATION

Logitech products are manufactured to high quality standards and are designed to provide years of enjoyment. This product is covered by a limited hardware warranty. For detailed information regarding the warranty period and terms specific to your region, please refer to the warranty documentation included with your product or visit the official Logitech support website.

CUSTOMER SUPPORT

Should you require further assistance or have questions not covered in this manual, please contact Logitech Customer Support. You can find contact information, FAQs, and additional resources on the official Logitech website:

Logitech Support Website: <https://support.logi.com>

Please have your product model number (Z213 or 980-000941) and purchase information ready when contacting support.