

[Manuals.plus](#) /

› [Frederique Constant](#) /

› Frederique Constant Geneve Classics Moonphase FC-335MC4P6B2 Automatic Mens Watch User Manual

Frederique Constant FC-335MC4P6B2

Frederique Constant Geneve Classics Moonphase Automatic Watch User Manual

MODEL: FC-335MC4P6B2

INTRODUCTION

Welcome to the user manual for your Frederique Constant Geneve Classics Moonphase Automatic Watch, Model FC-335MC4P6B2. This manual provides essential information on the setup, operation, maintenance, and care of your timepiece to ensure its longevity and accurate performance. Please read this guide thoroughly before using your watch.

PRODUCT OVERVIEW

The Frederique Constant Geneve Classics Moonphase FC-335MC4P6B2 is an elegant automatic men's watch featuring a polished stainless steel case and strap, a sapphire crystal, and an open balance spring display. It combines classic design with sophisticated mechanical functionality, including hours, minutes, seconds, and a moon phase complication.



Figure 1: Front view of the Frederique Constant Geneve Classics Moonphase Automatic Watch. This image displays the watch's white dial with Roman numerals, the open heart balance wheel at 12 o'clock, and the moon phase indicator at 6 o'clock. The watch features a polished stainless steel case and bracelet.

Key Features:

- **Case Material:** Polished Stainless Steel
- **Case Shape:** Round
- **Case Colour:** Silver
- **Bezel Material:** Polished Stainless Steel
- **Crystal:** Sapphire crystal for superior scratch resistance

- **Display Type:** Automatic movement with Hours, Minutes, Seconds
- **Special Feature:** Open Balance Spring display on the dial
- **Clasp Type:** Push Button Deployment Clasp

SETUP

Unboxing and Initial Inspection:

Upon receiving your watch, carefully remove it from its packaging. Inspect the watch for any visible damage. Your watch comes in a protective box designed to keep it secure during transit.



Box supplied may be different from picture

Figure 2: Example of the Frederique Constant watch presentation box. The box is typically dark green with the brand logo, designed to protect and present the timepiece. Note that the actual box supplied may vary slightly in appearance.

Winding the Watch:

As an automatic watch, your timepiece is powered by the motion of your wrist. However, for initial setup or if the watch has stopped, it requires manual winding. Unscrew the crown (if applicable) and turn it clockwise approximately 20-30 times until the second hand begins to move smoothly. This provides a power reserve to start the movement.

Setting the Time and Date:

1. Pull the crown out to the first or second position (refer to specific movement instructions if provided with the watch for exact positions).
2. Turn the crown to set the time. Ensure you pass 12 o'clock to determine if it's AM or PM when setting the date.
3. Push the crown back in to the normal operating position.
4. For the moon phase, use the designated pusher or crown position to advance the moon phase disc until it aligns with the current moon cycle.

Note: Avoid setting the date or moon phase between 9 PM and 3 AM, as this can damage the movement's gears.

OPERATING YOUR WATCH

Automatic Movement:

Your Frederique Constant watch is equipped with an automatic mechanical movement. This means it is powered by the natural motion of your wrist. When worn daily for approximately 8-10 hours, the watch will remain wound. If the watch is not worn for an extended period, it may stop and will need to be manually wound again as described in the "Setup" section.

Moon Phase Function:

The moon phase complication displays the current phase of the moon. This indicator typically completes one full cycle every 29.5 days, reflecting the lunar cycle. Adjustments are usually made via a dedicated pusher or a specific crown position, allowing you to align the moon phase with the actual lunar cycle.

MAINTENANCE

Cleaning:

To maintain the appearance of your watch, regularly wipe the case and sapphire crystal with a soft, lint-free cloth. For the stainless steel bracelet, a soft brush and mild soapy water can be used, ensuring no water enters the watch case. Always dry thoroughly.

Water Resistance:

While your watch is designed for daily wear, it is important to understand its water resistance rating. Avoid exposing the watch to water unless its specific water resistance rating permits it. Always ensure the crown is fully pushed in or screwed down before any contact with water. Water damage is typically not covered under warranty.

Service Intervals:

Mechanical watches, including automatic movements, benefit from periodic servicing to ensure optimal performance and longevity. It is recommended to have your Frederique Constant watch serviced by an authorized service center every 3-5 years. This service typically includes cleaning, lubrication, and adjustment of the movement.

Storage:

When not wearing your watch, store it in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields. The original presentation box is ideal for storage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch has stopped or is running slow.	Insufficient power reserve.	Manually wind the watch by turning the crown clockwise 20-30 times. Wear the watch regularly.
Time is inaccurate.	Exposure to magnetic fields; need for service.	Keep watch away from strong magnets. If problem persists, seek professional service.
Condensation under crystal.	Moisture ingress.	Immediately take the watch to an authorized service center to prevent further damage.

For issues not listed above or if troubleshooting steps do not resolve the problem, please contact an authorized Frederique Constant service center.

SPECIFICATIONS

Feature	Detail
Case Material	Stainless Steel (polished)
Case Shape	Round
Diameter (without crown)	40 mm / 1.57 inches
Strap Material	Stainless Steel (polished)
Crystal	Sapphire crystal
Display Type	Automatic: Hours, Minutes, Seconds
Special Feature	Open Balance Spring
Product Dimensions	5.91 x 5.91 x 5.91 inches; 4.94 ounces
Item Model Number	FC-335MC4P6B2
Clasp Type	Push Button Deployment Clasp
Manufacturer	Frederique Constant Geneve

WARRANTY AND SUPPORT

Frederique Constant watches are manufactured to the highest standards and come with a manufacturer's warranty covering defects in materials and workmanship. Please refer to the warranty card included with your watch for specific terms and conditions, including the warranty period and coverage details.

For warranty claims, service, or technical support, please contact an authorized Frederique Constant service center or visit the official Frederique Constant website for contact information and service locations. Always ensure that any service or repair is performed by an authorized professional to maintain the validity of your warranty.

Manufacturer: Frederique Constant Geneve

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question