Ontel 1000243

Ontel Turbo Jet Power Washer High Pressure Spray Nozzle Instruction Manual

Model: 1000243

1. Introduction

The Ontel Turbo Jet Power Washer is designed to enhance the cleaning capability of a standard garden hose. This attachment converts the normal water flow into a powerful jet stream, suitable for various outdoor cleaning tasks. It is constructed from durable aluminum and stainless steel, featuring quality brass fittings for reliable performance. This manual provides essential information for the proper setup, operation, and maintenance of your Turbo Jet Power Washer.

2. Product Overview

The Turbo Jet Power Washer is a versatile tool for outdoor cleaning. It includes two interchangeable nozzles and an integrated on/off valve for controlled operation.

Key Features:

- Converts standard garden hose water flow into a high-pressure jet stream.
- Durable construction with aluminum, stainless steel, and brass components.
- Includes one Jet-Stream Nozzle for concentrated cleaning and one Fan-Spray Nozzle for broader coverage.
- Features an adjustable on/off valve for water flow control.

Components:

- **Turbo Jet Wand:** The main body of the power washer attachment.
- **Jet-Stream Nozzle:** Provides a focused, high-pressure stream for tough dirt.
- **Fan-Spray Nozzle:** Delivers a wider spray pattern for larger surfaces.
- **On/Off Valve:** Integrated control for water flow.




Into A Power Washer!
• Makes Tough Cleaning Jobs A Breeze!
• Easily Attaches To Any Garden Hose
• Blasts Away Dirt, Grime, Weeds & More!
Jet-Stream
Includes 2 Nozzles!
Fan-Spray
Great For:
Patios & Decks
Windows & Eaves
Siding & Awnings
Cars & Trucks
Steps & More!
Heavy Duty Construction
✓ Durable Aluminum
✓ Stainless Steel
✓ Solid Brass

Figure 2.1: The complete Ontel Turbo Jet Power Washer High Pressure Spray Nozzle.



Figure 2.2: Illustration of the included Jet-Stream and Fan-Spray nozzles, demonstrating their distinct spray patterns.




Figure 2.3: Diagram illustrating the internal mechanism and function of the easy on/off valve for water flow control.

3. Setup Instructions

Follow these steps to properly set up your Turbo Jet Power Washer:

1. **Inspect Components:** Ensure all parts, including the wand, both nozzles, and any rubber washers/gaskets, are present and undamaged.
2. **Attach Nozzle:** Select either the Jet-Stream or Fan-Spray nozzle and securely screw it onto the end of the Turbo Jet wand. Hand-tighten only.
3. **Connect to Garden Hose:** Attach the threaded end of the Turbo Jet wand to a standard garden hose. Ensure the connection is tight to prevent leaks. Verify that a rubber washer is properly seated within the hose connection point.
4. **Turn on Water:** Slowly turn on the water supply to your garden hose. Check for any leaks at the connections.



Figure 3.1: Demonstrates the process of attaching the Turbo Jet Power Washer to a standard garden hose for immediate use.

4. Operating Instructions

The Turbo Jet Power Washer is designed for various outdoor cleaning tasks. Always ensure a stable footing and maintain a safe distance from the cleaning surface.

1. **Activate Water Flow:** Use the integrated on/off valve on the wand to control the water flow. Push the lever to the 'ON' position to start the water stream.
2. **Select Nozzle:**
    - **Jet-Stream Nozzle:** Ideal for concentrated cleaning of stubborn dirt, grime, and debris on hard surfaces like concrete, brick, and metal.
    - **Fan-Spray Nozzle:** Suitable for broader cleaning tasks on larger areas such as decks, patios, siding, and vehicles, providing a wider, less intense spray.
3. **Adjust Pressure:** The valve allows for some adjustment of water pressure and stream force. Experiment with the valve position to achieve the desired cleaning intensity for different surfaces.
4. **Cleaning Applications:**
    - **Patios and Driveways:** Use the Jet-Stream nozzle for targeted cleaning of cracks and stubborn stains, or the Fan-Spray for general surface cleaning.

- **Siding and Windows:** The extended reach of the wand is useful for cleaning higher areas. Use the Fan-Spray nozzle for general washing of siding and windows.
- **Vehicles:** The Fan-Spray nozzle can be used for rinsing cars and trucks.

5. **Deactivate Water Flow:** When finished, push the lever on the on/off valve to the 'OFF' position and turn off the main water supply to the garden hose.



Figure 4.1: The Turbo Jet Power Washer effectively cleaning dirt and debris from stone steps.



Figure 4.2: Demonstrates using the Turbo Jet Power Washer to reach and clean second-story windows.



Figure 4.3: Illustrates the cleaning power of the Turbo Jet on dirty exterior siding, showing a clear before-and-after effect.



Figure 4.4: The Turbo Jet Power Washer being used to clean and restore the appearance of pavers.

5. Maintenance

Regular maintenance ensures the longevity and optimal performance of your Turbo Jet Power Washer.

- **Cleaning:** After each use, rinse the wand and nozzles with clean water to remove any dirt or debris.
- **Storage:** Store the Turbo Jet Power Washer in a dry, cool place, away from direct sunlight and freezing temperatures. Disconnect it from the garden hose before storage.
- **Inspect Connections:** Periodically check all connections for wear or damage, especially the rubber washer/gasket at the hose attachment point. Replace if necessary to prevent leaks.
- **Nozzle Care:** If a nozzle becomes clogged, remove it from the wand and clear any obstructions using a small pin or by flushing with water from the opposite direction.

6. Troubleshooting

If you encounter issues with your Turbo Jet Power Washer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Low water pressure from nozzle	Low household water pressure; Clogged nozzle; Partially closed valve.	Ensure main water supply is fully open. Check and clear any clogs in the nozzle. Ensure the on/off valve on the wand is fully open.
Water leaking from connections	Loose connection; Missing or damaged rubber washer/gasket.	Tighten all connections securely. Inspect the rubber washer/gasket at the hose connection point and replace if worn or missing.
No water flow	Water supply off; Valve closed; Severe clog.	Ensure water supply is on. Open the on/off valve. Check for severe clogs in the wand or nozzle.

7. Specifications

- **Model Number:** 1000243
- **Brand:** Ontel
- **Material:** Aluminum, Stainless Steel
- **Dimensions (L x W x H):** 32.75 x 4.75 x 1.38 inches (approximately)
- **Item Weight:** 11.2 ounces
- **Inlet Connection Size:** 0.5 Inches
- **Inlet Connection Type:** Barb
- **Outlet Connection Type:** Barb
- **Number of Ports:** 2
- **UPC:** 735541707155

8. Warranty and Support

Specific warranty details and direct support contact information for the Ontel Turbo Jet Power Washer are not provided in the available product data. Please refer to the retailer or your purchase documentation for warranty terms and customer service options.

9. Official Product Videos

No official seller-provided product videos were available for embedding in this manual.