



[Manuals.plus](#) /

- › [STATIONERY ISLAND](#) /
- › STATIONERY ISLAND Chalk Pens Instruction Manual

STATIONERY ISLAND D30

STATIONERY ISLAND Chalk Pens Instruction Manual

Model: D30 | Brand: STATIONERY ISLAND

1. PRODUCT OVERVIEW

The STATIONERY ISLAND Chalk Pens are versatile liquid chalk markers designed for drawing and writing on various non-porous surfaces. This pack includes 8 vibrant colors, offering a smooth writing experience with a 3mm fine bullet nib, suitable for intricate details and general use.

These pens are water-based, non-toxic, and easily erasable from compatible surfaces, making them ideal for creative projects, educational settings, and business displays.



Figure 1.1: A set of 8 STATIONERY ISLAND Chalk Pens, showcasing the range of available colors.

2. GETTING STARTED: QUICK START GUIDE

Before first use, or if the ink flow is inconsistent, follow these steps to activate your chalk pens:

1. **Shake:** With the cap on, shake the pen vigorously for approximately 30 seconds to mix the ink thoroughly.
2. **Press:** Press the nib down repeatedly on a scrap piece of paper until the ink begins to flow and the nib is fully saturated. This may take several seconds.
3. **Test:** Before drawing on your intended surface, test the pen on a small, inconspicuous area to ensure proper ink flow and compatibility with the surface.
4. **Recap:** After each use, recap the pen tightly to prevent the nib from drying out.



Figure 2.1: Visual guide for activating the chalk pens for optimal performance.

3. OPERATING INSTRUCTIONS

3.1 Compatible Surfaces

STATIONERY ISLAND Chalk Pens are designed for use on **non-porous surfaces**. On these surfaces, the ink is easily erasable and washable. Always perform a small test on an inconspicuous area of your surface first to confirm compatibility and ease of removal.

- **Glass:** Windows, mirrors, glass bottles.
- **Metal:** Certain metal signs or surfaces.
- **Ceramic:** Glazed ceramic mugs, tiles.
- **Plastic:** Smooth plastic surfaces.
- **Whiteboards:** Standard dry-erase whiteboards.
- **Non-Porous Blackboards/Chalkboards:** Specifically designed liquid chalkboards.



Works on Various Surfaces

Figure 3.1: Examples of various non-porous surfaces suitable for chalk pen application.

ERASABLE FROM:



GLASS



METAL



CERAMIC



PLASTIC



WHITEBOARDS



NON-POROUS
BLACKBOARDS

PERMANENT ON:



PAINTED
SURFACES



WOOD



PAPER



CARDBOARD



SLATE
BLACKBOARD

Figure 3.2: Detailed compatibility guide for erasable and permanent surfaces.

3.2 Surfaces Where Ink May Be Permanent

The ink from these chalk pens may become permanent or difficult to remove on **porous surfaces**. Avoid using the pens on the following materials unless permanence is desired:

- Painted Surfaces
- Wood
- Paper
- Cardboard
- Slate Blackboards (traditional porous chalkboards)

3.3 Nib Type and Application

Each pen features a 3mm fine bullet nib, allowing for precise lines and detailed artwork. This tip is versatile for both writing and drawing.

3mm Fine Tip



Figure 3.3: Detail of the 3mm fine bullet nib for precise application.

4. MAINTENANCE AND CLEANING

To ensure the longevity of your chalk pens and maintain clean surfaces:

- **Recap Tightly:** Always replace the cap firmly after each use to prevent the nib from drying out and to preserve ink quality.
- **Storage:** Store pens horizontally or nib-down to keep the ink flowing to the tip.
- **Cleaning Surfaces:** For non-porous surfaces, the chalk ink can typically be wiped away with a damp cloth. For stubborn marks, a mild glass cleaner or whiteboard cleaner may be used. Ensure the surface is completely dry before reapplying ink.
- **Dust-Free:** Unlike traditional chalk, these liquid chalk markers produce no dust, making cleanup easier and reducing mess.



Figure 4.1: The chalk pens are erasable, washable, and dust-free for easy maintenance.

5. TROUBLESHOOTING

If you encounter issues with your chalk pens, consider the following common solutions:

- **Ink Not Flowing:** If the ink is not flowing smoothly, ensure the pen has been shaken well and the nib has been pressed down repeatedly on a scrap surface to prime it. The nib needs to be fully saturated with ink.
- **Ink Appears Faint:** This usually indicates insufficient priming. Re-shake the pen and press the nib down until the color is vibrant.
- **Ink Difficult to Remove:** Verify that the surface you are using is non-porous. If it is a porous surface (e.g., traditional chalkboard, wood, paper), the ink may be permanent. For non-porous surfaces, try a damp cloth, or a mild cleaner if necessary.
- **Nib Damage:** Avoid excessive force when pressing the nib, as this can damage it. If the nib is frayed, it may affect ink flow and line quality.

6. SPECIFICATIONS

Feature	Detail
Brand	STATIONERY ISLAND
Model Number	D30 (SI17-AP-CP-8D3MX0)
Item Weight	3.39 ounces
Product Dimensions	3.66 x 5.16 x 0.59 inches
Color	Mixed Color - Pack of 8
Material Type	Plastic
Number of Items	8
Point Type	Fine
Line Size	3.00 mm
Ink Color	Multicolor
Tip Type	Bullet, Metal
Recommended Uses	Drawing, Glass, Whiteboards, Non-porous Blackboards

7. SAFETY INFORMATION AND WARNINGS

Please observe the following safety guidelines:

- **Age Restriction:** Not suitable for children under 14 years due to small parts.
- **Small Parts:** Contains small parts which may pose a choking hazard. Keep out of reach of young children.
- **Non-Toxic:** The ink is water-based and non-toxic, but direct ingestion should be avoided.
- **Ventilation:** Use in a well-ventilated area.
- **Surface Testing:** Always test on a small, inconspicuous area of the surface first to ensure suitability and ease of removal.




Figure 7.1: Warning label on product packaging regarding age suitability and small parts.

8. WARRANTY AND SUPPORT

STATIONERY ISLAND is committed to providing high-quality products. For any questions, concerns, or support regarding your chalk pens, please refer to the contact information provided on the product packaging or visit the official STATIONERY ISLAND website. Specific warranty details, if applicable, will be outlined in the product packaging or on the manufacturer's website. For more information, you can visit the [STATIONERY ISLAND Store on Amazon](#).

9. OFFICIAL PRODUCT VIDEOS

No official product videos from the seller were found that meet the criteria for inclusion in this manual.