

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Casio](#) /

› [Casio MTP-1384L-7AV Men's Rose Tone Leather Band Day Date Watch User Manual](#)

Casio MTP-1384L-7AVDF

Casio MTP-1384L-7AV Men's Watch Instruction Manual

1. PRODUCT OVERVIEW

The Casio MTP-1384L-7AV is a men's analog watch featuring a quartz movement, a rose gold ion-plated bezel, and a genuine leather band. It includes a day and date display, Roman numerals on a silver dial, and offers 100-meter water resistance. This manual provides instructions for its proper use and care.





Image 1.1: Front view of the Casio MTP-1384L-7AV watch, displaying the silver dial with Roman numerals, day and date windows, and rose gold-tone case with a brown leather band.

Key Features:

- Quartz movement for accurate timekeeping.
- Rose gold ion-plated bezel and stainless steel case.
- Genuine leather band for comfort and durability.
- Day and date display windows.
- Mineral Glass for scratch resistance.
- Screw Lock Back for enhanced water resistance.
- 100-meter (10 BAR) water resistance.

2. SETUP AND INITIAL SETTINGS

Before using your watch, set the current time and date.



Image 2.1: Side view of the watch, highlighting the crown used for setting time and date.

Setting the Time:

1. Pull the crown out to the second click position. The second hand will stop.
2. Rotate the crown to advance the hour and minute hands to the correct time. Ensure the AM/PM setting is correct if the watch has a 24-hour indicator (though this model primarily uses a 12-hour display, the day/date change around midnight indicates PM).
3. Push the crown back in to the normal position. The second hand will resume movement.

Setting the Day and Date:

1. Pull the crown out to the first click position.
2. Rotate the crown to set the desired day and date. Rotate in one direction to change the date and the other to change the day.
3. Once the correct day and date are displayed, push the crown back in to the normal position.

Note: Avoid setting the date between 9:00 PM and 1:00 AM, as this may interfere with the automatic date change

mechanism. If you need to set the date during this period, first change the time to outside this range, set the date, and then reset the time.

3. OPERATING THE WATCH

Your Casio MTP-1384L-7AV watch is designed for straightforward operation.

Timekeeping:

- The watch continuously displays the current hour, minute, and second.
- The day and date windows automatically advance at midnight.

Water Resistance:

- The watch is water resistant to 100 meters (10 BAR). This means it is suitable for everyday use, swimming, and snorkeling.
- **Do not operate the crown while the watch is wet or submerged.**
- Avoid exposing the watch to hot water or steam, as this can compromise the water resistance seals.

4. MAINTENANCE AND CARE

Proper maintenance ensures the longevity and performance of your watch.



Image 4.1: Back view of the watch, showing the stainless steel screw lock back and model engravings.

Cleaning:

- Wipe the watch case and band with a soft, dry cloth regularly to remove dirt and moisture.
- For the leather band, avoid prolonged exposure to direct sunlight, extreme heat, or moisture, as this can cause discoloration or damage.

Battery Replacement:

- The watch is powered by one product-specific battery.
- When the battery runs low, the watch may stop or the second hand may move erratically.
- Battery replacement should be performed by a qualified watch technician to ensure proper sealing and maintain water resistance.

Storage:

- Store the watch in a cool, dry place away from direct sunlight and strong magnetic fields.

5. TROUBLESHOOTING

If you encounter issues with your watch, refer to the following common problems and solutions.

Watch Not Running:

- **Check the crown:** Ensure the crown is pushed fully into the normal position.
- **Battery:** The battery may be depleted. Consult a watch technician for replacement.

Incorrect Time or Date:

- **Reset time/date:** Follow the instructions in Section 2 to reset the time and date.
- **Daylight Saving Time:** Adjust the time manually when daylight saving time begins or ends.

Condensation Inside Watch:

- If condensation appears inside the watch glass and does not clear within a short time, it may indicate a compromised water resistance seal. Seek immediate service from a qualified technician.

6. SPECIFICATIONS

Detailed technical specifications for the Casio MTP-1384L-7AV watch.



Image 6.1: The watch displayed next to a credit card, illustrating its approximate dimensions relative to a standard card.

Feature	Detail
Model Number	MTP-1384L-7AVDF
Movement	Quartz
Water Resistance	100 meters (10 BAR)
Case/Bezel Material	Stainless Steel (Rose Gold Ion-Plated Bezel)
Band Material	Genuine Leather
Glass	Mineral Glass
Battery Type	1 Product Specific Battery

Dimensions (approx.)	1.1 x 1.1 x 2.83 inches (Case); 7.05 ounces (Weight)
Functions	Analog Timekeeping (Hour, Minute, Second), Day Display, Date Display

7. WARRANTY AND SUPPORT

For detailed warranty information, please refer to the warranty card included with your purchase or visit the official Casio website. Casio provides support for its products through authorized service centers.

If you require assistance or have questions not covered in this manual, please contact Casio customer support or an authorized Casio service provider.

