

ION ISP43

ION Audio Party On (ISP43) Bluetooth Speaker

User Manual

Model: ISP43 | Brand: ION Audio

INTRODUCTION

The ION Audio Party On (ISP43) is a compact, palm-sized Bluetooth speaker designed for portable audio and a dynamic light display. This manual provides essential information for the safe and efficient use of your device, covering setup, operation, maintenance, and troubleshooting.

PACKAGE CONTENTS

- ION Audio Party On (ISP43) Speaker
- 1/8-inch (3.5mm) Auxiliary Cable
- USB Charging Cable
- Quickstart Guide (this document)



Image: The included 3.5mm auxiliary cable and USB charging cable for the ION Audio Party On speaker.

FEATURES

- Projects brilliant lights onto walls and ceilings.
- Full-range speaker with passive radiator subwoofer for enhanced sound.
- Streams music wirelessly from any Bluetooth-enabled device.
- Long-lasting rechargeable battery, charged via USB.
- 1/8-inch (3.5mm) auxiliary input for non-Bluetooth audio sources.

SETUP

Charging the Battery

Before first use, fully charge the Party On speaker. Use the included micro-USB cable to connect the speaker to a computer's USB port or a USB power adapter (sold separately). The **CHARGE** indicator light will illuminate during charging. A full charge typically takes approximately 3 hours.



Image: Rear panel of the ION Audio Party On speaker, highlighting the power switch, Bluetooth disconnect button, AUX input, and micro-USB charging port with its indicator.

Powering On/Off

Locate the **OFF/DEMO/ON** switch on the rear panel of the speaker. Slide the switch to the **ON** position to power on the device. To power off, slide the switch to the **OFF** position.

The **DEMO** mode is designed for retail display and will automatically turn off after 5 minutes of inactivity. For regular use, select the **ON** position.

OPERATING INSTRUCTIONS

Bluetooth Connection

1. Ensure the Party On speaker is powered on and within 30 feet of your Bluetooth device.
2. On your Bluetooth device (smartphone, tablet, computer), navigate to its Bluetooth settings.
3. Select "Party On" from the list of available devices to pair.
4. Once paired, the Bluetooth indicator on the speaker will confirm the connection. You can now stream audio wirelessly.

To disconnect a paired device, press the **DISCONNECT** button located on the rear panel of the speaker. This allows another device to connect.

Auxiliary Input

For devices without Bluetooth, connect them using the included 1/8-inch (3.5mm) auxiliary cable. Plug one end into the **AUX** input on the rear of the Party On speaker and the other end into your audio device's headphone jack or auxiliary output.

Controls



Image: Front panel controls of the ION Audio Party On speaker, including Power, Volume adjustment, and Next track buttons.

- **POWER Button:** This button on the front panel can be used for soft power control or to activate/deactivate certain functions. The main power switch is located on the rear.
- **VOLUME Buttons (Up/Down Arrows):** Press to adjust the speaker's audio output volume.
- **NEXT Button (Right Arrow):** Press to skip to the next track when playing music via Bluetooth.
- *Note: Play/Pause functionality is typically controlled directly from your connected Bluetooth device or may be integrated with one of the existing buttons (e.g., a short press of the Power button).*

Light Show Function

The Party On speaker features an integrated light dome that projects colorful, pulsating lights. The light show automatically synchronizes with the music played through the speaker, whether via Bluetooth or the auxiliary input. The lights project onto walls and ceilings, creating a dynamic visual effect.




Image: The ION Audio Party On speaker illuminating a room with its integrated party lights.



Image: The ION Audio Party On speaker projecting red and blue light patterns onto a textured wall surface.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the speaker. Do not use abrasive cleaners or solvents.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Recharge the speaker regularly, even if not in use for extended periods. Store in a cool, dry place.
- **Storage:** When storing the speaker, ensure it is powered off.

TROUBLESHOOTING

Problem	Solution
Speaker does not power on.	Ensure the OFF/DEMO/ON switch is in the ON position. Check if the battery is charged; connect to a power source using the USB cable.
Cannot connect via Bluetooth.	• Ensure the speaker is within 30 feet of your device. • Press the DISCONNECT button on the speaker to clear previous connections. • Turn off and on your device's Bluetooth, then try pairing again. • Ensure your device is Bluetooth-enabled and compatible.

Problem	Solution
No sound from speaker.	• Increase the volume on both the speaker and your connected device. • If using Bluetooth, ensure the device is properly paired. • If using AUX, ensure the cable is securely connected to both devices.
Lights are not working or not syncing.	Ensure music is playing through the speaker. The lights are designed to respond to audio input.
Speaker automatically turns off.	Check if the power switch is set to DEMO mode. For continuous operation, set it to ON . Low battery can also cause automatic shutdown; recharge the unit.

SPECIFICATIONS

- **Model:** ISP43
- **Power:** 3.7V / 500mAh battery (rechargeable via micro-USB)
- **Battery Life:** Up to 3 hours (actual battery life may vary based on usage)
- **Recharge Time:** Approximately 3 hours
- **Dimensions (L x W x H):** 2.75" x 2.85" x 3.1" (70mm x 72mm x 79mm)
- **Weight:** 0.75 lbs (12 oz / 0.34 kg)
- **Connectivity:** Bluetooth, 1/8-inch (3.5mm) AUX input
- **Speaker Type:** Full-range with passive radiator subwoofer
- **Speaker Maximum Output Power:** 25 Watts
- **Impedance:** 4 Ohms
- **UPC:** 812715016128



Image: Diagram showing the dimensions of the ION Audio Party On speaker.

Safety Information

Please read and understand all safety instructions before using this product. Keep these instructions for future reference.

- Do not expose the unit to water or moisture.
- Do not block any ventilation openings.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel.

WARRANTY AND SUPPORT

For the most up-to-date warranty information and customer support, please visit the official ION Audio website or contact their customer service department. Keep your purchase receipt as proof of purchase.

Online Support: www.ionaudio.com/support

© 2024 ION Audio. All rights reserved. ION is a registered trademark of inMusic Brands, Inc.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question