## Hampton Bay DC032LED

# Hampton Bay 32 in. Brushed Nickel LED Oval Flush Mount Instruction Manual

Model: DC032LED

## Introduction

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Hampton Bay 32 inch Brushed Nickel LED Oval Flush Mount light fixture. Please read this manual thoroughly before beginning installation and retain it for future reference.

The Hampton Bay LED Oval Flush Mount is designed for indoor use, offering energy-efficient illumination with a contemporary aesthetic. It features a long-life LED light source and a dimmable function for adjustable light levels.



Image 1: Hampton Bay 32 inch Brushed Nickel LED Oval Flush Mount. This image displays the full oval fixture with its brushed nickel frame and white diffuser.

## Safety Information

**WARNING: RISK OF ELECTRIC SHOCK. Disconnect power at the circuit breaker or fuse box before installation or**

**servicing. Improper installation can result in electric shock or fire.**

- Always consult a qualified electrician if you are unsure about the installation process.
- Ensure all electrical connections comply with local codes and ordinances, as well as the National Electric Code (NEC).
- Do not install this fixture in wet or damp locations. It is designed for indoor use only.
- Handle the fixture with care to avoid damage to the LED components.
- Do not attempt to modify the fixture or its components.

## Package Contents

Verify that all components are present and undamaged before proceeding with installation. If any parts are missing or damaged, contact Hampton Bay customer service.

- LED Oval Flush Mount Fixture (1)
- Mounting Hardware (screws, wire nuts, mounting bracket)
- Diffuser (pre-installed or separate)
- Instruction Manual (this document)

## Specifications

| Feature | Detail |
|---|---|
| Brand | Hampton Bay |
| Model Number | DC032LED |
| Dimensions (L x W x H) | 32.44" x 18.11" x 4.76" |
| Weight | 8.54 lbs |
| Finish | Brushed Nickel |
| Light Source | Integrated LED |
| Wattage | 43 Watts (equivalent to 125 watts incandescent) |
| Brightness | 3000 Lumens |
| Color Temperature | 4000K (Bright White) |
| Voltage | 120-Volt or 277-Volt operation |
| Dimmable | Yes, with 0-10 Volt dimmer |
| Lifespan | Up to 50,000 hours |
| Certification | ENERGY STAR qualified, ETL listed |



Image 2: Close-up view of the brushed nickel finish and diffuser edge of the Hampton Bay LED Oval Flush Mount.

## Setup and Installation

Before you begin, ensure the power is turned off at the circuit breaker. Gather all necessary tools, including a screwdriver, wire strippers, and electrical tape.

### Tools Required:

- Phillips Head Screwdriver
- Flathead Screwdriver
- Wire Strippers
- Electrical Tape
- Safety Glasses

### Installation Steps:

1. **Turn Off Power:** Locate the circuit breaker controlling the light fixture's power supply and switch it to the OFF position. Verify power is off using a voltage tester.
2. **Remove Existing Fixture:** Carefully remove your old light fixture, noting the wiring connections.
3. **Install Mounting Bracket:** Attach the provided mounting bracket to the junction box in the ceiling using the screws supplied. Ensure the bracket is securely fastened.
4. **Make Electrical Connections:**
    - Connect the **black** wire from the fixture to the**black** (hot) wire from the ceiling using a wire nut.

- Connect the **white** wire from the fixture to the **white** (neutral) wire from the ceiling using a wire nut.
- Connect the **ground** wire (bare copper or green) from the fixture to the **ground** wire from the ceiling (or to the green ground screw on the mounting bracket) using a wire nut.
- Ensure all wire nuts are tightly secured and wrapped with electrical tape for added safety.

5. **Mount the Fixture:** Carefully align the fixture with the mounting bracket and secure it in place using the provided screws. Ensure no wires are pinched during this step.
6. **Install Diffuser:** If the diffuser is not pre-installed, carefully attach it to the fixture according to the specific design.
7. **Restore Power:** Once the fixture is securely installed and all connections are made, turn the power back ON at the circuit breaker.



Image 3: The Hampton Bay LED Oval Flush Mount fixture installed on a ceiling, demonstrating its low-profile appearance.

## Operating Instructions

The Hampton Bay LED Oval Flush Mount is designed for simple operation.

- **Turning On/Off:** Use your standard wall switch to turn the light fixture on or off.
- **Dimming Function:** This fixture is dimmable with a compatible 0-10 Volt dimmer switch. If you have installed a dimmer, adjust the dimmer control to achieve your desired light level. Ensure your dimmer switch is rated for LED lighting.

## Maintenance

The LED Oval Flush Mount requires minimal maintenance due to its long-life LED components.

- **Cleaning:** To clean the fixture, ensure the power is off. Use a soft, dry, or slightly damp cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish or electrical components.
- **LED Replacement:** The integrated LED light source is designed for a long lifespan (up to 50,000 hours) and is not user-replaceable. If the LED fails, the entire fixture may need to be replaced.

## Troubleshooting

If you encounter issues with your Hampton Bay LED Oval Flush Mount, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| Light does not turn on. | ◦ Power is off at the circuit breaker.<br>◦ Loose or incorrect wiring connections.<br>◦ Faulty wall switch. | ◦ Check the circuit breaker and ensure it is ON.<br>◦ Verify all wire connections are secure (ensure power is off before checking).<br>◦ Test the wall switch with another device or replace it if faulty. |
| Light flickers or dims improperly. | ◦ Incompatible dimmer switch.<br>◦ Loose wiring connection. | ◦ Ensure a 0-10 Volt LED compatible dimmer is used.<br>◦ Check wiring connections (with power off). |
| Light output is lower than expected. | ◦ Dimmer setting is too low.<br>◦ Dust or debris on the diffuser. | ◦ Adjust the dimmer to maximum brightness.<br>◦ Clean the diffuser as per maintenance instructions. |

## Warranty and Support

For warranty information or technical assistance, please contact Hampton Bay customer service. Refer to your purchase receipt or the product packaging for specific warranty details and contact information.
**Manufacturer:** Hampoton Bay
**Model:** DC032LED

© 2025 Hampton Bay. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**