

[Manuals.plus](#) /

› [Ameriwood Home](#) /

› Ameriwood Home Parsons Desk Instruction Manual

Ameriwood Home 9178896PCOM

Ameriwood Home Parsons Desk Instruction Manual

Model: 9178896PCOM

1. INTRODUCTION

Thank you for choosing the Ameriwood Home Parsons Desk. This modern and versatile desk is designed to provide optimal functionality and style for your home office, bedroom, dorm room, or homeschooling space. Crafted from durable engineered wood with a laminated finish, it offers a spacious work surface and a convenient storage drawer. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure a smooth and enjoyable experience with your new desk.



Image: The Ameriwood Home Parsons Desk in White/Teal, showcasing its minimalist design and integrated drawer.

2. PRODUCT FEATURES

- **Optimal Functionality:** The preassembled desktop allows for quick setup. Its compact size makes it suitable as a computer desk with drawers for small spaces. The small center storage drawer holds all your school supplies.
- **Spacious and Versatile:** Despite its compact size, this home office desk table offers ample space for your laptop and paperwork. Its versatile design works well as a study desk with drawers or as a desk for bedrooms and living rooms.
- **Universal Style and Durability:** The Ameriwood Home Parsons Desk showcases a universal style, making it great as a work desk for the home office. Crafted from engineered wood, it ensures long-lasting durability and modern appeal.



Image: The Parsons Desk integrated into a home office setup, demonstrating its spacious surface for a laptop and other accessories.

3. SETUP GUIDE

3.1. Unpacking and Component Checklist

Carefully unpack all components from the packaging. Ensure all parts are present and undamaged before proceeding with assembly. If any parts are missing or damaged, please contact customer support.

Component	Quantity
Preassembled Desktop (with drawer)	1
Legs	4
Hardware (screws, wood glue, Allen wrench)	1 set

3.2. Assembly Instructions

Assembly of the Parsons Desk is minimal and straightforward. It is recommended that two people assist with assembly for ease and safety.

1. Place the preassembled desktop upside down on a soft, clean surface (e.g., a blanket or carpet) to prevent scratches.
2. Locate the four legs and the included hardware.

3. Align each leg with the designated corner attachment points on the underside of the desktop.
4. Insert the provided screws and tighten them using the included Allen wrench. Ensure all connections are secure.
5. Apply the included wood glue into the designated holes for added stability, if applicable, as per the detailed instructions in your physical manual.
6. Carefully turn the assembled desk upright and place it in its desired location. Avoid dragging the desk to prevent damage.

4. OPERATING INSTRUCTIONS

The Ameriwood Home Parsons Desk is designed for ease of use. Its primary function is to provide a stable and spacious work surface.

- **Work Surface:** The desktop offers ample space for laptops, monitors, books, and other work essentials. The smooth laminated surface is suitable for mouse operation without a pad.
- **Storage Drawer:** The single center drawer is ideal for organizing small office supplies, stationery, or personal items. To open, gently pull the drawer front. To close, push it back until it is flush with the desk frame. The drawer has a maximum weight capacity of 6 pounds.



Image: A close-up of the desk's single drawer, demonstrating its capacity for small items like pens and notebooks.

5. MAINTENANCE AND CARE

- To maintain the appearance and longevity of your Ameriwood Home Parsons Desk, follow these simple care instructions:
- **Cleaning:** Dust and wipe the desk surfaces with a dry, soft cloth regularly. If needed, a damp cloth may be used sparingly. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the laminated finish.
 - **Spills:** Wipe up spills immediately with a dry cloth to prevent staining or damage to the surface.
 - **Heat and Moisture:** Avoid placing hot items directly on the desk surface. Use coasters or protective pads under hot beverages or dishes. Protect the desk from prolonged exposure to direct sunlight or extreme humidity.
 - **Weight Distribution:** Distribute weight evenly across the desktop. Do not exceed the maximum weight capacity of 150 pounds for the top surface or 6 pounds for the drawer.

6. TROUBLESHOOTING

- If you encounter any issues with your Parsons Desk, refer to the following common troubleshooting tips:
- **Desk Wobbles:** Ensure all leg screws are securely tightened. If the wobbling persists, check that the desk is placed on a level surface. Adjustments may be needed for uneven floors.
 - **Drawer Sticks or Does Not Slide Smoothly:** Check for any obstructions inside the drawer or along its glides. Ensure the drawer is properly aligned on its metal glides. Lightly lubricate the glides with a silicone-based spray if necessary.
 - **Surface Scratches:** While the laminated finish is durable, deep scratches can occur. For minor scuffs, a furniture polish or touch-up pen matching the desk's color may help. For significant damage, contact customer support for advice.

7. SPECIFICATIONS

Attribute	Detail
Brand	Ameriwood Home
Model Number	9178896PCOM
Model Name	Parsons Computer Desk with Drawer
Product Dimensions (D x W x H)	19.7"D x 39"W x 30"H
Color	White/Teal

Attribute	Detail
Style	Transitional
Base Material	Engineered Wood
Finish Type	Laminated
Special Feature	Compact
Maximum Weight Recommendation (Top)	150 Pounds
Drawer Weight Limit	6 Pounds
Number of Drawers	1
Required Assembly	Yes (attaching four legs)
Recommended Number of People for Assembly	2





Image: A visual representation of the Parsons Desk in different available colors, highlighting its versatile design.

8. WARRANTY INFORMATION

The Ameriwood Home Parsons Desk is backed by a 1-year limited warranty. This warranty covers manufacturing defects and ensures the product meets quality standards. Please retain your proof of purchase for any warranty claims.

9. SUPPORT AND CONTACT

For further assistance, questions, or to report any issues with your Ameriwood Home Parsons Desk, please refer to the contact information provided in your product packaging or visit the official Ameriwood Home website for support resources.

© 2024 Ameriwood Home. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B00L27KPJ6>

More documents and user manuals: <https://manuals.plus/>