Bajaj Majesty

Bajaj Majesty 10-Litre 2000-Watt GPU Water Heater User Manual

1. Introduction

Thank you for choosing the Bajaj Majesty 10-Litre 2000-Watt GPU Water Heater. This manual provides essential information for the safe installation, operation, and maintenance of your new appliance. Please read these instructions carefully before use and retain them for future reference.



Image 1.1: Bajaj Majesty 10-Litre 2000-Watt GPU Water Heater. This image displays the front view of the water heater, showcasing its multicolour engineered plastic body and compact design.

2. Safety Instructions

Your safety and the safety of others are paramount. Please observe all safety precautions outlined below:

- **Electrical Safety:** Ensure the water heater is connected to a properly grounded electrical outlet. The appliance features a fire retardant cable with a 3-pin plug for enhanced safety.
- **Overheating Protection:** The unit is equipped with multiple safety systems to protect against overheating. Do not bypass or tamper with these safety features.

- **Dry Heating Protection:** Integrated safety mechanisms prevent dry heating, which can damage the heating element.
- **Over Pressure Protection:** The water heater includes protection against excessive pressure buildup within the tank.
- **Water Connection:** Ensure all water connections are secure and leak-free before operating the appliance.
- **Children and Vulnerable Persons:** This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. Package Contents

Upon unpacking, please verify that all components are present and undamaged:

- Bajaj Majesty 10-Litre 2000-Watt GPU Water Heater Unit
- Installation Kit (typically includes mounting brackets, fasteners, and inlet/outlet pipes)
- User Manual and Warranty Card

If any items are missing or damaged, please contact customer service immediately.

4. Setup and Installation

Proper installation is crucial for the safe and efficient operation of your water heater. It is highly recommended to have the installation performed by a qualified technician.

- **Professional Installation:** Bajaj offers free installation for storage water heaters of 6 liters and above. To schedule installation after delivery, please contact Bajaj customer service at **18001025963**.
- **Mounting:** The water heater is designed for wall mounting. Ensure the wall can support the weight of the unit when full of water.
- **Water Pressure:** This model is suitable for high pressure and pressure pump installations, with a rated pressure of 0.70 MPA.
- **Location:** Install the water heater in a location protected from freezing temperatures and direct sunlight. Ensure adequate ventilation around the unit.
- **Electrical Connection:** Connect the appliance to a dedicated 230 Volts, 2000 Watts power supply.

5. Operating Instructions

Operating your Bajaj Majesty water heater is straightforward:

- **Power On:** After ensuring proper installation and water supply, switch on the main power supply to the water heater.
- **Temperature Setting:** Use the external adjustable thermostat to set your desired water temperature. Rotate the knob to increase or decrease the temperature.
- **Temperature Indicator:** The unique temperature indicator dial provides a visual reference of the current water temperature inside the tank.
- **Heating Cycle:** The heating element will activate to heat the water to the set temperature and then automatically switch off. It will reactivate as needed to maintain the temperature.

6. Maintenance

Regular maintenance ensures the longevity and efficient performance of your water heater:

- **Corrosion Protection:** The water heater features a special protection device that attracts harmful salts, safeguarding the Incoloy heating element and the glass-lined coated inner tank from corrosion. This significantly extends the life of the appliance.
- **Cleaning:** Periodically wipe the exterior of the water heater with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Annual Inspection:** It is recommended to have a qualified technician inspect the water heater annually to check for sediment buildup, anode rod condition, and overall operational integrity.
- **Drainage:** If the water heater is not going to be used for an extended period, or if there is a risk of freezing, it is advisable to drain the tank. Refer to a qualified technician for this procedure.

7. Troubleshooting

If you encounter issues with your water heater, refer to the following basic troubleshooting steps:

- **No Hot Water:** Check if the power supply is on. Ensure the thermostat is set to a desired temperature. Verify that the water supply valve is open.
- **Insufficient Hot Water:** The set temperature might be too low, or the demand for hot water exceeds the unit's capacity. Allow more time for heating.
- **Water Leaks:** Turn off the power and water supply immediately. Contact customer service or a qualified technician.
- **Unusual Noises:** Minor noises during heating are normal. If loud or persistent noises occur, contact customer service.

For any complex issues or if troubleshooting steps do not resolve the problem, please contact Bajaj customer service.

8. Technical Specifications

Feature	Detail
Brand	Bajaj
Model Number	Majesty (150713)
Type	Storage Water Heater
Capacity	10 Litres
Wattage	2000 Watts
Voltage	230 Volts
Rated Pressure	0.70 MPA (0.7 Kilopascal)
Heating Element	High efficiency and long life Incoloy heating element
Inner Tank Material	Glasslined coated
Body Material	High impact resistant engineered plastic

Feature	Detail
Special Features	Rust Proof, Energy Efficient, Multiple Safety Systems, External Adjustable Thermostat, Unique Temperature Indicator Dial
Mount Type	Wall
Item Weight	7716 Grams

9. Warranty and Customer Support

Bajaj provides comprehensive support for your product:

- **Product Warranty:** 2 years on the product.
- **Tank Warranty:** 5 years on the inner tank.
- **Customer Service:** For any product or service queries, including installation scheduling, please contact Bajaj customer service at **18001025963**.

Please retain your purchase receipt for warranty claims.

Bajaj Electricals Ltd. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question