

[Manuals.plus](#) /

› [QUNDA](#) /

› KT-E03 Universal Remote for All Major Brands of Mini Split AC User Manual

QUNDA E03

QUNDA KT-E03 Universal Remote Control User Manual

Model: E03

INTRODUCTION

The QUNDA KT-E03 is a universal remote control designed for mini split air conditioning units. It features a wide compatibility range with 4000 codes, an LCD display, and various fan speed options. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance of your remote control.



Figure 1: Front view of the KT-E03 remote control, showing the LCD display and 'One Key' button.

PRODUCT FEATURES

- **LCD Display:** Provides clear visual feedback for settings and modes.
- **Fan Speed Options:** Includes Auto, High, Medium, and Low settings for customized airflow.
- **Auto Digital Search Mode:** Features a comprehensive database of 4000 codes for broad compatibility with various mini split

AC brands.

- **16 Buttons:** The remote includes 16 buttons, with 15 conveniently hidden under a slide-down cover for a clean design and protection against accidental presses.
- **One-Button Operation:** A dedicated 'One Key' button allows for quick activation of the cooling mode at 80°F, simplifying operation for all users.
- **Universal Compatibility:** Designed to work with most major brands of mini split AC units.



Figure 2: The KT-E03 remote with its slide-down cover open, revealing additional function buttons.

1. Battery Installation

The KT-E03 remote requires two AAA batteries (not included). To install:

1. Slide open the battery compartment cover located on the back of the remote.
2. Insert two AAA batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
3. Close the battery compartment cover securely.



Figure 3: Battery compartment of the KT-E03 remote, showing where to insert AAA batteries.

2. Code Setup (Pairing with your AC Unit)

The KT-E03 offers two methods for finding the correct code for your AC unit: Manual Code Entry and Automatic Search.

Method A: Manual Code Entry (Recommended if your brand code is known)

Refer to the included code list (often found on the packaging or a separate sheet, or as shown in Figure 4) to find the code(s) corresponding to your AC brand.

1. Turn on your mini split AC unit manually.
2. Press and hold the 'SET' button on the remote until the code on the LCD display starts flashing.
3. Use the 'TEMP+' or 'TEMP-' buttons to input the 3-digit code for your AC brand.
4. Point the remote at your AC unit and press the 'ENTER' button. The AC unit should beep, indicating successful pairing.
5. Test basic functions (Power, Mode, Temp) to confirm the code works correctly. If not, try the next code for your brand or proceed to Method B.

Method B: Automatic Search (For unknown codes or brands not listed)

This method cycles through all 4000 codes until a compatible one is found.

1. Ensure your mini split AC unit is turned on.
2. Point the remote at your AC unit.
3. Press and hold the 'SET' button for approximately 6 seconds. The code on the LCD display will start flashing and automatically increment.
4. The remote will begin transmitting codes. When your AC unit responds (e.g., turns off, beeps, or changes mode), immediately release the 'SET' button.
5. Test basic functions (Power, Mode, Temp) to confirm the code works correctly. If the AC unit does not respond or stops responding, repeat the process.



Universal A/C Remote Control 4000 IN 1

Model Code Table
(To arrange in alphabetical order according to the brand and mask)

Brand	Model Code	Brand	Model Code	Brand	Model Code
AIRWELL	0555, 0556	HISENSE	0332-0335, 0517, 1868, 2895	Sabro	0435, 0506-0508, 0947, 3578
ALPIN	0252-0253, 1278, 1780	HITACHI	0118-0126, 1656, 2173	SAVO DENKI	0212-0215, 0724, 2262
AUCMA	0288-0289, 0462, 1826, 3534	HUABAO	0336-0344, 2384, 2903	SAMPO	0424-0426, 1448, 2985
AUX	0297-0300, 0451, 1834, 3011	HUAIKE	0408, 0620, 1501, 3480	SAMSUNG	0188-0196, 0516, 0518, 1212
BANSHEN	0284, 1288, 2824	HUAMEI	0402, 0460-0465, 2962, 3986	SANYO	0046-0095, 0529, 0530, 1070
BOERKA	0383, 0434, 0436, 0437, 3508	HUALING	0317-0325, 0452, 2365, 3524	SASUKI	0254, 0470, 1494, 2814
CARRIER	0203-0209, 0456-0458, 0482-0486, 0563-0565	HUIFENG	0370, 2418, 3442	SHANGLING	0384-0388, 0444-0445, 3407
CHANGHONG	0301-0305, 2348, 3880	HUIKANG	0368, 0441-0443, 1978, 3440	SHARP	0096-0106, 0525, 1122
CHIGO	0379-0382, 0515, 1912, 2940	HYUNDAI	0202, 0433, 0480, 0551, 3552	SHENGFENG	0376, 0480, 0888, 1911
CHOFU	0184-0197, 1208, 2233	JIDC	0373, 0440, 2488, 3957	SHINCO	0351-0354, 0454-0456, 3935
CHUNLAN	0345-0350, 0450, 0453, 3522	JINSONG	0389-0391, 0446-0448, 3463	SHUANGLU	0378, 0404-0407, 0480, 1400
CORONA	0155-0163, 0459, 2204, 3531	JOHNSON	0245, 0492, 2028, 3829	SHUAKANG	0288, 0600
CONROWA	0377, 0889, 1315, 2937	KANGLI	0374-0375, 1911, 2442	SONGGE	0428-0429, 2986, 3501
CONSUL	0463, 1999, 3535	KELON	0282-0287, 0473, 0485-0488	SOVA	0409-0410, 1433, 2457
COUNTRY AIR	0560	KLIMATAIR	0225, 0226, 0452, 3297	SUMMER	0427, 1963
DAEWOO	0203-0209, 0406, 1430, 3792	KOLIN	0416-0418, 2466, 3488	SUNDURG	0257, 0505, 1529, 2305
DAIKIN	0171-0183, 0566, 0567, 0583	KONKA	0397, 0457-0459, 3017	SWAN	0434, 0516, 0524, 2994
DOCTOR	0221, 0449, 1473, 3805	LG	0197-0200, 0514, 0572, 2248	TADIRAN	0246-0251, 0759, 1787
DONGBAC	0355-0361, 1897, 2918	LIANGYU	0233, 0451, 1987, 3817	TATUNG	0419-0420, 2980, 3491
DONGHABO	0413, 1505, 3485	LITTLE DUCK	0019-0020, 0630, 1039	TCL	0273-0281, 0570, 0786
Electrolux	0216-0220, 0569, 1244	LOREN-SEB	0255, 0471, 0472, 2007, 3327	TECO	0256, 0473-0475, 1497, 3840
ELECTRA	0557	MACQUAY	0234-0237, 0465, 1489, 2794	TIANDI	0415, 1439, 3999
EMAILAIR	0558	MICOM	0415, 1439, 2465, 3487	TOSHIBA	0107-0117, 0489, 0561, 0562, 1001
FEDDERS	0528	MIDEA	0260-0265, 0526, 1801, 2820	TRANE	0227-0232, 0739, 1101, 1788
FRESTECH	0277, 0519, 0520, 2325	MITSUBISHI	0001-0045, 0476-0479, 0552, 0553, 0568, 0582	UNI-AIR	0222-0224, 0450, 1985
FUJITSU	0127-0137, 0464, 0552-0554	NORITZ	0431, 0943, 2991	WANBAO	0138-0154, 0483, 0652, 0995
FUNAI	0430, 0481, 3041, 3502	OMEGA	0559	WEILI	0383-0386, 1420, 1932
GALANZ	0371, 0372, 0521, 1906, 2931	National	0138-0154, 0483, 2714, 3722	Whirlpool	0164-0170, 0502, 1526, 3748
GENERAL	0127-0137, 0464, 2000, 3712	PANASONIC	0378, 1914, 3962	WINIA	0481, 0993
GLEE	0398, 0399, 2446, 2959	PANDA	0210-0211, 0487, 0488, 1254	XILENG	0411, 0412, 0924, 1947
GOLDSTAR	0201, 0466-0469, 1737, 3539	PHILCO	0421-0423, 0934, 2981	XINLE	0400, 0401, 0913, 2960
GREE	0309-0316, 0482, 0512, 0513	PHOTON	0362-0367, 2410, 3435	YANGYAIR	0403, 1427, 2451
HAIER	0266-0272, 0453-0455	RAYBO	0369, 0438-0439, 0527, 0531	YINYAN	0258-0259, 0326-0331, 0838
		ROWA		YORK	0238-0243, 0751, 1778
				ZHEN BAO	0127-0137, 0464, 2000, 3711



Universal A/C Remote Control 4000 IN 1

One key Nonstop

Input codes directly by digit keys

Excellent function (Clock, Sleep, C&F etc)

Thermometer function

Memory function



One Key Universal A/C Remote Control

Coding Invention Patent No.: ZL 2008 1 0023186.7 One key nonstop patent

Blind friends also can use

Figure 4: Example of a code table and feature overview for the universal remote.

OPERATING INSTRUCTIONS

Once the remote is successfully paired with your AC unit, you can use its various functions.

Basic Functions (Visible Buttons)

- **POWER:** Turns the AC unit on or off.

- **MODE:** Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **TEMP+ / TEMP-:** Adjusts the temperature setting up or down.
- **FAN:** Adjusts fan speed (Auto, Low, Medium, High).
- **ONE KEY:** Activates cooling mode at a preset temperature (typically 80°F).

Advanced Functions (Under Slide-Down Cover)

Slide down the front cover to access additional buttons.

- **SWING:** Controls the vertical louver movement.
- **VANE:** Controls the horizontal louver movement (if applicable to your AC unit).
- **SLEEP:** Activates sleep mode for quiet operation and energy saving.
- **TIME ON / TIME OFF:** Sets a timer for the AC unit to turn on or off automatically.
- **CLOCK:** Sets the current time on the remote's display.
- **C/F:** Toggles between Celsius and Fahrenheit temperature display.
- **SET:** Used for code setup and advanced settings.
- **ENTER:** Confirms selections during setup or setting changes.



Figure 5: Side view of the KT-E03 remote, illustrating the slide-down cover mechanism.

MAINTENANCE

Battery Replacement

Replace batteries when the remote's display becomes dim or the remote becomes unresponsive. Always replace both batteries at the same time with new AAA alkaline batteries. Do not mix old and new batteries or different types of batteries.

Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

TROUBLESHOOTING

- **Remote not responding to AC unit:**
 - Ensure the remote is pointed directly at the AC unit's receiver.
 - Check battery levels and replace if necessary.
 - Re-perform the code setup process (Method A or B) as the code may have been lost or was incorrect.
- **Some functions not working:**
 - Not all functions on the universal remote may be supported by every AC unit model. This is common with universal remotes.
 - Ensure the correct code is selected. Try another code for your brand if available.

- **Remote display is blank or dim:**
 - Replace the batteries.
- **Compatibility Note:** This remote is primarily designed for mini split AC units and is not likely to work with window or portable AC units.

SPECIFICATIONS

Feature	Detail
Model Number	E03
Product Dimensions	6 x 2 x 1 inches
Item Weight	3.2 ounces
Batteries Required	2 AAA batteries
Battery Type	Alkaline
Connectivity Technology	Infrared
Max Number of Supported Devices	1 (AC Unit)
Special Feature	Universal

WARRANTY AND SUPPORT

Warranty information for the QUNDA KT-E03 Universal Remote Control is typically provided by the manufacturer or the retailer at the time of purchase. Please refer to your purchase documentation or contact the seller directly for details regarding warranty coverage and support options.

© 2024 QUNDA. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question