

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [Schecter](#) /

> [Schecter C-6 Deluxe Solid-Body Electric Guitar, Satin Black Instruction Manual](#)

## Schecter 430

# Schecter C-6 Deluxe Solid-Body Electric Guitar Instruction Manual

Model: 430 | Brand: Schecter

## INTRODUCTION

This manual provides essential information for the setup, operation, maintenance, and troubleshooting of your Schecter C-6 Deluxe Solid-Body Electric Guitar. Please read this manual thoroughly to ensure proper use and to maximize the lifespan of your instrument.



*Image: Full view of the Schecter C-6 Deluxe Solid-Body Electric Guitar in Satin Black finish.*

## SETUP

Before playing your new Schecter C-6 Deluxe guitar, follow these steps for initial setup:

1. **Unpacking:** Carefully remove the guitar from its packaging. Inspect for any visible damage.
2. **Tuning:** Tune the guitar to standard pitch (E-A-D-G-B-e) using an electronic tuner. New strings may require frequent re-tuning initially.
3. **Strap Attachment:** Attach a guitar strap to the strap buttons located on the body of the guitar for comfortable playing while standing.
4. **Amplifier Connection:** Connect a standard 1/4-inch instrument cable from the guitar's output jack to your amplifier's input.



*Image: Front view of the Schecter C-6 Deluxe Electric Guitar, highlighting the body and neck.*

## OPERATING THE GUITAR

Your Schecter C-6 Deluxe features intuitive controls for shaping your sound:

- **Volume Knob:** Controls the overall output level of the guitar. Turn clockwise to increase volume, counter-clockwise to decrease.
- **Tone Knob:** Adjusts the treble response. Turn clockwise for brighter tones, counter-clockwise for

warmer, darker tones.

- **Pickup Selector Switch:** This switch allows you to select different pickup configurations.
  - **Position 1 (Bridge):** Activates the bridge pickup for a sharp, bright tone, often used for lead guitar or aggressive rhythms.
  - **Position 2 (Middle):** Activates both bridge and neck pickups, offering a balanced tone.
  - **Position 3 (Neck):** Activates the neck pickup for a warm, mellow tone, ideal for clean passages or blues.



*Image: Close-up of the guitar's body, showing the Schecter Diamond Plus humbucker pickups, volume and tone knobs, and the pickup selector switch.*

## MAINTENANCE

Regular maintenance will preserve your guitar's playability and appearance:

- **Cleaning:** Wipe down the body, neck, and strings with a soft, lint-free cloth after each use to remove sweat and oils. Use guitar-specific cleaning products for deeper cleaning.

- **String Replacement:** Replace strings regularly (e.g., every 1-3 months, depending on usage) to maintain optimal tone and playability. Change one string at a time to maintain neck tension.
- **Fretboard Care:** Periodically clean and condition the rosewood fretboard to prevent drying and cracking. Use a lemon oil or specialized fretboard conditioner.
- **Storage:** Store the guitar in a stable environment, away from extreme temperature changes and humidity fluctuations. A guitar case or gig bag is recommended for protection.



*Image: Close-up of the guitar's headstock, featuring the Schecter logo and tuning machines.*

## TROUBLESHOOTING

---

Here are solutions to common issues you might encounter:

- **No Sound:**
  - Check all cable connections (guitar to amp, amp to power).
  - Ensure the amplifier is turned on and volume is up.
  - Verify the guitar's volume knob is not turned down.

- Test with a different cable or amplifier if possible.

- **Buzzing Strings:**

- Check for proper fretting technique.
- Inspect for worn frets or incorrect string action. Professional setup may be required.
- Ensure strings are correctly seated in the nut and bridge.

- **Poor Tuning Stability:**

- Stretch new strings thoroughly after installation.
- Check tuning machines for looseness.
- Ensure the nut slots are not binding the strings.

## SPECIFICATIONS

Feature	Detail
Item Weight	10.33 pounds
Product Dimensions	44 x 19 x 5 inches
ASIN	B00LE533EU
Item Model Number	430
Back Material	Basswood
Body Material	Wood (Basswood)
Color Name	Black
Fretboard Material	Rosewood
Guitar Pickup Configuration	H (Humbucker)
Scale Length	25.5 inches
String Material	Alloy Steel
Top Material	Basswood, Maple Wood, Rosewood
Neck Material Type	Maple
Number of Strings	6
Guitar Bridge System	Tune-O-Matic
Hand Orientation	Right

## PRODUCT DEMONSTRATION

Watch this video for a demonstration and sound test of the Schecter C-6 Deluxe Electric Guitar:

Your browser does not support the video tag.

*Video: Electric Guitar Video Review | Demo, Unboxing + Sound Test for the Schecter C-6 Deluxe Electric Guitar.*

## WARRANTY AND SUPPORT

---

Information regarding specific warranty details and customer support for the Schecter C-6 Deluxe Solid-Body Electric Guitar was not available in the provided product data. Please refer to the manufacturer's official website or contact your retailer for warranty registration, support, and service inquiries.

---

© 2023 Schecter. All rights reserved.