

[manuals.plus](#) /

› [Haan](#) /

› [HAAN Portable Travel Steamer Iron HI-400BL User Manual](#)

Haan HI-400BL

HAAN Portable Travel Steamer Iron HI-400BL User Manual

Model: HI-400BL | Brand: Haan

1. INTRODUCTION

Thank you for choosing the HAAN Portable Travel Steamer Iron HI-400BL. This handheld garment steamer is designed for efficient wrinkle removal, offering portability and ease of use for both home and travel. With its quick heat-up time and lightweight design, it provides a convenient solution for keeping your garments fresh and wrinkle-free.



Image 1.1: The HAAN Portable Travel Steamer Iron HI-400BL, a compact and efficient handheld garment steamer.

2. IMPORTANT SAFETY INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USE. FAILURE TO FOLLOW THESE INSTRUCTIONS MAY RESULT IN ELECTRIC SHOCK, FIRE, OR SERIOUS INJURY.

- **Electrical Compatibility:** This appliance is designed for 220V, 60Hz power outlets. It is usable in 200V~250V regions. If your local voltage is lower than 200V, a suitable transformer MUST be used. Failure to do so can damage the unit and pose a safety risk.
- **Plug Type:** The appliance uses a Type C plug. Ensure your outlet is compatible or use an appropriate adapter.
- **Water Safety:** Do not immerse the steamer in water or other liquids. Do not operate if the power cord or plug is damaged.

- **Hot Steam:** Steam is hot. Always direct steam away from yourself, other people, and pets. Use caution when handling the steamer during and immediately after operation.
- **Unplug When Not in Use:** Always unplug the steamer from the electrical outlet when filling with water, emptying, cleaning, or when not in use.
- **Children and Pets:** Keep the appliance out of reach of children and pets.
- **Proper Use:** Use the steamer only for its intended purpose as described in this manual.

3. PRODUCT COMPONENTS

The HAAN Portable Travel Steamer Iron HI-400BL comes with the following components:

- Main Body (Steamer Unit)
- Cushion Clip
- Dust Removal Brush
- Heat Plate Clip
- Wrinkle Clip
- Measuring Cup
- Travel Pouch



Image 3.1: Overview of the HAAN Steamer's main body and included accessories, such as the cushion clip, brush for

removing dust, hot plate clip, unwrinkle clip, measuring cup, and travel pouch.



Image 3.2: Detailed view of the HAAN Steamer highlighting key features such as the large water tank (approx. 7 minutes continuous use), steam button for constant injection, 600g ultra-light design, and quick 20-second standby time. Also shows the included multi-function clips and travel pouch.

4. SETUP

- Fill the Water Tank:** Ensure the steamer is unplugged. Remove the water tank from the handle. Use the provided measuring cup to fill the tank with clean tap water. The capacity is 400 milliliters. Do not overfill.
- Attach Water Tank:** Securely reattach the filled water tank to the steamer handle until it clicks into place.
- Attach Desired Accessory:** Depending on your garment and steaming needs, attach the appropriate clip (cushion clip, dust removal brush, heat plate clip, or wrinkle clip) to the steamer head.
- Plug In:** Plug the power cord into a compatible 220V electrical outlet.
- Heat Up:** The steamer will begin to heat up. The initial operating time (heat time) is approximately 20 seconds. A signal light will indicate when the steamer is ready for use.

5. OPERATING INSTRUCTIONS

1. **Hold the Steamer:** Hold the steamer upright, ensuring the water tank is below the steam head.
2. **Activate Steam:** Once the steamer is ready (signal light on), press and hold the steam button to release a continuous flow of steam. The steamer can provide continuous steam for about 7 minutes on a full tank.
3. **Steam Garments:** Hold the garment taut with one hand and move the steamer head slowly over the fabric with the other. For best results, steam from top to bottom.
4. **Using Accessories:**
 - **Dust Removal Brush:** Use to remove lint, pet hair, and dust while steaming.
 - **Cushion Clip:** Ideal for delicate fabrics or for providing a gentle press.
 - **Heat Plate Clip:** Provides a flat surface for pressing, similar to an iron, for sharper creases.
 - **Wrinkle Clip:** Helps to hold fabric taut for easier wrinkle removal, especially on collars or cuffs.
5. **Refilling:** If steam production decreases or stops, unplug the steamer, allow it to cool slightly, and refill the water tank as described in the Setup section.
6. **Finishing:** When finished steaming, release the steam button and unplug the steamer from the outlet.

When you iron standing

The burden of the wrist

Down 

Comfortable feeling

Up 

파워핸디는 미니멀한 사이즈로
가볍고 편리하게 사용할 수 있는 핸디형 다리미입니다.



500ml 생수 VS **POWER HANDY**

Image 5.1: The HAAN Steamer being used in various household settings, demonstrating its versatility for different fabrics and items, including clothing on a line, furniture, and baby crib bedding.



Image 5.2: The HAAN Steamer's compact size and lightweight design make it easy to carry and store, fitting conveniently into a travel bag or briefcase, highlighting its suitability for travel.

6. MAINTENANCE AND CARE

- **Empty Water Tank:** After each use, unplug the steamer and allow it to cool completely. Empty any remaining water from the tank to prevent mineral buildup.
- **Cleaning:** Wipe the exterior of the steamer with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Descaling (if needed):** If you notice reduced steam output or mineral residue, you may need to descale the unit. Consult the manufacturer's website or customer support for specific descaling instructions.
- **Storage:** Store the steamer in a cool, dry place. Use the provided travel pouch for convenient and protected storage, especially when traveling.

7. TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|--------------------------------|---|---|
| No steam or very little steam. | Water tank is empty or low. Steamer not heated sufficiently. Mineral buildup. | Refill water tank. Wait 20 seconds for heating. Descale the unit (refer to maintenance). |
| Water leaking from steam head. | Overfilled water tank. Steamer not hot enough. Condensation buildup. | Do not overfill. Allow steamer to fully heat before use. Hold steamer upright; allow it to heat fully. |
| Steamer not turning on. | Not plugged in correctly. No power at outlet. Incorrect voltage. | Ensure plug is fully inserted. Check household circuit breaker. Verify outlet voltage is 220V or use a transformer. |

8. SPECIFICATIONS

| Feature | Detail |
|------------------------------------|---|
| Model | HI-400BWT (also known as HI-400BL) |
| Color | Black |
| Power | 220V, 60Hz, 1400W |
| Weight | Approximately 600g (excluding power cord) / 2.44 pounds (Item Weight) |
| Cord Length | 1.6m |
| Use Time (Continuous Steam) | About 7 minutes |
| Initial Operating Time (Heat Time) | About 20 seconds |
| Dimensions | 320 x 160 x 110(H) mm / 13.19 x 8.19 x 4.41 inches (Package Dimensions) |
| Water Tank Capacity | 400 Milliliters |
| Product Benefits | Efficient wrinkle removal, Portable and convenient for travel, Easy to use as a handheld device |
| Plug Type | Type C |




Image 8.1: The HAAN Steamer compared in size to a 500ml water bottle, illustrating its compact and portable design.

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official HAAN website. Keep your proof of purchase for any warranty claims. If you require further assistance or have questions not covered in this manual, please contact HAAN customer service.