

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Amope](#) /
- › [Amope Pedi Perfect Electric Callus Remover Instruction Manual](#)

Amope 10051400931972

Amope Pedi Perfect Electric Callus Remover Instruction Manual

Your guide to safe and effective foot care with the Amope Pedi Perfect device.

1. SETUP

1.1 Unpacking

Carefully remove the Amope Pedi Perfect Electric Callus Remover and all included accessories from its packaging. Ensure all components are present before proceeding.

NEW LOOK!



Figure 1: The Amopé Pedi Perfect Electric Callus Remover comes securely packaged. Carefully remove the device and all accessories from the box.

1.2 Battery Installation

The device requires 4 AA batteries (included). To install, twist the base of the handle counter-clockwise to open the battery compartment. Insert the batteries according to the polarity indicators (+/-). Replace the base by twisting clockwise until it clicks securely into place.

2. OPERATING INSTRUCTIONS

2.1 General Use

The Amopé Pedi Perfect is designed for use on hard skin on the feet only. It can be used on both wet or dry skin, though it is primarily intended for dry settings. Turn on the device by pressing the power button. Gently glide the rotating roller head over areas of hard skin. Apply light to medium pressure. Do not use in the same area for more than 3-4 seconds at a time to prevent discomfort or injury. Stop use immediately if irritation occurs.



Figure 2: The Amope Pedi Perfect Electric Callus Remover being used on a foot to gently buff away hard skin.

2.2 Dual Speed System

The device features a dual-speed system, allowing you to choose the intensity that best suits your exfoliation needs. Press the power button once for the lower speed setting. Press it again for the higher speed setting. Press a third time to turn the device off.

Your browser does not support the video tag.

Video 1: This video demonstrates the operation of the Amope Pedi Perfect, including its dual-speed settings and how it buffs away hard skin.

3. MAINTENANCE

3.1 Cleaning the Roller Head

After each use, remove the roller head by pressing the release button on the side of the device. Rinse the roller head under running water to remove any skin particles. Dry the roller head thoroughly with a clean, dry cloth before reattaching or storing.

3.2 Replacing the Roller Head

When the roller head becomes less effective, it's time for a replacement. To replace, press the release button to remove the old roller head. Align the new roller head with the device and push it in until it clicks into place. Ensure it is securely fastened before use.



💧 Use On Wet or Dry Skin

🛡️ Splash-proof*

🔄 360 Degree Spin

// Dual Speed

*However, intended for use in dry settings

Figure 3: A close-up view of the exfoliating roller head, which can be easily removed for cleaning or replacement.

4. TROUBLESHOOTING

- **Device stops during use:** The Amope Pedi Perfect has an integrated safety stop feature that activates if too much pressure is applied. Reduce pressure and continue use. If the device still stops, check battery levels.
- **Reduced effectiveness:** The roller head may be worn out. Replace it with a new Amope Pedi Perfect roller head. Ensure the roller head is clean and free of debris.
- **Device not turning on:** Check that the batteries are correctly installed and not depleted. Replace with new AA batteries if necessary. Ensure the battery compartment cover is securely closed.

INTEGRATED SAFETY STOP PREVENTS YOU FROM APPLYING TOO MUCH PRESSURE



Figure 4: The device features an integrated safety stop to prevent excessive pressure during use.

5. SPECIFICATIONS

Feature	Detail
Model Number	10051400931972
Power Source	4 AA Batteries (included)
Dimensions	2.36 x 6.46 x 7.95 inches
Weight	11.36 ounces
Material	Plastic
Features	Exfoliating Diamond Crystals, Dual Speed, Splashproof (for wet/dry use, not submersible)

6. SAFETY INFORMATION

Please read and adhere to the following safety precautions:

- Keep out of reach of children.
- For use on hard skin on the feet only.
- Use only on dry (not wet) skin. Do not use the product anywhere else on the body.
- Only use for its intended purpose.
- Do not use in the same area for more than 3-4 seconds at a time.
- Stop use immediately if irritation or discomfort occurs.
- Do not use on broken, sore, or irritated skin.
- Do not submerge the product in water.
- This product is not suitable for diabetics and those with poor blood circulation.
- Keep long hair and clothing away from the product when in use.

7. WARRANTY & SUPPORT

For warranty information or product support, please refer to the manufacturer's official website or contact their customer service. Keep your purchase receipt for any warranty claims.