

## aerolatte 095

# aerolatte French Press Coffee Maker Model 095 Instruction Manual

Model: 095 | Brand: aerolatte

## INTRODUCTION

Thank you for choosing the aerolatte French Press Coffee Maker. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new coffee maker. Please read it thoroughly before first use and keep it for future reference.

This 5-cup (20-ounce) French press is designed for making a better cup of coffee at home with precise control, offering a rich and flavorful brew.

## IMPORTANT SAFETY INFORMATION

- Always handle with care, especially when the glass beaker contains hot liquids.
- Keep out of reach of children.
- Do not use on a stovetop or in a microwave.
- Ensure the plunger lid is securely in place before pressing.
- Use only coarse-ground coffee suitable for French presses to prevent excessive pressure and potential breakage.
- Do not overfill the French press. Observe the water markings on the glass.
- This product is Proposition 65 compliant.

## COMPONENTS

Your aerolatte French Press consists of the following main components:

- **Glass Beaker:** Made from high borosilicate glass, with water markings for precise measurement.
- **Frame with Handle:** Constructed from stainless steel, polypropylene, and ABS, providing support and a comfortable grip.

- **Plunger Assembly:** Includes a stainless steel rod, a fine mesh filter, and a plunger knob.
- **Lid:** Features a built-in microfilter spout to capture grounds and sediment.
- **Coffee Scoop:** Included for measuring coffee.



*Image: The aerolatte French Press Coffee Maker, showing its main parts including the glass beaker, frame, and plunger assembly.*

## SETUP AND FIRST USE

1. **Unpack:** Carefully remove all components from the packaging.
2. **Inspect:** Check for any damage to the glass beaker or other parts.
3. **Wash:** Before first use, wash all parts (glass beaker, plunger assembly, lid, and frame) with warm soapy water. Rinse thoroughly and dry. The glass beaker can be easily lifted out from the frame for cleaning.
4. **Reassemble:** Place the clean glass beaker back into the frame. Ensure the handle is securely attached to the frame.

Your browser does not support the video tag.

*Video: An aerolatte representative demonstrates the assembly and disassembly of the French press, highlighting how the glass beaker can be removed from the frame for cleaning.*

## OPERATING INSTRUCTIONS: BREWING COFFEE

1. **Heat Water:** Heat fresh water to just below boiling (approximately 200°F / 93°C). Do not use boiling water directly, as it can scorch the coffee.
2. **Add Coffee Grounds:** Remove the plunger assembly from the French press. Add coarse-ground coffee to the bottom of the glass beaker. Use the included coffee scoop and the water markings on the beaker to achieve your desired coffee-to-water ratio. A common ratio is 1-2 tablespoons of coffee per 6 ounces of water.
3. **Pour Water:** Slowly pour the hot water over the coffee grounds, ensuring all grounds are saturated.
4. **Stir (Optional):** Gently stir the coffee and water mixture with a non-abrasive spoon to ensure even saturation.
5. **Steep:** Place the plunger assembly back on top of the beaker, but do not press down yet. Allow the coffee to steep for 3-4 minutes. Adjust steeping time to your preferred strength.
6. **Press:** Slowly and steadily press the plunger straight down. Do not press too quickly or with excessive force, as this can cause hot liquid to spray out or damage the filter. The plunger's microfilter will separate the grounds from the brewed coffee.
7. **Serve:** Pour the freshly brewed coffee into your cup immediately. Do not let the coffee sit in the French press with the grounds after brewing, as it can continue to extract and become bitter.



*Image: The aerolatte French Press filled with freshly brewed coffee, ready to be served.*



*Image: Close-up of coffee being poured from the aerolatte French Press into a white cup.*

## MAINTENANCE AND CLEANING

---

Regular cleaning ensures the longevity and optimal performance of your French press.

- **Daily Cleaning:** After each use, discard coffee grounds. Rinse the glass beaker, plunger assembly, and lid with warm water.
- **Thorough Cleaning:** The durable glass beaker easily lifts out from the frame for cleaning. All parts are dishwasher safe for easy cleanup. For best results, disassemble the plunger and filter screens to remove any trapped coffee residue.
- **Drying:** Allow all components to dry completely before reassembling or storing to prevent odors or mildew.



Image: The plunger and fine mesh filter assembly of the aerolatte French Press, designed to capture coffee grounds effectively.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Coffee tastes bitter	Over-extraction (steeped too long) or water too hot.	Reduce steeping time (3-4 minutes recommended). Ensure water is just below boiling.
Coffee tastes weak	Under-extraction (steeped too short) or not enough coffee grounds.	Increase steeping time or use more coffee grounds.
Grinds in coffee cup	Coffee grounds too fine, plunger pressed too quickly, or filter not clean.	Use coarse-ground coffee. Press plunger slowly and steadily. Disassemble and thoroughly clean the filter.
Plunger is hard to press	Coffee grounds too fine, too much coffee, or filter clogged.	Use coarser grounds. Reduce amount of coffee. Clean filter thoroughly.

## SPECIFICATIONS

- **Brand:** aerolatte
- **Model Name:** HIC (Model Number: 095)
- **Capacity:** 20 Ounce (approximately 600 Milliliters / 5 Servings)
- **Product Dimensions:** 5.88"D x 4.5"W x 8.13"H
- **Item Weight:** 13.3 ounces
- **Materials:** Stainless steel, high borosilicate glass, polypropylene, ABS
- **Coffee Maker Type:** French Press
- **Operation Mode:** Manual
- **Dishwasher Safe:** Yes, all parts.



Image: Diagram showing the dimensions of the aerolatte French Press, including height and width.

## WARRANTY AND SUPPORT

For warranty information or product support, please refer to the packaging or contact aerolatte customer service directly. Keep your purchase receipt as proof of purchase.

You can visit the official aerolatte store for more information: [aerolatte Store](#)

