

[Manuals.plus](#) /

› [Electrolux](#) /

› Electrolux 242044113 Defrost Heater Assembly Instruction Manual

Electrolux 242044113

Electrolux 242044113 Defrost Heater Assembly Instruction Manual

Model: 242044113

INTRODUCTION

This manual provides essential information for the installation, operation, and maintenance of the Electrolux 242044113 Defrost Heater Assembly. This genuine replacement part is designed to restore the defrosting function in compatible refrigerators and freezers, primarily those manufactured by Frigidaire and other Electrolux brands. The defrost heater is a critical component that melts frost buildup on the evaporator coils, ensuring efficient cooling and preventing ice accumulation that can impede airflow and appliance performance.



Image 1: The Electrolux 242044113 Defrost Heater Assembly. This image shows the complete heater assembly, typically consisting of a heating element encased in a metal tube with electrical connectors.

SAFETY INFORMATION

Always prioritize safety when working with electrical appliances. Failure to follow these instructions may result in electric shock, injury, or damage to the appliance.

- **Disconnect Power:** Before beginning any repair or installation, always unplug the appliance from the electrical outlet or turn off the circuit breaker to prevent electric shock.
- **Wear Protective Gear:** Wear appropriate personal protective equipment, including work gloves, to protect hands from

sharp edges often found within appliance compartments.

- **Consult a Professional:** If you are unsure about any step of the installation process, consult a qualified appliance repair technician.
- **Handle with Care:** The defrost heater assembly contains delicate components. Handle it carefully to avoid bending or damaging the heating element or wiring.

SPECIFICATIONS

Feature	Detail
Part Number	242044113
Brand	Electrolux (Genuine Replacement Part)
Material	Stainless Steel
Voltage	115 Volts
Wattage	450 Watts
Item Length	Approximately 10 Inches
Item Weight	Approximately 0.32 ounces (9.07 g)
UPC	840993000799

INSTALLATION INSTRUCTIONS

Replacing a defrost heater assembly requires careful attention to detail. The following steps are general guidelines. Always refer to your specific appliance's service manual or a reputable online video tutorial for your exact model for detailed, visual instructions.

1. Prepare the Appliance:

- Disconnect the refrigerator/freezer from its power source.
- Empty the freezer compartment of all food items.
- Allow any existing ice buildup to melt completely. This may take several hours. Place towels on the floor to absorb water.
- Remove shelves, ice maker, and any other components obstructing access to the rear panel of the freezer compartment.

2. Access the Evaporator Coils:

- Locate and carefully remove the rear panel inside the freezer compartment. This panel is usually secured with screws.
- Once the panel is removed, the evaporator coils and the existing defrost heater will be visible.

3. Remove the Old Defrost Heater:

- Carefully disconnect the electrical wires leading to the old defrost heater. Note their position for reinstallation.
- The heater is typically secured with clips or screws. Gently release these fasteners and remove the old heater from its position around or beneath the evaporator coils.
- Be cautious of sharp edges around the evaporator fins.

4. Install the New Defrost Heater:

- Position the new Electrolux 242044113 Defrost Heater Assembly in the same location as the old one.
- Secure it using the existing clips or screws. Ensure it is firmly in place and does not touch any moving parts or other components unnecessarily.

- Connect the electrical wires to the new heater, ensuring a secure and correct connection.

5. Reassemble the Appliance:

- Replace the rear panel, securing it with its screws.
- Reinstall any shelves, the ice maker, and other components that were removed.
- Plug the appliance back into the electrical outlet or turn on the circuit breaker.

6. Test Operation:

- Monitor the appliance for a few hours to ensure it is cooling properly and that the defrost cycle is functioning as expected.

Note: Online resources such as YouTube often provide visual guides for specific refrigerator models. Searching for "[Your Refrigerator Model Number] defrost heater replacement" can be very helpful.

OPERATING PRINCIPLE

The Electrolux 242044113 Defrost Heater Assembly operates automatically as part of your refrigerator's defrost system. It is controlled by a defrost timer or an adaptive defrost control board, which activates the heater periodically (e.g., every 8-12 hours) for a short duration (e.g., 20-30 minutes). During this cycle, the heater warms the evaporator coils, melting any frost that has accumulated. The melted water then drains through a tube to a pan beneath the refrigerator, where it evaporates. This process is essential for maintaining the appliance's cooling efficiency and preventing excessive ice buildup.

MAINTENANCE

While the defrost heater itself requires no routine maintenance, proper care of your refrigerator can extend the life of its components, including the defrost system.

- **Keep Doors Sealed:** Ensure refrigerator and freezer doors seal properly to prevent warm, moist air from entering, which can increase frost buildup.
- **Clean Condenser Coils:** Periodically clean the condenser coils (usually located at the back or underneath the appliance) to ensure efficient operation and reduce strain on the cooling system.
- **Avoid Overloading:** Do not overload the freezer, as this can restrict airflow and lead to uneven cooling and increased frost.

TROUBLESHOOTING

If your refrigerator or freezer is experiencing issues related to frost buildup after replacing the defrost heater, consider the following:

- **Excessive Frost Buildup:** If frost quickly returns or accumulates heavily on the evaporator coils, the issue might not be solely the heater. Check the defrost thermostat (bimetal thermostat) and the defrost timer/control board, as these components work in conjunction with the heater.
- **Appliance Not Cooling:** Heavy frost buildup can block airflow, leading to poor cooling in both the freezer and fresh food compartments. If the new heater is installed correctly but cooling issues persist, other components of the sealed system or control board may be at fault.
- **Water Leaks:** If the defrost drain is clogged, melted water cannot escape, leading to ice buildup at the bottom of the freezer or water leaking into the fresh food compartment or onto the floor. Ensure the drain tube is clear.

For complex issues, it is recommended to consult a professional appliance repair technician.

WARRANTY AND SUPPORT

As a genuine Electrolux replacement part, this defrost heater assembly typically comes with a manufacturer's warranty. Please refer to the packaging or contact Electrolux customer support for specific warranty terms and conditions. For technical assistance

or further inquiries, you may visit the official Electrolux website or contact their customer service department.
Electrolux Customer Support: www.electrolux.com/support

© 2023 Electrolux. All rights reserved. This manual is for informational purposes only.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page
<https://manuals.plus/asin/B00LGV19FW>
More documents and user manuals: <https://manuals.plus/>