

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [DELTA](#) /

› [DELTA Canopies 10'x30' PE Party Tent Instruction Manual](#)

DELTA WDMT

DELTA Canopies 10'x30' PE Party Tent Instruction Manual

1. INTRODUCTION

This manual provides detailed instructions for the safe and efficient assembly, operation, and maintenance of your DELTA Canopies 10'x30' PE Party Tent. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

The DELTA Canopies 10'x30' PE Party Tent is designed to provide temporary shelter for various outdoor events, including parties, corporate gatherings, and other social functions. Its robust galvanized steel frame and durable polyethylene cover offer protection from sun and light rain.



Image 1.1: Fully assembled DELTA Canopies 10'x30' PE Party Tent.

2. IMPORTANT SAFETY WARNINGS

Your safety and the safety of others are paramount. Failure to follow these instructions may result in serious injury or property damage.

- **Anchoring:** Always ensure the tent is securely anchored to the ground using appropriate stakes, ropes, or weights, especially in windy conditions. Inadequate anchoring can lead to the tent lifting or collapsing.
- **Weather Conditions:** This tent is designed for temporary use and is not intended for extreme weather conditions such as heavy winds, snow, or severe thunderstorms. Disassemble the tent if adverse weather is anticipated.
- **UV Exposure:** While the tent offers some UV protection, prolonged exposure to direct sunlight under the tent should be minimized. Take appropriate precautions against UV radiation.
- **Fire Hazard:** Keep all sources of ignition, including open flames, heaters, and cooking equipment, away from the tent fabric. The material is not fireproof.
- **Assembly:** Assembly requires at least two adults. Do not attempt to assemble the tent alone. Follow all assembly steps carefully.
- **Site Selection:** Choose a level, clear area free from overhead obstructions (e.g., power lines, tree branches) and sharp objects on the ground.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, contact customer support immediately.

- Galvanized Steel Frame Poles (various lengths and types)
- Metal Connectors (for frame assembly)
- Polyethylene (PE) Roof Cover
- Polyethylene (PE) Side Walls (with windows)
- Ropes and Stakes (for anchoring)
- Storage Bag

10'x30' Tent with Metal Connectors



Storage Bag Included

Image 3.1: Tent components including metal connectors.

4. SETUP AND ASSEMBLY

Follow these steps carefully for proper assembly. It is recommended to have at least two people for assembly.

- 1. Unpack Components:** Lay out all frame poles, connectors, and fabric parts on a clean, flat surface. Identify each component.
- 2. Assemble the Roof Frame:** Connect the roof poles using the metal connectors. Ensure all connections are secure.



Image 4.1: Assembled galvanized steel frame structure.

3. **Attach the Roof Cover:** Carefully drape the polyethylene roof cover over the assembled roof frame. Secure it to the frame using the provided fasteners or bungee balls.



Image 4.2: Tent frame with roof cover installed.

4. **Install Legs:** Attach the leg poles to the roof frame connectors. Gradually raise the tent structure, ensuring stability as you go.
5. **Attach Side Walls:** Secure the polyethylene side walls to the frame using the integrated fasteners. The side walls with windows can be positioned as desired.



Image 4.3: Tent with side walls being attached.

6. **Anchor the Tent:** Use the provided ropes and stakes to firmly anchor the tent to the ground at all designated points. This step is critical for stability.



Image 4.4: Detail of a metal connector for the frame.

5. OPERATING AND USE GUIDELINES

To ensure the longevity and safe operation of your DELTA Canopies tent, observe the following guidelines:

- **Ventilation:** Ensure adequate ventilation, especially if using the tent in warm weather or with many occupants.
- **Weather Monitoring:** Regularly check weather forecasts. Disassemble the tent if strong winds, heavy rain, or snow are predicted.
- **Weight Distribution:** Avoid hanging heavy objects from the tent frame, as this can compromise its structural integrity.
- **Entry/Exit:** Use designated entry and exit points. Avoid forcing entry or exit, which could damage zippers or fabric.



Image 5.1: Interior view of the tent, suitable for various events.

6. MAINTENANCE AND CARE

Proper maintenance will extend the life of your tent.

- **Cleaning:** Clean the polyethylene fabric with mild soap and water. Do not use harsh chemicals or abrasive cleaners, as these can damage the material. Rinse thoroughly and allow to air dry completely before storage.
- **Frame Inspection:** Periodically inspect the galvanized steel frame for any signs of rust, bending, or damage. Replace any compromised parts immediately.
- **Storage:** Ensure the tent fabric and frame components are completely dry before packing them into the storage bag. Store in a cool, dry place away from direct sunlight and extreme temperatures.



Image 6.1: Included storage bag for tent components.



Image 6.2: Carrying the tent in its storage bag.

7. TROUBLESHOOTING

This section addresses common issues you might encounter.

- **Tent Instability:** If the tent feels unstable, re-check all frame connections and ensure all anchoring points (stakes, ropes) are securely fastened to the ground. Add additional weights if necessary.
- **Water Accumulation/Condensation:** Ensure the roof cover is taut to prevent water pooling. Condensation can occur due to temperature differences; ensure adequate ventilation to minimize this.
- **Difficulty Assembling Frame:** Verify that you are using the correct poles and connectors as per the assembly diagram (not included in this text, refer to product packaging for specific diagrams). Ensure no parts are bent or damaged.
- **Damaged Fabric:** Small tears in the polyethylene fabric can often be repaired with a suitable repair kit or strong waterproof tape. For significant damage, contact customer support for replacement parts.

8. SPECIFICATIONS

Feature	Detail
Brand	DELTA
Model Number	WDMT
Dimensions	10'x30' (Length x Width)
Floor Area	300 Square Feet
Frame Material	Galvanized Steel
Cover Material	Polyethylene (PE)
Color	White
Water Resistance Level	Water Resistant
UV Protection	Yes
Assembly Required	Yes
Item Weight	106 Pounds
UPC	799418233789


9. WARRANTY AND SUPPORT

This product comes with a manufacturer's warranty. For specific warranty details, please refer to the documentation included with your purchase or contact the seller directly. If you require assistance with assembly, missing parts, or have any questions regarding your DELTA Canopies tent, please contact WPIC-Store customer support.

Manufacturer/Seller: WPIC-Store

For support, please visit the DELTA store on Amazon or contact the seller through your purchase platform.

Related Documents - WDMT

	<p>DELTA Z19-3U*P2 Rack Cabinet Blank Panel User Manual</p> <p>User manual for the DELTA Z19-3U*P2 Blank Panel, designed to bridge gaps in rack cabinets. Includes safety information, package contents, specifications, and manufacturer details.</p>
	<p>DELTA M520 Micro Camera User Manual</p> <p>User manual for the DELTA M520 Micro Camera, detailing its features, specifications, safety precautions, and proper disposal. Includes information on its discreet design and technical capabilities.</p>
	<p>Delta Variable Speed Grinder 23-206 & 23-207 User Manual</p> <p>This manual provides comprehensive instructions for the Delta 23-206 (6-inch) and 23-207 (8-inch) Variable Speed Grinders, covering features, specifications, safety guidelines, operation, maintenance, and troubleshooting.</p>
	<p>DELTA FUT007 Remote Control User Manual - MiBOXER LED Lighting</p> <p>Comprehensive user manual for the DELTA FUT007 remote control, compatible with MiBOXER/Mi-Light 2.4 GHz LED lighting controllers. Features include zone control, brightness adjustment, and CCT settings.</p>
	<p>DELTA A Series Temperature Controller Instruction Sheet - User Manual</p> <p>Detailed instruction sheet for DELTA A Series Temperature Controllers (DTA4848, DTA4896, DTA7272, DTA9696). Covers safety, operation, specifications, and technical details for industrial temperature control.</p>

<p>TP02G-AS1 Instruction Sheet 要 裝 說 明 TecPac TECHNICAL PACIFIC</p> <p>3024088P</p> <p>DELT Delta Systems. Together.</p>	<p>Delta TP02G-AS1 Operator Panel: Instruction Sheet and Specifications</p> <p>A comprehensive guide to the Delta TP02G-AS1 operator panel, covering installation, hardware operation, panel functions, specifications, password management, and communication connections. Includes detailed diagrams and safety warnings.</p>
--	---


Documents - DELTA – WDMT



[Great Plains NTA-607/NTA-2007 Spartan II No-Till Drill Parts Manual](#)

This parts manual provides detailed information, illustrations, and part numbers for the Great Plains NTA-607 and NTA-2007 Spartan II No-Till Drill models.

lang:en score:20 filesize: 7.02 M page_count: 168 document date: 2023-05-10



[\[pdf\] User Manual](#)

Parts Manual HDZ 4 Mower 08 21 deborahs Bush Hog 2021 04 — ENGINES AND RELATED PARTS

Kawasaki Engine Kohler Engines BUSH HOG LAND MAINTENANCE REPAIR MANUAL bushhog |||

Revised 08/21 HDZ-4 SERIES ZEROTURNMOWER MODELS HDZ3155FX4,


HDZ3161FX4, HDZ3173FX4, HDZ3355ECV4, HD ... 2020 REF. NO. PART NO.

DESCRIPTION REF. QTY. NO. PART NO. DESCRIPTION QTY. 1 50081783 Frame

Wdmt, 55 , HDZ W/Decals 1 50081784 Frame **Wdmt**, 61 , HDZ W/Decals 1

50081785 Frame **Wdmt**, 73 , HDZ W...

lang:de score:18 filesize: 7.57 M page_count: 62 document date: 2021-08-19



[pdf] User Manual

Sec 118C HDZ 4 Mower deborahs PARTS MANUAL 06 20 bushhog 2020

Revised 06/20 HDZ-4 SERIES ZEROTURNMOWER MODELS HDZ3155FX4,

HDZ3161FX4, HDZ3173FX4, HDZ3355ECV4, HD ... 2020 REF. NO. PART NO.

DESCRIPTION REF. QTY. NO. PART NO. DESCRIPTION QTY. 1 50081783 Frame

Wdmt, 55 , HDZ W/Decals 1 50081784 Frame **Wdmt**, 61 , HDZ W/Decals 1

50081785 Frame **Wdmt**, 73 , HDZ W...

lang:de score:17 filesize: 7.56 M page_count: 62 document date: 2020-06-03



[pdf] User Manual

Sec 118B HDZ 3 Mower Layout 1 deborahs Parts Manual 09 19 bushhog 2020 01


Published 09/19 HDZ-3 SERIES ZEROTURNMOWER MODELS HDZ3161FX3,

HDZ3173FX3, HDZ3361ECV3, HDZ3373ECV3 ... 0077894-10 25 50081097

50081098 50081100 50081101 26 50079962 27 50079963 28 50043276 Frame

Wdmt, 61 , HDZ W/Decals 1 Frame **Wdmt**, 73 , HDZ W/Decals 1 Caution Decal, Operator Spanish 1 Cau...

lang:en score:16 filesize: 7.26 M page_count: 54 document date: 2019-09-11




[pdf] Warranty Catalog

YIELDTRAC Norwood Sales The exploded parts illustration will be shown on the left page and listing right throughout this catalog Option 2019 24R22 2000 Series Yieldtrac Parts Catalog T0056283norwoodsales files manuals yieldtrac 2019 T0056283 |||

YIELDTRAC Yieldtrac Planter Bar 24R-22 24 Row 22 Spacing 2000 Series Front Fold Trailing Planter ... TA02054 Assy, 24R22 RH Wing 1 17 TA02083 Assy, Bulk Material 24R22 FF 2000 1 18 TWO001398 **Wdmt**, Control Link 2 Note: 1. T=XXX = Torque Expressed in ft-lbs Use standard torque values fro...

lang:en score:11 filesize: 22.54 M page_count: 186 document date: 2024-04-18




[pdf] Price List

Kathy Jauregui partlist amsportworks 80 docs s

American SportWorks Parts Price List Effective 5/1/11 NOTE: A D- in front of the description means ... RIPTION BOLT 5/8-11 X 6.000 HHCS G5 Z NUT 1/2-13 TL HEX Z BOLT 3/4-10 X 6.500 HHCS G8 PL SPINDLE LH **WDMT** LG - GBLK W/ ZERK SPINDLE RH **WDMT** LG - GBLK W/ ZERK FRONT BRK **WDMT** - GBLK WIRE ASM BRK LGT SWTC...

lang:i-klingon score:10 filesize: 511.41 K page_count: 45 document date: 2011-04-29

YIELDTRAC



Yieldtrac Planter Bar 16R-30
16 Row 30" Spacing (2000 Barrels)
Front Fold Trailing Planter

Part number 1000055
1st edition English
July 2019

[pdf] Warranty Catalog

YIELDTRAC Norwood Sales 3560 4285 4827 Notes Bolt head identification marks as per grade

Manufacturing will vary Thick nuts must be used with Grade 8 bolts 2018 16R30 2000 Series Yieldtrac

Parts Catalog T0056295norwoodsales files manuals yieldtrac 2018 T0056295 |||

YIELDTRAC Yieldtrac Planter Bar 16R-30 16 Row 30 Spacing 2000 Series Front Fold

Trailing Planter ... rator s Package 16R30 FF 2000 Bulk Fill Assy 2000 Assy, 16R30

LH Stub Arm Assy, 16R30 RH Stub Arm Wdmt, Control Link aty. Aner 1 1 1 2 1 1 1

1 1 1 1 1 2 Note: 1. T=XXX = Torque Expressed in ...

lang:en score:10 filesize: 23.97 M page_count: 193 do