

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Whirlpool](#) /

› [Whirlpool 180 L 4 Star Direct-Cool Single Door Refrigerator \(195 Mp Classic Plus 4S, Wine Duet\) - User Manual](#)

Whirlpool 195 Mp Classic Plus 4S

Whirlpool 180 L 4 Star Direct-Cool Single Door Refrigerator

MODEL: 195 MP CLASSIC PLUS 4S, WINE DUET

1. Introduction

Welcome to the user manual for your new Whirlpool 180 L 4 Star Direct-Cool Single Door Refrigerator, model 195 Mp Classic Plus 4S. This appliance is designed for efficient cooling and convenient storage, featuring a **Jumbo Bottle Rack**, a unique **Health Guard Door** with an anti-fungal gasket, and **Stabilizer Free Operation**. It also includes a durable **Roll-Bond Freezer**, an ergonomically designed external handle, a **Quick Chill Zone**, and robust **Toughened Glass shelves**. Please read this manual carefully to ensure proper installation, operation, and maintenance of your refrigerator.

2. Safety Information

Always adhere to the following safety precautions to prevent injury or damage to the appliance:

- Ensure the refrigerator is connected to a properly grounded electrical outlet. Do not use extension cords.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Keep ventilation openings in the appliance enclosure or in the built-in structure clear of obstruction.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- The refrigerator operates without the need for an external stabilizer, but ensure the power supply is stable within the specified voltage range.
- Unplug the appliance before cleaning or performing any maintenance.

3. Product Overview



Figure 3.1: Whirlpool 180 L Direct-Cool Single Door Refrigerator (Wine Duet)

This image displays the Whirlpool 180 L Single Door Refrigerator in its distinctive Wine Duet color. The appliance

features a sleek silver-colored front door panel with a contrasting wine-colored body and top. An ergonomically designed, recessed handle is visible on the left side of the door, providing easy access. The Whirlpool logo is subtly placed on the upper right portion of the silver door. The overall design is compact and modern, suitable for various kitchen settings.

Key components include:

- **Refrigerator Compartment:** Main storage area with Toughened Glass shelves.
- **Freezer:** Roll-Bond Freezer for ice and frozen items.
- **Chiller Zone:** Extra deep zone for quick chilling of beverages.
- **Jumbo Bottle Rack:** Designed to accommodate large 2L bottles.
- **Health Guard Door Gasket:** Anti-fungal gasket for hygiene.
- **External Handle:** Ergonomically designed for comfortable opening.
- **Door Lock:** For added security.

4. Setup

1. **Unpacking:** Carefully remove all packaging materials. Inspect the refrigerator for any transit damage.
2. **Placement:**
 - a. Place the refrigerator on a firm, level surface away from direct sunlight, heat sources, and moisture.
 - b. Ensure adequate ventilation around the appliance (at least 10 cm clearance from walls).
 - c. Adjust the leveling feet at the bottom to ensure stability and proper door alignment.
3. **Initial Cleaning:** Before first use, clean the interior and exterior with a soft cloth and mild detergent. Rinse and dry thoroughly.
4. **Power Connection:** Plug the refrigerator into a dedicated 3-pin power socket. This model features *Stabilizer Free Operation*, eliminating the need for an external voltage stabilizer within its specified operating range.
5. **First Use:** Allow the refrigerator to run empty for at least 2-4 hours before loading food items to ensure it reaches optimal cooling temperature.

5. Operating Instructions

- **Temperature Control:** Locate the thermostat knob inside the refrigerator compartment. Adjust it to your desired cooling level. Higher numbers typically indicate colder settings.
- **Food Storage:**
 - a. Utilize the **Toughened Glass shelves** for storing heavy containers. These shelves are designed for durability.
 - b. Place large 2-liter bottles in the dedicated **Jumbo Bottle Rack** for secure storage.
 - c. Use the **Quick Chill Zone** for rapidly cooling beverages or small items.
 - d. Ensure food items are properly covered to prevent odor transfer and maintain freshness.
- **Door Operation:** The ergonomically designed external handle allows for easy opening and closing of the door. Ensure the door is fully closed after each use to maintain cooling efficiency.
- **Door Lock:** If your model is equipped with a door lock, use the provided key to secure the door when necessary.

6. Maintenance

Regular maintenance ensures optimal performance and longevity of your refrigerator.

- **Cleaning:**

- Unplug the refrigerator before cleaning.
- Clean the interior regularly with a solution of mild detergent and warm water. Wipe dry with a soft cloth.
- The **Unique Health Guard Door** features a special anti-fungal gasket. Clean this gasket regularly with a damp cloth to prevent mold growth and ensure a tight seal.
- Clean the exterior surfaces with a soft, damp cloth. Avoid abrasive cleaners.

- **Defrosting:** As a Direct Cool refrigerator, manual defrosting is required when frost accumulation on the freezer walls reaches approximately 5mm.

- Turn off the refrigerator and unplug it.
- Remove all food items from the freezer and refrigerator compartments.
- Leave the door open to allow frost to melt naturally. Place towels at the bottom to collect water.
- Do not use sharp objects to remove ice.
- Once defrosted, clean and dry the interior before plugging it back in and reloading food.

- **Power Outages:** During power outages, keep the refrigerator door closed to maintain internal temperature for as long as possible.

7. Troubleshooting

Before contacting service, check the following common issues and solutions:

Problem	Possible Cause	Solution
Refrigerator not cooling	Not plugged in; power outage; temperature setting too high; door not closed properly.	Check power connection; verify power supply; adjust thermostat to a colder setting; ensure door is fully sealed.
Excessive frost in freezer	Door left open too long; frequent door opening; high humidity; gasket not sealing.	Reduce door opening frequency; ensure door closes completely; check and clean door gasket; perform manual defrost.
Unusual noises	Refrigerator not level; items rattling inside; normal operating sounds (e.g., refrigerant flow).	Adjust leveling feet; rearrange items; normal sounds are not a concern.
Water on floor/inside	Drain hole blocked; excessive humidity; door left open.	Clear drain hole; ensure proper ventilation; keep door closed.

If the problem persists after checking these points, please contact authorized service personnel.

8. Technical Specifications

Brand	Whirlpool
Model	195 Mp Classic Plus 4S
Capacity	180 litres

Energy Efficiency	4 Star Rating
Defrost System	Direct Cool
Installation Type	Freestanding
Form Factor	Standard Single Door
Colour	Wine Duet
Dimensions (LxWxH)	60.2 x 53.6 x 110 Centimeters
Shelf Type	Toughened Glass
Special Features	Door Lock, Jumbo Bottle Rack, Health Guard Door, Stabilizer Free Operation, Quick Chill Zone, Powerful Compressor (Green Gas Technology)

9. Warranty and Support

Your Whirlpool refrigerator comes with a comprehensive warranty to ensure peace of mind:

- **1 Year Comprehensive Warranty** on the entire refrigerator.
- **5 Years Warranty** on the Compressor.

For warranty claims, technical assistance, or service requests, please contact Whirlpool customer support. Keep your purchase receipt and product model information handy when contacting support.