

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Bulova](#) /
- › [Bulova Men's Icon High Precision Quartz Chronograph Watch Model 98B229 User Manual](#)

## Bulova 98B229

# Bulova Men's Icon High Precision Quartz Chronograph Watch

MODEL: 98B229

User Instruction Manual

## 1. PRODUCT OVERVIEW

The Bulova Men's Icon High Precision Quartz Chronograph Watch, Model 98B229, is a sophisticated timepiece featuring a curved mineral crystal, a black ion-plated case and bracelet with striking blue accents on the dial. It is equipped with a high-frequency quartz movement for exceptional accuracy and a comprehensive chronograph function.



Figure 1: Bulova Precisionist Collection showcasing the watch's design.

## 2. SETUP

### 2.1 Unboxing

Carefully remove your new Bulova watch from its packaging. Inspect the watch for any signs of damage. The watch comes securely packaged in a branded box.



Figure 2: The Bulova watch box.

## 2.2 Setting Time and Date

1. Pull the crown (located on the right side of the watch case) out to the first click position to set the date. Turn the crown clockwise or counter-clockwise until the correct date is displayed.
2. Pull the crown out to the second click position to set the time. Turn the crown to move the hour and minute hands until the correct time is displayed. Ensure the AM/PM is correctly set (the date will change at midnight).
3. Push the crown back in to the normal position to engage the movement and start the watch.

## 2.3 Bracelet Adjustment

The stainless steel bracelet can be adjusted to fit your wrist. This typically involves removing or adding links. For precise and safe adjustment, it is recommended to visit a professional jeweler or watch repair service.

# 3. OPERATING INSTRUCTIONS

---

## 3.1 Basic Timekeeping

Your Bulova Precisionist watch features a high-frequency quartz movement, providing exceptional accuracy. The continuous-sweep second hand offers a smooth motion, characteristic of high-end timepieces.



Figure 3: Detailed view of the watch dial, highlighting the chronograph functions.

### 3.2 Chronograph Function

The watch is equipped with a 1/1000 second chronograph. The pushers on the side of the case control the chronograph functions:

- **Start/Stop:** Press the top pusher to start the chronograph. Press it again to stop.
- **Reset:** While the chronograph is stopped, press the bottom pusher to reset all chronograph hands to zero.

### 3.3 Water Resistance

This watch is water resistant to 300 meters (984 feet). This makes it suitable for swimming, snorkeling, and recreational scuba diving. Ensure the crown is fully pushed in before any water exposure.

Your browser does not support the video tag.

Video 1: Official Bulova Precisionist video demonstrating watch features and design.

Your browser does not support the video tag.

Video 2: A brief merchant video showcasing the Bulova 98B229 watch from various angles.

## 4. MAINTENANCE

### 4.1 Cleaning

To maintain the appearance of your watch, wipe the case and bracelet regularly with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals or abrasive materials.

### 4.2 Battery Replacement

The watch is powered by a Lithium Metal battery. When the battery needs replacement, it is highly recommended to take your watch to an authorized Bulova service center or a qualified watchmaker. Improper battery replacement can damage the movement or compromise water resistance.

### 4.3 Water Resistance Checks

Although the watch is highly water resistant, seals can degrade over time. It is advisable to have the water resistance checked periodically (e.g., every 2-3 years) by an authorized service center, especially if the watch is frequently exposed to water.

## 5. TROUBLESHOOTING

## 5.1 Watch Not Running

- Ensure the crown is fully pushed in to the normal operating position.
- If the watch still does not run, the battery may need replacement. Refer to Section 4.2.

## 5.2 Incorrect Time or Date

- Follow the instructions in Section 2.2 to reset the time and date.
- If the time or date repeatedly becomes incorrect, there may be an internal issue requiring professional inspection.

## 6. SPECIFICATIONS

Feature	Detail
Model Number	98B229
Brand	Bulova
Case Material	Gunmetal Grey Ion-Plated Stainless Steel
Band Material	Stainless Steel
Crystal Type	Curved Mineral Crystal
Case Diameter	46 Millimeters
Case Thickness	47 Millimeters
Band Width	24 Millimeters
Movement Type	High Precision Quartz (262 kHz)
Display Type	Analog
Dial Color	Black with Blue Accents
Water Resistance Depth	300 Meters (984 Feet)
Chronograph	1/1000 Second Chronograph
Power Source	Battery Powered (1 Lithium Metal battery included)
Clasp Type	Push Button Foldover Clasp With Safety
Item Weight	246 Grams

## 7. WARRANTY

This Bulova watch is covered by a Manufacturer's Warranty. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration of coverage. Keep your proof of purchase for warranty claims.

## 8. SUPPORT

For further assistance, service, or inquiries regarding your Bulova Men's Icon High Precision Quartz Chronograph

Watch, Model 98B229, please contact Bulova customer service or visit their official website. Authorized service centers can provide expert care for your timepiece.

