

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [iBall](#) /

› [iBall Tarang F5 5.1 Speakers for PC User Manual](#)

iBall Tarang F5

iBall Tarang F5 5.1 Speakers for PC User Manual

Model: Tarang F5

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your iBall Tarang F5 5.1 Speakers for PC. Please read this manual thoroughly before using the product to ensure proper functionality and to prevent damage.

PACKAGE CONTENTS

Verify that all items listed below are present in your package:

- 1 x Subwoofer Unit
- 5 x Satellite Speaker Units
- 1 x Remote Control
- Audio Connection Cables (RCA to 3.5mm, RCA to RCA)
- User Manual (this document)



Image: Overview of the iBall Tarang F5 5.1 Speaker System, showing the subwoofer and five satellite speakers.

SETUP INSTRUCTIONS

- 1. Positioning Speakers:** Place the subwoofer on a stable surface, preferably on the floor. Arrange the five satellite speakers around your listening area for optimal 5.1 surround sound. Typically, one center speaker, two front left/right, and two rear left/right speakers.
- 2. Connecting Satellite Speakers:** Connect each satellite speaker to the corresponding output ports on the rear panel of the subwoofer unit. Ensure correct polarity (positive to positive, negative to negative) if applicable, or match color-coded connectors.
- 3. Connecting Audio Source:**
 - **For PC/MP3 Player (2.1Ch or 5.1Ch input):** Use the provided audio cables to connect the audio output of your device to the "Audio Input" ports on the subwoofer. For 5.1 channel input, ensure your source device supports 5.1 output and connect all relevant channels (Front L/R, Rear L/R, Center/Sub). For 2.1 channel, connect to the stereo input.
 - **For USB/SD/MMC Card:** Insert your USB drive or SD/MMC card into the designated slot on the front panel of the subwoofer.
- 4. Power Connection:** Connect the power cord to the subwoofer unit and then plug it into a standard AC power outlet.
- 5. Power On:** Turn on the main power switch located on the rear or front panel of the subwoofer. The LED display should illuminate.



Image: Illustrative diagram of the subwoofer's rear panel, detailing connections for satellite speakers and various audio input sources.

OPERATING INSTRUCTIONS

Front Panel Controls and Remote Control

The iBall Tarang F5 can be operated using the controls on the front panel of the subwoofer or via the included full-function remote control.

- **Power On/Off:** Press the **POWER** button on the remote or the main power switch on the unit.
- **Input Source Selection:** Press the **INPUT** button on the remote or front panel to cycle through available sources: 2.1Ch, 5.1Ch, USB, SD/MMC, FM Radio. The selected source will be displayed on the LED screen.
- **Volume Adjustment:** Use the **VOL+** and **VOL-** buttons on the remote or the master volume knob on the front panel to adjust the overall volume.
- **Bass/Treble Adjustment:** Use dedicated **BASS+/BASS-** and **TREBLE+/TREBLE-** buttons on the remote control to fine-tune audio output.
- **Mute Function:** Press the **MUTE** button on the remote to temporarily silence the audio. Press again to unmute.

USB/SD/MMC Playback

When a USB drive or SD/MMC card is inserted, the system will automatically switch to the USB/SD input mode and begin playing compatible audio files. Use the remote control for playback functions:

- **Play/Pause:** Press the **PLAY/PAUSE** button.
- **Next/Previous Track:** Use the **NEXT** and **PREV** buttons.

FM Radio Operation

To use the FM radio function:

1. Switch the input source to **FM** mode using the **INPUT** button.
2. **Auto Scan:** Press and hold the **PLAY/PAUSE** button (or a dedicated **SCAN** button if available on the remote) to automatically scan and save available FM stations.
3. **Manual Tuning:** Use the **NEXT** and **PREV** buttons to manually tune to specific frequencies or navigate through saved stations.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker surfaces. Do not use liquid cleaners, aerosols, or solvents, as these may damage the finish or internal components.
- **Ventilation:** Ensure the subwoofer's ventilation openings are not blocked to prevent overheating.
- **Placement:** Avoid placing the speakers in direct sunlight, near heat sources, or in areas with high humidity or dust.
- **Power Cord:** Regularly inspect the power cord for any damage. If damaged, discontinue use and contact customer support.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cord not connected; Power switch off; Power outlet faulty	Ensure power cord is securely connected. Turn on the power switch. Test the power outlet with another device.

Problem	Possible Cause	Solution
No sound	Incorrect input source; Volume too low; Audio cables loose/damaged; Mute function active	Select the correct input source. Increase volume. Check all audio cable connections. Deactivate mute.
Distorted sound	Volume too high; Source audio quality poor; Speaker cables loose	Reduce volume. Test with a different audio source. Check satellite speaker connections.
Remote control not working	Batteries depleted; Obstruction between remote and unit; Remote sensor blocked	Replace remote control batteries. Ensure clear line of sight to the subwoofer's IR sensor.
Poor FM reception	Antenna not extended/positioned correctly; Weak signal area	Extend and adjust the FM antenna for better reception. Try auto-scanning again.

SPECIFICATIONS

Feature	Detail
Brand	iBall
Model	Tarang F5
Channel Configuration	5.1 Surround Sound
Subwoofer Driver Size	5.25 Inches
Satellite Driver Size	3 Inches (each)
Subwoofer Impedance	8 Ohm
Satellite Impedance	4 Ohm
Compatible Devices	Computers, MP3 Players, SD Cards
Connectivity Technology	USB, RCA (for 2.1Ch/5.1Ch input)
Special Features	FM Radio, USB/SD/MMC Playback, Remote Control, LED Display, Wooden Cabinets
Power Source	AC
Material	Wood
Item Weight	8 kg
Package Dimensions (W x H x D)	40.4 x 34.2 x 32.8 cm

WARRANTY AND SUPPORT

Your iBall Tarang F5 5.1 Speakers are covered by a limited warranty from the date of purchase. Please refer to the warranty card included in your package for specific terms and conditions.

For technical support, service, or warranty claims, please contact iBall customer service:

- **Website:** www.iball.co.in/support *(Example link, actual link may vary)*
- **Email:** support@iball.co.in *(Example email, actual email may vary)*
- **Phone:** 1800-XXX-XXXX *(Example number, actual number may vary)*

Please have your product model number (Tarang F5) and proof of purchase ready when contacting support.