

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Rev-A-Shelf](#) /

› [Rev-A-Shelf 4WBDP18-25 Wood Base Cabinet Door Mount Organizer Instruction Manual](#)

Rev-A-Shelf 4WBDP18-25

Rev-A-Shelf 4WBDP18-25 Wood Base Cabinet Door Mount Organizer Instruction Manual

PRODUCT OVERVIEW

The Rev-A-Shelf 4WBDP18-25 is a wood door-mount organizer designed to enhance storage and organization within your base cabinet. This unit features durable maple wood construction with a clear coat finish, ensuring longevity and a consistent aesthetic with various cabinet interiors. It includes adjustable shelves and door-mount brackets for flexible installation and customization.

The organizer is intended for cabinet floor/side mounting and provides convenient access to stored items by attaching directly to your cabinet door.



Image: The Rev-A-Shelf Wood Base Cabinet Door Mount Organizer shown installed inside a kitchen cabinet, providing organized storage for various items.

SETUP AND INSTALLATION

This product requires assembly and installation. Please follow these general guidelines. Specific instructions may vary based on your cabinet type and dimensions. Always ensure the cabinet door can fully close after installation.

1. Measure Your Cabinet Opening



Before installation, accurately measure the minimum cabinet opening (MCO) to ensure proper fit. Consider both framed and frameless cabinet types.

- **Width (W):** Measure the horizontal distance of the opening.
- **Depth (D):** Measure the distance from the front edge to the back of the cabinet.
- **Height (H):** Measure the vertical distance of the opening.

Check for any obstructions such as door hinges or plumbing that might interfere with the organizer's operation.

MINIMUM CABINET OPENING (MCO)

FRAMED VS. FRAMELESS

COMMON
FACE FRAME
WIDTHS:1-1/2"
1-5/8"
1-3/4" MEASUREW WIDTH
D DEPTH
H HEIGHT**PLEASE NOTE!** When measuring, check for obstructions such as door hinges or plumbing

FRAMED

Traditional style
common in the USA

FRAMELESS

(Full-Access)
European inspired design

HOW TO MEASURE

Image: A diagram detailing how to measure the minimum cabinet opening (MCO) for both framed and frameless cabinet styles, highlighting width, depth, and height.

2. Assemble the Organizer

Follow the included hardware instructions to assemble the wood door-mount pantry unit. This typically involves attaching the shelves to the main frame.

3. Mount to Cabinet Door

The adjustable door-mount brackets are essential for operation. Attach these brackets to the cabinet door according to the provided instructions. Ensure they are level and securely fastened.

4. Secure to Cabinet Floor/Side

The organizer is designed for cabinet floor/side mounting. Secure the base of the organizer to the cabinet floor or side using the appropriate hardware. Verify that the unit is stable and aligned with the cabinet door.

OPERATING INSTRUCTIONS

Once installed, the Rev-A-Shelf door-mount organizer provides accessible storage. Simply open your cabinet door to reveal the contents of the organizer.

Adjusting Shelves

The shelves are adjustable, allowing you to customize the storage space to fit various item heights. To adjust a shelf:

1. Empty the shelf of its contents.
2. Carefully lift or slide the shelf to disengage it from its current position.
3. Reposition the shelf at the desired height, ensuring it is securely seated in the new supports.

Avoid overloading the shelves to maintain stability and prevent damage to the unit or cabinet door.

CARE AND MAINTENANCE

Proper care and maintenance will ensure the longevity and optimal performance of your Rev-A-Shelf organizer. Perform the following tasks as needed.

CARE & MAINTENANCE

Rev-A-Shelf® storage & organization products are designed and engineered to last a lifetime.

Our products are manufactured with durable, high quality materials for which little maintenance is required. We recommend you perform the following tasks as needed.

WIPE CLEAN

Occasionally our products become dirty from everyday use in your kitchen, closet, utility room, laundry room, or bathroom. We suggest handwashing with soap and water and wiping dry when this happens. Avoid using abrasives or bleach, and clean promptly as chemicals and oils can break down resin (plastic) polymers or finishes on wood and metal.



ADJUST

Maintenance, if ever needed, consists of simply adjusting a bracket or tightening a screw or bolt that has become loose over a period of time, from normal use.



GREASE

Our products are known to pivot, pull and slide and are usually mounted to a slide system that is coated with a multi-purpose grease. You should never have to apply more grease, but if you need to, always use a good quality multi-purpose one. Never use any spray lubricant, as that will break down the grease over time.



Please contact Rev-A-Shelf® Customer Service with any additional questions or concerns.

1-800-626-1126 | INFO@REV-A-SHELF.COM

Image: A graphic outlining the recommended care and maintenance procedures for Rev-A-Shelf products, including cleaning, adjustment, and lubrication.

Wipe Clean

Periodically clean your organizer to remove dust and spills. Use handwashing with soap and water, then wipe dry promptly. Avoid abrasive cleaners, bleach, or strong chemicals, as these can damage the wood finish or metal components.

Adjust

If any brackets or screws become loose over time due to normal use, simply tighten them. This maintains the stability and functionality of the organizer.

Grease

While the product is designed for smooth operation, if it utilizes a slide system, you may apply a good quality multi-purpose grease if needed. Avoid using spray lubricants, as they can degrade the grease over time.

TROUBLESHOOTING

This section addresses common issues you might encounter with your door-mount organizer.

Organizer Not Closing Properly

- **Check for Obstructions:** Ensure no items on the shelves are protruding and preventing the cabinet door from closing fully.
- **Verify Installation:** Re-check that the door-mount brackets and the organizer's base are securely fastened and correctly aligned. Loose fittings can cause misalignment.
- **Cabinet Squareness:** Ensure your cabinet itself is square and plumb, as an uneven cabinet can affect door closure.

Shelves Feel Loose or Unstable

- **Secure Shelf Placement:** Ensure each shelf is fully seated in its support clips or grooves.
- **Tighten Fasteners:** Check all screws and bolts connecting the shelves and frame, tightening any that are loose.
- **Weight Distribution:** Distribute items evenly on shelves and avoid placing excessively heavy items on upper shelves.

SPECIFICATIONS

Feature	Detail
Model Name	Wood Base Cabinet Door Mount Organizer
Model Number	4WBDP18-25
Brand	Rev-A-Shelf
Product Dimensions	4"D x 12"W x 25"H

Feature	Detail
Material	Maple Wood (Maple Veneer)
Finish Type	Clear Polyurethane
Number of Shelves	4
Mounting Type	Cabinet Floor/Side Mounted
Assembly Required	Yes
Item Weight	9.9 Pounds
Included Components	(1) Wood Door-Mount pantry and mounting hardware

WARRANTY INFORMATION

Specific warranty details for the Rev-A-Shelf 4WBDP18-25 Wood Base Cabinet Door Mount Organizer are not provided in this manual. For information regarding product warranty, please contact Rev-A-Shelf customer service directly or refer to the official Rev-A-Shelf website.

CUSTOMER SUPPORT

If you have any questions, concerns, or require assistance with your Rev-A-Shelf product, please contact customer service:

- **Phone:** 1-800-626-1126
- **Email:** INFO@REV-A-SHELF.COM

You can also visit the official Rev-A-Shelf website for additional product information and support resources.

OFFICIAL PRODUCT VIDEOS

No official product videos from the seller were found for this item in the provided data.

This instruction manual is for informational purposes only. Rev-A-Shelf reserves the right to make changes to products without prior notice.