

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Gorenje](#) /

› [Gorenje W8644H Front-loading Washing Machine User Manual](#)

Gorenje W8644H

Gorenje W8644H Front-loading Washing Machine User Manual

Model: W8644H

INTRODUCTION

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Gorenje W8644H Front-loading Washing Machine. Please read these instructions carefully before using the appliance for the first time and keep them for future reference.



A white Gorenje W8644H front-loading washing machine with a silver-grey door ring and a control panel featuring a central dial and an LCD display.

SETUP AND INSTALLATION

Unpacking and Placement

The Gorenje W8644H is a freestanding front-loading washing machine. Ensure the appliance is placed on a stable, level surface. Remove all packaging materials and transit bolts before use. Refer to the separate installation guide for detailed instructions on removing transit bolts and connecting water/drain hoses.

Dimensions and Weight

- **Item Dimensions (LxWxH):** 60 x 60 x 85 Centimeters
- **Item Weight:** 80 kg 500 g

Installation Service

For requesting installation or a demonstration, please contact the provided customer support channels. The manufacturer will arrange for an appointment at your convenience. Note that for semi-automatic washing machines and refrigerators, installation is typically not provided by the manufacturer; however, this model is fully automatic.

OPERATING INSTRUCTIONS

Control Panel

The Gorenje W8644H features a fully automatic control console with an LCD display and a central program selection dial. Familiarize yourself with the various buttons and indicators before starting a wash cycle.

Loading Laundry

This washing machine has an 8 kg capacity. Do not overload the drum. Ensure clothes are evenly distributed to prevent imbalance during the spin cycle. The door opens 180 degrees for easy loading and unloading.

Wash Programs

Select the appropriate wash program using the program dial. The machine offers 23 wash programs, including:

- Cotton
- Synthetic
- Wool
- Hand Wash
- Quick Program
- Only Spin
- Bio Wash (for natural cleaning)
- NightWash (optimized for quiet operation)
- Sport mode

Special Functions and Settings

- **Prewash:** Use for heavily soiled clothes.
- **Time Delay:** Allows you to load the machine and start the wash cycle at a later, pre-set time.
- **Temperature Setting:** Adjustable for various fabric types.
- **Adjustable Spin Speed:** Up to 1400 RPM.
- **Personal Settings:** Customize and save settings for all programs.
- **Child Protection (CDP):** Activates a lock to prevent accidental program changes by children.
- **SoftSound:** Audio signals for user feedback.

- **Shower Jet:** Enhances washing performance.
- **Drum Illumination:** LED light inside the drum for visibility.
- **SensoCARE:** Advanced sensor technology for optimized washing.

MAINTENANCE

Cleaning the Appliance

Regularly wipe the exterior of the washing machine with a soft, damp cloth. Clean the detergent dispenser drawer to prevent residue buildup. Refer to the full manual for instructions on cleaning the pump filter.

SterilTub Program

The SterilTub program is designed to clean the washing machine drum and remove any bacteria or odors, ensuring optimal hygiene for your laundry. Run this program periodically, especially if you frequently wash at low temperatures.

PerfectBlack Feature

The PerfectBlack feature helps maintain the intensity of dark colors, reducing fading over time. Use appropriate detergents for dark laundry.

TROUBLESHOOTING

If your washing machine is not functioning as expected, consult the following basic troubleshooting steps. For more complex issues, refer to the comprehensive troubleshooting guide in the full product manual or contact customer support.

Common Issues

- **Machine does not start:** Check if the power cord is properly plugged in, the door is closed securely, and the start button has been pressed.
- **No water intake:** Ensure the water supply tap is open and the water inlet hose is not kinked.
- **Excessive vibration:** Verify that the transit bolts have been removed and the machine is level.
- **Service Diagnostic Indicator:** If this indicator illuminates, it suggests a fault. Note the error code (if displayed) and contact customer service.

Safety Features

- **Partial Aqua Stop:** Provides protection against water leakage.
- **Overflow Protection:** Prevents water from overflowing the drum.
- **High Water Level Indication:** Alerts to excessive water levels.

SPECIFICATIONS

Brand	Gorenje
Model	W8644H
Capacity	8 Kilograms
Maximum Rotational Speed	1400 RPM

Installation Type	Freestanding
Form Factor	Front-Loading
Colour	White
Control Console	Fully Automatic
Access Location	Front Load
Door Orientation	Front-loading
Item Weight	80 kg 500 g
Item Dimensions (LxWxH)	60 x 60 x 85 Centimeters
Cycle Options	Cotton, Hand Wash, Prewash, Spin, Synthetic, Wool

WARRANTY AND SUPPORT

Warranty Information


The Gorenje W8644H Front-loading Washing Machine comes with a 2-year warranty on the product. Please retain your purchase receipt for warranty claims.



Customer Support

For any service requests, technical assistance, or to schedule an installation/demo, please contact Gorenje customer support. Refer to your purchase documentation for specific contact details or visit the official Gorenje website.

© 2023 Gorenje. All rights reserved.

Related Documents - W8644H

 gorenje USER MANUAL WASHING MACHINE	<p>Gorenje Washing Machine User Manual: Operation, Safety, and Maintenance</p> <p>This user manual provides comprehensive guidance for Gorenje washing machines, covering installation, operation, safety instructions, troubleshooting, and maintenance tips for optimal performance and longevity.</p>
 RB39EPW4 G200 Freestanding Fridge, 44.2 x 47.3 x 66.8 cm, White	<p>Gorenje RB39EPW4 Freestanding Refrigerator Specifications</p> <p>Detailed technical specifications and features for the Gorenje RB39EPW4 G200 freestanding refrigerator, including dimensions, energy efficiency, control, equipment, and more.</p>

 <p>PVK61S-1V Cooktop a gás</p>	<p>Manual de Uso, Instalação e Ligação do Cooktop a Gás Gorenje PVK61S-1V</p> <p>Este manual detalha a instalação, operação segura, manutenção e solução de problemas do cooktop a gás Gorenje PVK61S-1V. Aprenda a conectar e usar seu aparelho Gorenje de forma eficaz.</p>
 <p>gorenje INSTRUCTIUNI DE UTILIZARE MASINA DE GĂTIT INDEPENDENTĂ</p>	<p>Gorenje Mașină de Gătit Independentă - Manual de Utilizare</p> <p>Manual detaliat de utilizare pentru mașina de gătit independentă Gorenje, inclusând instrucțiuni de siguranță, operare, întreținere și depanare pentru o utilizare optimă și sigură a aparatului dumneavoastră.</p>
 <p>gorenje UDÉHÉZMÉN PÉR PERIODRUM MASINA LAVARE</p>	<p>Gorenje Washing Machine User Manual</p> <p>Comprehensive user manual for Gorenje washing machines, covering installation, operation, maintenance, troubleshooting, and safety guidelines.</p>
 <p>W1PNEI84A1SWIFI gorenje ConnectLife</p>	<p>Gorenje W1PNEI84A1SWIFI: 8kg Washing Machine with ConnectLife and 1400 RPM Spin</p> <p>Discover the Gorenje W1PNEI84A1SWIFI, an 8kg freestanding washing machine featuring ConnectLife smart technology, 1400 RPM spin speed, multiple wash programs, and energy-efficient operation. Learn about its features, specifications, and performance.</p>