

## Braun 810

# Braun Face 810 Mini Facial Epilator and Cleansing Brush User Manual

## 1. INTRODUCTION

The Braun Face 810 is a versatile device designed for precise facial epilation and deep facial cleansing. This cordless, waterproof unit combines a slim epilator head with 10 micro-openings for efficient root hair removal and a cleansing brush with micro-oscillations for pore-deep skin cleansing. This manual provides essential information for the safe and effective use of your device.

## 2. SAFETY INFORMATION

### **WARNING:**

- Keep away from water when not in use or when changing batteries.
- For external use only.
- Do not use on irritated skin, open wounds, or if you have any skin conditions. Consult a dermatologist if you have concerns.
- Keep out of reach of children.

## 3. WHAT'S IN THE BOX

Your Braun Face 810 package typically includes:

- Braun Face 810 device body
- Epilator head
- Cleansing brush head
- Protective cap
- Batteries (LR44, typically 1-2 included)



Vol Share in 2015-2016, leading market research institutes

Image: Braun Face 810 device with its epilator head, cleansing brush head, and batteries.

## 4. SETUP

---

### 4.1. Battery Installation

1. Twist the bottom part of the device counter-clockwise to open the battery compartment.
2. Insert the LR44 battery(ies) according to the polarity markings (+/-).
3. Twist the bottom part clockwise to securely close the battery compartment.

### 4.2. Attaching Heads

1. Ensure the device is turned off.
2. Align the desired head (epilator or cleansing brush) with the device body.
3. Gently push and twist until it clicks into place.
4. To remove, twist and pull the head off.

## 5. OPERATING INSTRUCTIONS

---

### 5.1. Facial Epilation

The epilator head is designed for precise removal of fine facial hair from areas such as the upper lip, chin, forehead, and for maintaining eyebrows.

1. Ensure your skin is clean and dry before epilation.
2. Turn on the device. The epilator head can rotate in two directions (clockwise and counter-clockwise). Select the direction that is opposite to your hair growth for optimal results.
3. Hold the device gently against your skin, ensuring the epilator head is flat.
4. Move the device slowly and smoothly against the direction of hair growth. Avoid sudden jerks.
5. After epilation, you may experience slight redness. Apply a soothing cream or a cold compress if needed. It is recommended to epilate in the evening to allow skin to recover overnight.

## 5.2. Facial Cleansing

The cleansing brush head provides pore-deep cleansing and gentle exfoliation.

1. Attach the cleansing brush head to the device.
2. Wet your face and the brush head. Apply your preferred facial cleanser directly to the brush or your face.
3. Turn on the device.
4. Gently move the brush in small circular motions across your face for approximately one minute. Avoid pressing too hard.
5. Rinse your face and the brush head thoroughly after use.



Image: Demonstrating use on eyebrows and upper lip.



Image: Overview of facial epilation and cleansing features.

## 6. MAINTENANCE

---

### 6.1. Cleaning the Device and Heads

The Braun Face 810 is waterproof, allowing for easy cleaning under running water.

1. After each use, turn off the device and remove the head.
2. Rinse the epilator head and cleansing brush head under warm running water. You can use a small brush (if provided) to remove any trapped hairs from the epilator head.
3. Clean the device body with a damp cloth. Do not use abrasive cleaners or harsh chemicals.
4. Allow all parts to air dry completely before reassembling or storing.

### 6.2. Storage

Store the device in a cool, dry place, away from direct sunlight and extreme temperatures. Use the protective cap for the epilator head when not in use to prevent damage.

## 7. TROUBLESHOOTING

---

- **Device not turning on:** Check if the batteries are correctly inserted and have sufficient charge. Replace batteries if necessary.
- **Reduced epilation performance / Motor slowing down:** Ensure the epilator head is clean and free of hair. The battery might be low; replace it. Ensure you are not pressing too hard against the skin, which can impede rotation.
- **Skin irritation/redness:** This can be normal, especially during initial uses. Ensure you are moving the device smoothly and not applying excessive pressure. Apply a soothing cream after use. If irritation persists, discontinue use and consult a dermatologist.
- **Blades not spinning properly:** This could indicate a mechanical issue. Ensure the head is correctly attached and clean. If the problem persists, contact customer support.

## 8. SPECIFICATIONS

---

- **Model Number:** 810
- **Power Source:** Battery Powered (1 LR44 battery required, included)
- **Water Resistance Level:** Waterproof
- **Item Weight:** Approximately 299 g (10.58 Ounces)
- **Item Dimensions (LxWxH):** 10 x 4 x 15 Centimeters
- **Recommended Uses:** Face, Lip
- **First Available:** 3 August 2014

## 9. WARRANTY

---

The Braun Face 810 typically comes with a **2-year manufacturer warranty**. Please retain your proof of purchase for warranty claims. For specific terms and conditions, refer to the warranty card included with your product or contact Braun customer service.

## 10. SUPPORT

---

For further assistance, product inquiries, or warranty claims, please contact Braun customer service:

- **Braun Customer Care (India):** 1800-202-1364
- **Email:** [intouch.im@pg.com](mailto:intouch.im@pg.com)
- **Manufacturer:** Procter & Gamble, One P&G Plaza, Cincinnati, Ohio 45202, United States
- **Importer (India):** Universal Corporation limited, 4/1 Middleton Street, Sikkim Commerce House, Kolkata - 700080