Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DEWALT DWA7760

DEWALT Circular Saw Blade DWA7760 Instruction Manual

5 1/2 Inch, 30 Tooth, Aluminum Cutting

1. Introduction

This manual provides essential information for the safe and effective use of your DEWALT DWA7760 Circular Saw Blade. This 5-1/2 inch (140 mm) blade features 30 carbide teeth and a 20mm arbor, specifically designed for cutting aluminum. Please read all instructions and safety warnings carefully before installation and operation to ensure optimal performance and user safety.

2. Safety Information

WARNING: Always prioritize safety. Failure to follow these instructions may result in serious injury or property damage.

- **Eye Protection:** Always wear ANSI-approved safety glasses or goggles when operating a circular saw.
- **Hearing Protection:** Use hearing protection to prevent noise-induced hearing loss.
- **Hand Protection:** Wear appropriate gloves to protect hands from sharp edges and debris.
- **Power Disconnection:** Disconnect the saw from the power source before installing, removing, or adjusting the blade.
- **Blade Compatibility:** Ensure the blade's arbor size (20mm) matches your saw's arbor. Never force a blade onto an arbor.
- **Rotation Direction:** Install the blade with the teeth pointing in the correct direction of rotation as indicated on the saw and blade.
- **Secure Fastening:** Ensure the blade is securely fastened and the arbor nut is tightened according to your saw's manufacturer instructions.
- **Material Suitability:** This blade is specifically designed for cutting aluminum. Do not use it for cutting other materials unless explicitly stated by DEWALT.
- **Maximum RPM:** Do not exceed the maximum RPM of 7000 indicated on the blade. Ensure your saw's RPM does not exceed this limit.
- **Workpiece Stability:** Always secure the workpiece firmly to prevent movement during cutting.

3. Product Overview

The DEWALT DWA7760 circular saw blade is engineered for precision and durability in aluminum cutting applications. Key features include:

- **Extra-Hard Carbide Teeth:** Ensures cutting edges remain sharp for extended periods, providing clean cuts.
- **Laser-Cut Expansion Slots:** Designed to minimize noise and reduce blade vibration, resulting in a smoother cut and less burring on aluminum.
- **Laser Etched and Color Coded:** Important blade information, including material suitability (aluminum), is clearly marked and color-coded for quick identification.
- **Dimensions:** 5-1/2 inch (140 mm) diameter with 30 teeth.
- **Arbor Size:** 20mm arbor hole for compatibility with various circular saws.



This image displays the DEWALT DWA7760 circular saw blade. Key features visible include the 5-1/2 inch (140 mm) diameter, 30 carbide teeth, and a 20mm arbor. The blade is clearly marked for 'ALUMINUM CUTTING' and indicates a maximum RPM of 7000. Safety warnings are also visible on the blade's surface.

4. Setup and Installation

Follow these steps to safely install the DEWALT DWA7760 blade on your circular saw:

1. **Disconnect Power:** Ensure your circular saw is unplugged from the power source to prevent accidental startup.
2. **Consult Saw Manual:** Refer to your circular saw's instruction manual for specific blade change procedures and safety guidelines.
3. **Remove Old Blade:** If applicable, carefully remove the old blade, ensuring the arbor nut is loosened correctly.
4. **Clean Arbor:** Clean the saw's arbor and flanges to remove any debris that could affect blade seating.
5. **Install New Blade:** Place the DEWALT DWA7760 blade onto the arbor, ensuring the teeth are oriented correctly for the saw's rotation direction. The blade's label should typically face outwards.
6. **Secure Blade:** Reinstall the outer flange and arbor nut. Tighten the arbor nut firmly using the appropriate wrench, but do not overtighten.
7. **Check for Wobble:** Manually rotate the blade to ensure it spins freely and without wobble.

5. Operating Instructions

When cutting aluminum with the DWA7760 blade, observe the following guidelines for best results and safety:

- **Secure Workpiece:** Always clamp the aluminum workpiece securely to prevent movement during the cut.
- **Proper Feed Rate:** Apply a consistent, moderate feed rate. Avoid forcing the blade, as this can lead to overheating, premature dulling, and kickback.
- **Coolant (Optional):** For extended cuts or thicker aluminum, consider using a cutting lubricant or coolant to reduce heat buildup and improve cut quality.
- **Clear Cutting Path:** Ensure the cutting path is clear of obstructions and that you have a stable stance.
- **Blade Guard:** Always ensure the saw's blade guard is functioning correctly and in place.
- **Avoid Overheating:** If the blade becomes excessively hot, stop cutting and allow it to cool down. Overheating can damage the blade and affect cut quality.

6. Maintenance

Regular maintenance will extend the life of your DEWALT DWA7760 blade and ensure consistent performance:

- **Cleaning:** After each use, clean the blade to remove aluminum chips, dust, and residue. A stiff brush and appropriate cleaning solution can be used. Ensure the blade is dry before storage.
- **Inspection:** Periodically inspect the blade for signs of wear, damage, or missing carbide teeth. Check for cracks in the blade body or excessive runout.
- **Sharpening:** If the blade becomes dull, it can be professionally sharpened. Do not attempt to sharpen carbide teeth yourself unless you have specialized equipment and training.
- **Storage:** Store the blade in a dry, protected area to prevent rust and damage to the teeth. Use a blade case or hang it securely.
- **Replacement:** Replace the blade immediately if it is bent, cracked, has missing teeth, or shows significant damage.

7. Troubleshooting

Refer to the table below for common issues and their potential solutions:

Issue	Possible Cause	Solution
Poor cut quality / Rough edges	Dull blade, incorrect feed rate, blade wobble, improper clamping.	Inspect blade for sharpness; adjust feed rate; check blade installation; secure workpiece.
Excessive vibration / Noise	Loose blade, damaged blade, debris on arbor, incorrect blade for saw.	Ensure blade is securely tightened; inspect for damage; clean arbor; verify blade compatibility.
Blade binding / Kickback	Forcing the cut, workpiece not properly supported, dull blade, incorrect blade alignment.	Reduce feed rate; ensure workpiece is fully supported; inspect blade sharpness; check saw alignment.
Overheating blade	Excessive feed rate, dull blade, prolonged cutting without cooling, insufficient chip clearance.	Reduce feed rate; sharpen or replace blade; allow blade to cool; ensure saw's dust collection is effective.

8. Specifications

Specification	Detail
Model Number	DWA7760
Blade Diameter	5-1/2 inches (140 mm)
Number of Teeth	30
Arbor Size	20mm
Tooth Material	Carbide
Blade Material	Blend
Application	Aluminum Cutting
Maximum RPM	7000
Item Weight	175 g
Product Dimensions	19.99 x 1.27 x 22.2 cm

9. Warranty and Support

For information regarding warranty coverage, technical support, or service for your DEWALT DWA7760 Circular Saw Blade, please refer to the official DEWALT website or contact DEWALT customer service directly. Keep your purchase receipt as proof of purchase.

© 2023 DEWALT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00M0FK66Q

More documents and user manuals: **https://manuals.plus/**