

## Bel Air Lighting 248538

# Bel Air Lighting Pewter Ceiling Flush Mount Model 248538 Instruction Manual

Model: 248538 | Brand: Bel Air Lighting

## 1. INTRODUCTION

This manual provides comprehensive instructions for the safe installation, operation, and maintenance of your Bel Air Lighting Pewter Ceiling Flush Mount fixture, Model 248538. Please read all instructions carefully before beginning installation and retain this manual for future reference.

## 2. SAFETY INFORMATION

- **WARNING:** To avoid electric shock, ensure power is turned off at the circuit breaker or fuse box before installation, servicing, or changing bulbs.
- All electrical connections must be in accordance with local codes, ordinances, and the National Electric Code (NEC). If you are unfamiliar with proper electrical wiring connections, obtain the services of a qualified electrician.
- Do not install this fixture in wet locations. Suitable for dry or damp indoor locations only.
- Use only the specified bulb type and wattage to avoid fire or electrical hazard.
- Handle glass components with care to prevent breakage.

## 3. PACKAGE CONTENTS

Verify that all parts listed below are included in your package. If any parts are missing or damaged, contact customer service before proceeding with installation.

- Flush Mount Fixture Base (Brushed Nickel Finish)
- White Glass Shade
- Mounting Hardware Kit (screws, wire nuts, mounting bracket)
- 13 Watt CFL Bulb (GU24 base)



This image displays the retail packaging for the Bel Air Lighting Flush Mount Ceiling Fixture. The box highlights key features such as the brushed nickel finish and white glass, along with dimensions and bulb requirements.

## 4. TOOLS REQUIRED

---

The following tools are typically required for installation:

- Phillips Head Screwdriver
- Flat Head Screwdriver
- Wire Strippers
- Electrical Tape
- Step Ladder

## 5. SETUP AND INSTALLATION

---

Follow these steps to properly install your flush mount ceiling fixture:

1. **Turn Off Power:** Locate the circuit breaker or fuse box controlling the power to the installation location. Turn off the power completely.
2. **Prepare Mounting:** Remove the existing fixture (if any) and its mounting bracket. Attach the new mounting bracket (provided) to the electrical junction box using the screws provided. Ensure the bracket is securely fastened.
3. **Make Electrical Connections:** Carefully connect the fixture's wires to the house wiring. Use wire nuts (provided) to secure connections.
  - Connect the **black** fixture wire to the **black** (hot) house wire.
  - Connect the **white** fixture wire to the **white** (neutral) house wire.
  - Connect the **green or bare copper** fixture ground wire to the **green or bare copper** (ground) house wire.
4. **Secure Fixture Base:** Carefully tuck all wires into the junction box. Align the fixture base with the mounting bracket and secure it using the provided screws. Ensure the fixture is flush against the ceiling.
5. **Install Bulb:** Screw the provided 13-watt GU24 CFL bulb into the fixture socket. Do not overtighten.
6. **Attach Glass Shade:** Carefully place the white glass shade onto the fixture base and secure it according to the fixture's design (e.g., by twisting or using decorative nuts).
7. **Restore Power:** Once installation is complete and all components are secure, turn the power back on at the circuit

breaker or fuse box.

## 6. OPERATING INSTRUCTIONS

The Bel Air Lighting Flush Mount Fixture operates via a standard wall switch. Simply toggle the wall switch connected to the fixture to turn the light on or off.

## 7. MAINTENANCE

- **Cleaning:** To clean the fixture, ensure power is off. Wipe the brushed nickel finish with a soft, dry cloth. For the glass shade, use a mild glass cleaner and a soft cloth. Avoid abrasive cleaners or harsh chemicals.
- **Bulb Replacement:** Ensure power is off before replacing the bulb. Allow the bulb to cool completely. Unscrew the old GU24 CFL bulb and replace it with a new 13-watt GU24 CFL bulb. Do not exceed the maximum wattage of 13 watts.

## 8. TROUBLESHOOTING

- **Light does not turn on:**
  - Check that the power is on at the circuit breaker.
  - Ensure the bulb is securely screwed into the socket and is not burnt out.
  - Verify all electrical connections are secure.
- **Light flickers:**
  - Ensure the bulb is fully tightened.
  - Check for loose wire connections.
  - Replace the bulb if it is old or faulty.

## 9. SPECIFICATIONS

|                      |                                                |
|----------------------|------------------------------------------------|
| Brand                | Bel Air Lighting                               |
| Model Number         | 248538                                         |
| UPC                  | 736916550444                                   |
| Dimensions (Fixture) | 6.75 inches (diameter) x 5.375 inches (height) |
| Material             | Glass, Metal                                   |
| Finish               | Brushed Nickel                                 |
| Shade Material       | White Glass                                    |
| Light Source Type    | Fluorescent                                    |
| Bulb Requirement     | 1 x 13 Watt CFL (GU24 base)                    |
| Voltage              | 120 Volts                                      |
| Installation Type    | Flush Mount                                    |
| Power Source         | Hardwire                                       |

## 10. WARRANTY AND SUPPORT

Specific warranty information for the Bel Air Lighting Pewter Ceiling Flush Mount Model 248538 is not provided in this document. Please refer to the product packaging or contact Bel Air Lighting customer support directly for details regarding warranty coverage and technical assistance.

For further support, visit the official Bel Air Lighting website or contact their customer service department.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question