GRECO TH-15S

GRECO Wireless Transmitter Holder TH-15S User Manual

Model: TH-15S

1. Introduction

Thank you for purchasing the GRECO Wireless Transmitter Holder TH-15S. This holder is designed to securely attach small guitar wireless transmitters to your guitar strap, providing convenience and freedom of movement during performances or practice.

This manual provides essential information for the proper setup, operation, and maintenance of your TH-15S holder. Please read it thoroughly before use to ensure optimal performance and longevity of the product.

2. Product Overview

The TH-15S features a simple yet effective design, utilizing durable polyethylene for the base plate and flexible elastic bands with Velcro for secure attachment. It is engineered to accommodate various common small transmitter sizes while allowing easy access to controls and preventing antenna obstruction.



Figure 2.1: Components of the TH-15S holder, showing the base plate and the elastic band with Velcro.

This image displays the two main components of the Greco TH-15S Wireless Transmitter Holder: the rigid polyethylene base plate and the elastic strap with a Velcro closure. The base plate has slots for threading a guitar strap, and the elastic strap is designed to secure the wireless transmitter to the base plate.




Figure 2.2: Detailed dimensions of the TH-15S holder in millimeters.

This diagram illustrates the precise measurements of the TH-15S holder in millimeters. Key dimensions include the overall length of 110mm and width of 89mm, with specific measurements for the strap slots and the central area where the transmitter is held. This helps users verify compatibility with their guitar straps and transmitters.

Key Features:

- Designed for small guitar wireless transmitters.
- Attaches securely to guitar straps.
- Flexible elastic band accommodates various transmitter sizes.
- Simple construction with vertical and horizontal elastic bands.
- Allows easy access to transmitter switches and prevents antenna pressing.
- Durable polyethylene base plate.

- Includes two base plate sizes (large/small) for strap width compatibility.

3. Setup and Installation

Follow these steps to properly install your GRECO Wireless Transmitter Holder TH-15S onto your guitar strap and secure your wireless transmitter.

1. **Select Base Plate:** Choose the appropriate base plate (large or small) that best fits the width of your guitar strap. The base plate has slots designed for the strap to pass through.
2. **Thread Strap:** Carefully thread your guitar strap through the designated slots on the chosen base plate. Ensure the strap lies flat and is not twisted.




Figure 3.1: Front view of the TH-15S installed on a guitar strap with a transmitter.

This image shows the front view of the TH-15S holder attached to a guitar strap. The elastic band is visible, ready to secure a wireless transmitter. The strap is threaded through the top and bottom slots of the base plate.




Figure 3.2: Back view of the TH-15S installed on a guitar strap.

This image provides a view of the back of the TH-15S holder once it is installed on a guitar strap. It demonstrates how the strap passes through the base plate, ensuring a secure and stable attachment point for the transmitter.

3. **Insert Transmitter:** Place your wireless transmitter onto the base plate, positioning it centrally.
4. **Secure Transmitter:** Wrap the elastic band around your transmitter and secure it firmly using the Velcro closure. Ensure the transmitter is snug and does not move freely. The design allows for easy access to switches and prevents the antenna from being pressed.



Figure 3.3: The TH-15S holder with a wireless transmitter securely attached to a guitar strap.

This image shows the Greco TH-15S holder fully assembled with a wireless transmitter and attached to a guitar strap. It demonstrates the final appearance and how the elastic band holds the transmitter firmly in place, ready for use.

5. **Check Stability:** Gently tug on the transmitter to ensure it is securely fastened and will not dislodge during use.

Important Note: *Ensure the elastic band is not cut or excessively stretched, as this may compromise its ability to hold the transmitter securely. While compatible with many common small transmitters, some specialized transmitters may not fit perfectly. Always verify the fit before relying on the holder during performance.*

4. Operating Instructions

The GRECO TH-15S is a passive holder and does not require any power or complex operation. Its primary function is to provide a stable and accessible mounting point for your wireless transmitter.

- Once installed, ensure your wireless transmitter is powered on and functioning according to its own manufacturer's instructions.
- The holder's design allows for easy access to the transmitter's power switch and other controls without needing to remove it from the holder.
- The open design also ensures that the transmitter's antenna is not obstructed, maintaining optimal signal transmission.

5. Care and Maintenance

To ensure the longevity and continued performance of your GRECO Wireless Transmitter Holder TH-15S, follow these simple care and maintenance guidelines:

- **Cleaning:** Wipe the holder with a soft, damp cloth to remove dust or grime. Do not use harsh chemicals or abrasive cleaners, as they may damage the polyethylene or elastic material.
- **Storage:** Store the holder in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Elastic Band Inspection:** Regularly inspect the elastic band and Velcro for signs of wear, fraying, or loss of elasticity. If the band becomes loose or damaged, it may not securely hold your transmitter.
- **Avoid Overstretching:** Do not excessively stretch the elastic band beyond its intended capacity, as this can lead to premature wear or breakage.

6. Troubleshooting

This section addresses common issues you might encounter with your GRECO Wireless Transmitter Holder TH-15S.

Problem	Possible Cause	Solution
Transmitter feels loose in the holder.	Elastic band not tight enough or worn out. Transmitter size is too small for the holder.	Ensure the Velcro is securely fastened. If the band is worn, consider replacing the holder. Verify your transmitter's dimensions against the holder's capacity.
Guitar strap does not fit through the base plate slots.	Strap is too wide for the selected base plate.	Ensure you are using the correct base plate size (large or small) for your strap. Check your strap's width against the holder's specifications (Hole for straps: 3.1 x 2.3 inches (8 x 58 mm)).
Antenna is bent or pressed.	Transmitter is not positioned correctly.	Adjust the transmitter's position within the elastic band to ensure the antenna has clear space.

7. Specifications

Feature	Detail
Model Number	TH-15S
Material	Polyethylene (base plate), Elastic band with Velcro
Dimensions (Base Plate)	Approx. 4.3 x 3.5 inches (110 x 89 mm)
Strap Hole Dimensions	Approx. 3.1 x 2.3 inches (8 x 58 mm)
Weight	Approx. 40 g
Included	1 large base plate, 1 small base plate, Elastic band with Velcro

8. Warranty and Support

GRECO products are manufactured to high standards. For specific warranty information or technical support, please refer to the official GRECO website or contact your authorized dealer. Keep your purchase receipt as proof of purchase.

For general inquiries or assistance, you may also contact the seller, TOKYO TRENDS, through the Amazon platform

where the product was purchased.

Note: This product is a holder for electronic devices and does not contain electronic components itself. Warranty terms for the holder typically cover manufacturing defects.

© 2024 GRECO. All rights reserved.
This manual is subject to change without notice.