

[Manuals.plus](#) /

› [Wacom](#) /

› Wacom Intuos Creative Stylus 2 (CS600PK) User Manual

Wacom CS600PK

Wacom Intuos Creative Stylus 2 (CS600PK) User Manual

Model: CS600PK

1. INTRODUCTION

The Wacom Intuos Creative Stylus 2 is a digital pen designed to enhance your creative experience on compatible iPad devices. It offers pressure sensitivity and palm rejection technology, allowing for natural drawing, sketching, and painting. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your stylus.



2. COMPATIBILITY

The Wacom Intuos Creative Stylus 2 is compatible with the following Apple iPad models:

- iPad (3rd generation)
- iPad (4th generation)
- iPad Air (1st generation)
- iPad mini (1st generation)
- iPad mini 2
- iPad mini 3

Note: This stylus is NOT compatible with iPad 1, iPad 2, or iPad Air 2.

3. PACKAGE CONTENTS

Upon opening your Wacom Intuos Creative Stylus 2 package, you should find the following items:

- Wacom Intuos Creative Stylus 2
- Compact carrying case
- Standard Micro-USB charging cable
- Replacement nibs (typically 1-2)



Image 3.1: The stylus, its protective case, and the Micro-USB charging cable.

4. SETUP

4.1 Charging the Stylus

Before initial use, fully charge your stylus. Connect the included Micro-USB cable to the charging port on the stylus and to a USB power source. A full charge typically takes approximately 3 hours.



Image 4.1: The Micro-USB charging port located at the end of the stylus.

4.2 Pairing with Your iPad

The stylus connects to your iPad via Bluetooth. Follow these general steps:

1. Ensure Bluetooth is enabled on your iPad (Settings > Bluetooth).
2. Open a compatible creative application (e.g., Bamboo Paper, Procreate, Adobe Line/Sketch).
3. Within the application, navigate to its settings or stylus connection menu.
4. Activate the stylus by pressing its side button or following the app's specific pairing instructions. The app should detect and connect to the stylus.

Important:

- Stylus functionality, including pressure sensitivity and palm rejection, relies on specific app integration. Ensure your chosen app supports the Wacom Intuos Creative Stylus 2.
- For optimal performance, disable iPad's multi-touch gestures in Settings > General > Gestures (if applicable for your iPad model and iOS version).

5. OPERATING INSTRUCTIONS

5.1 Basic Operation

Once paired, the stylus functions as a precise input tool for your creative applications. The fine tip allows for detailed work, while pressure sensitivity enables varying line thickness and opacity based on how firmly you press the stylus against the screen.

5.2 Palm Rejection

The stylus features palm rejection technology, designed to ignore accidental touches from your hand resting on the iPad screen while you draw. This feature is dependent on the application's implementation.

5.3 Side Switch

The recessed side switch on the stylus can be programmed within compatible applications to perform various functions, such as undo, redo, or switching between tools (e.g., pen and eraser). Refer to your application's settings for customization options.

5.4 Compatible Applications

The Wacom Intuos Creative Stylus 2 is designed to work seamlessly with a range of creative applications. Some popular compatible apps include:

- Bamboo Paper
- Procreate
- Adobe Line and Sketch
- Autodesk Sketchbook
- Concepts




Image 5.1: Examples of creative applications that support the stylus.

6. MAINTENANCE

6.1 Cleaning

To clean your stylus, gently wipe it with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials, as these can damage the stylus finish or tip.

6.2 Nib Replacement

The stylus comes with spare nibs. If the tip becomes worn or damaged, carefully pull out the old nib and insert a new one. Ensure the new nib is fully seated.

6.3 Storage

When not in use, store the stylus in its compact carrying case to protect it from damage and dust. This also helps prevent accidental activation and preserves battery life.

7. TROUBLESHOOTING

If you encounter issues with your Wacom Intuos Creative Stylus 2, consider the following:

- **Stylus not connecting or recognized:**

- Ensure the stylus is charged.
 - Verify Bluetooth is active on your iPad.
 - Confirm the creative app you are using supports the stylus and that stylus support is enabled within the app's settings.
 - Try re-pairing the stylus by disconnecting and reconnecting it within the app or iPad's Bluetooth settings.
 - Close all other applications running in the background on your iPad.
- **Inaccurate drawing or offset lines:**
 - This can sometimes be due to the iPad's capacitive touch technology. Some apps allow for calibration or offset adjustments.
 - Ensure your iPad's multi-touch gestures are disabled.
 - The accuracy can vary with your drawing style and the angle at which you hold the stylus. Experiment to find a comfortable and accurate position.
 - If drawing diagonal lines results in waviness, this is often a limitation of the iPad's screen technology. Drawing more quickly and confidently can sometimes mitigate this.
- **Lag in drawing:**
 - Lag can be influenced by the app, iPad processing power, and other background tasks. Close unnecessary apps.
 - Ensure your iPad's operating system and the creative application are updated to their latest versions.
- **Palm rejection not working effectively:**
 - Palm rejection is app-dependent. Check the app's settings for palm rejection options.
 - Consider using a drawing glove if persistent issues occur.
- **Stylus not responding:**
 - Check battery level.
 - Ensure the nib is properly seated.

8. SPECIFICATIONS

Feature	Detail
Model Number	CS600PK
Color	Grey
Stylus Material	High-quality plastic and metal
Case Material	Canvas
Item Dimensions (L x W x H)	5.55 x 0.55 x 0.39 inches
Item Weight	0.04 Pounds
Battery Type	1 Lithium Ion (included)

Charging Time	3 Hours
Connectivity	Bluetooth

9. WARRANTY INFORMATION

The Wacom Intuos Creative Stylus 2 (CS600PK) comes with a **2-year manufacturer's warranty**. Please retain your proof of purchase for warranty claims. For detailed terms and conditions, refer to the warranty documentation included with your product or visit the official Wacom website.

10. SUPPORT

For further assistance, technical support, or to explore additional Wacom products and resources, please visit the official Wacom Store or contact Wacom customer service.

Wacom Store: [Visit the Wacom Store on Amazon](#)