

Coaster Fine Furniture 460182

Coaster Fine Furniture Cooper Twin and Full Bunk Bed

INSTRUCTION MANUAL

1. INTRODUCTION

Thank you for purchasing the Coaster Fine Furniture Cooper Twin and Full Bunk Bed. This manual provides important information regarding the assembly, safe operation, and maintenance of your new bunk bed. Please read these instructions carefully before assembly and retain them for future reference.

2. SAFETY INFORMATION

Your safety and the safety of others are paramount. Please adhere to all warnings and instructions to prevent injury or damage.

- **Adult Assembly Required:** This product must be assembled by adults.
- **Weight Capacity:** The top bunk has a maximum weight capacity of 200 pounds. The bottom bunk has a maximum weight capacity of 400 pounds. Do not exceed these limits.
- **Top Bunk Age Restriction:** The top bunk is not suitable for children under 6 years of age.
- **Guard Rails:** Always use the guard rails on the top bunk. Ensure they are properly installed and secured.
- **Ladder Safety:** Use the ladder for entry and exit from the top bunk. Do not use the bed as a climbing frame.
- **Mattress Size:** Use only mattresses that are 74-75 inches long and 37.5-38.5 inches wide for the twin (top) bunk, and 74-75 inches long and 53-54 inches wide for the full (bottom) bunk. The maximum mattress thickness for the top bunk should not exceed 6 inches to ensure adequate guard rail height.
- **No Jumping:** Do not allow jumping on the bed.
- **Ventilation:** Ensure adequate ventilation around the bed.
- **Regular Inspection:** Periodically check all fasteners and connections to ensure they are tight and secure.

3. PACKAGE CONTENTS

Before beginning assembly, ensure all parts are present and undamaged. If any parts are missing or damaged, do not proceed with assembly. Contact customer support for assistance.

- Headboards and Footboards (Twin and Full)
- Side Rails (Twin and Full)
- Bed Slats
- Ladder
- Guard Rails
- Storage Drawers (2 units)
- Hardware Pack (screws, bolts, nuts, washers, Allen wrench)
- Assembly Instructions

4. SETUP AND ASSEMBLY

Assembly requires two adults. Clear a spacious area for assembly. Do not use power tools for assembly as over-tightening may damage the wood.

1. **Unpack Components:** Carefully remove all components from the packaging. Place them on a soft, clean surface to prevent scratches.
2. **Assemble Bottom Bed Frame:** Attach the full-size side rails to the full-size headboard and footboard using the provided hardware. Ensure all connections are secure but do not fully tighten until the frame is complete.
3. **Install Bottom Bed Slats:** Place the full-size bed slats evenly across the bottom bed frame and secure them according to the instructions.
4. **Assemble Top Bed Frame:** Attach the twin-size side rails to the twin-size headboard and footboard.
5. **Install Top Bed Slats:** Place the twin-size bed slats evenly across the top bed frame and secure them.
6. **Attach Top Bunk to Bottom Bunk:** Carefully lift the assembled top bunk and align its support posts with the designated connection points on the bottom bunk. Secure with the provided hardware. This step requires two adults.
7. **Install Guard Rails:** Attach the guard rails to the top bunk, ensuring they are firmly secured on both sides.
8. **Attach Ladder:** Secure the ladder to the designated hooks or attachment points on the side rail of the top bunk.
9. **Assemble Storage Drawers:** Follow the separate instructions for assembling the two storage drawers. Once assembled, slide them under the bottom bunk.
10. **Final Tightening:** Once the entire bed structure is assembled, go back and securely tighten all bolts and screws. Do not overtighten.



Image 1: Fully assembled Coaster Cooper Twin and Full Bunk Bed, showcasing the grey finish, integrated ladder, safety rails, and two under-bed storage drawers.



Image 2: Another view of the Coaster Cooper Bunk Bed, emphasizing the robust wooden construction and the accessibility of the storage drawers.

5. OPERATING INSTRUCTIONS

Once assembled, the bunk bed is ready for use. Follow these guidelines for safe operation:

- **Accessing Top Bunk:** Always use the attached ladder to access or exit the top bunk. Do not climb on the side rails or other parts of the bed.
- **Storage Drawers:** The two integrated storage drawers are designed for light items such as bedding, clothes, or

toys. Avoid overloading them to ensure smooth operation and prevent damage.

- **Weight Distribution:** Distribute weight evenly on both bunks. Avoid concentrating weight in one small area.
- **Ventilation:** Ensure the area around the bed is well-ventilated, especially if using the storage drawers frequently.

6. MAINTENANCE

Proper maintenance will extend the life of your bunk bed.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the finish. For specific product care instructions, refer to the product description or store page.
- **Hardware Check:** Periodically (e.g., every 3-6 months) check all bolts, screws, and connections. Tighten any loose hardware to maintain stability and safety.
- **Structural Integrity:** Inspect the wooden frame for any signs of cracks, splinters, or damage. Address any issues promptly to prevent further deterioration.
- **Drawer Maintenance:** Keep the drawer tracks clean and free of debris to ensure smooth operation.

7. TROUBLESHOOTING

If you encounter any issues with your bunk bed, refer to the following common problems and solutions:

- **Squeaking Noises:** Squeaking often indicates loose hardware. Re-tighten all bolts and screws, paying close attention to the frame connections.
- **Wobbly Frame:** A wobbly frame is usually due to uneven tightening during assembly or loose hardware. Ensure all connections are fully tightened and the bed is on a level surface.
- **Drawers Sticking:** Check the drawer tracks for any obstructions or debris. Ensure the drawers are properly aligned on their runners.
- **Ladder Feels Unstable:** Verify that the ladder is securely attached to the bunk bed frame. Tighten any fasteners connecting the ladder.

If problems persist, contact customer support for further assistance.

8. SPECIFICATIONS

Model Number	460182
Brand	Coaster Fine Furniture
Style	Contemporary
Size	Twin over Full
Color	Grey
Frame Material	Wood

Special Feature	With Storage Drawers
Item Dimensions (L x W x H)	77.5" x 58.25" x 65"
Item Weight	202 Pounds
Maximum Weight Recommendation (Top Bunk)	200 Pounds
Maximum Weight Recommendation (Bottom Bunk)	400 Pounds
Required Assembly	Yes

9. WARRANTY INFORMATION

This product comes with a Limited Warranty. For detailed information regarding the terms and conditions of your warranty, including coverage and duration, please refer to the product description on the store page or contact Coaster Fine Furniture customer service directly.

10. SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Coaster Fine Furniture customer support. Have your model number (460182) and purchase information ready when you call.

For the most current contact information, please visit the official Coaster Fine Furniture website or refer to your purchase documentation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question