

Dogtra iQ Plus 2-Dog Remote Trainer

Dogtra iQ Plus 2-Dog Remote Trainer User Manual

Model: iQ Plus 2-Dog Remote Trainer

INTRODUCTION

The Dogtra iQ Plus 2-Dog Remote Trainer is designed to assist in training dogs weighing 10 pounds and up. This compact electronic training collar system provides a range of up to 400 yards and offers precise stimulation levels, along with a non-stimulating pager function. It is suitable for dogs with mild temperaments and is built with fully waterproof receiver collars and a water-resistant transmitter.

SAFETY INFORMATION

- This device is intended for dog training purposes only. Do not use on aggressive dogs.
- Read all instructions before using the product.
- Ensure proper fit of the receiver collar to prevent skin irritation. Do not leave the collar on the dog for more than 8-10 hours per day.
- Regularly check the contact points for signs of irritation or sores. If irritation occurs, discontinue use until the skin heals.
- Keep out of reach of children.
- Do not attempt to disassemble or repair the unit yourself. Contact Dogtra for service.

PACKAGE CONTENTS

Verify that all items are present in your package:

- Transmitter
- Two Receiver Collars
- Detachable Strap
- Battery Charger and Splitter Cable
- Owner's Manual (this document)

Transmitter



The handheld remote control unit. It features buttons for stimulation, a dial for intensity levels, and a switch to select between the two receiver collars. The image shows the compact design of the transmitter alongside the two receiver collars.

- **Stimulation Dial:** Adjusts the intensity level from 0 to 100.
- **Nick Button:** Delivers a single, quick stimulation pulse.
- **Constant Button:** Delivers continuous stimulation for up to 12 seconds.
- **Pager Button:** Activates a non-stimulating vibration.
- **Dog Selector Switch:** Toggles between Dog 1 and Dog 2.
- **LED Battery Indicator:** Shows battery life status.

Receiver Collar



The compact unit worn by the dog, containing the contact points and receiving signals from the transmitter. The image displays the receiver collar attached to a strap, highlighting its small size suitable for various dog breeds.

- **Contact Points:** Deliver stimulation to the dog's skin.
- **Charging Port:** For connecting the battery charger.
- **On/Off Button:** Powers the receiver on or off.
- **LED Indicator Light:** Shows power status and charging status.

SETUP

1. Charging the Unit

Before first use, fully charge the transmitter and both receiver collars for 2 hours. The units utilize a 2-hour quick charge lithium polymer battery.

1. Connect the charger to a standard wall outlet.
2. Attach the splitter cable to the charger, then connect the charging clips to the charging ports on the transmitter and both receiver collars.
3. The LED indicator on the units will glow red during charging and turn green when fully charged.
4. Disconnect the charger once charging is complete.

2. Fitting the Receiver Collar

Proper fit is essential for consistent and effective stimulation. The contact points must make direct contact with the dog's skin.

1. Position the receiver collar high on your dog's neck, just below the ears.
2. Ensure the contact points are pressing firmly against the skin. You should be able to fit two fingers snugly under the strap.
3. If the collar is too loose, the stimulation may be inconsistent or ineffective. If it's too tight, it can cause skin irritation.
4. Trim any long hair around the contact points if necessary to ensure good skin contact.

OPERATING THE TRANSMITTER

Turning On/Off

- **Transmitter:** Press and hold the On/Off button until the LED indicator lights up. To turn off, press and hold until the LED turns off.
- **Receiver Collars:** Press and hold the On/Off button on each receiver until the LED indicator lights up. To turn off, press and hold until the LED turns off.

Selecting a Dog

Use the Dog Selector Switch on the transmitter to choose which receiver collar you wish to control (Dog 1 or Dog 2).

Adjusting Stimulation Level

The stimulation dial allows you to select an intensity level from 0 (no stimulation) to 100 (maximum stimulation). Start at the lowest level and gradually increase until your dog responds with a slight head turn or ear twitch.

Stimulation Modes

- **Nick:** Press the Nick button for a single, brief pulse of stimulation. This is typically used for immediate corrections.
- **Constant:** Press and hold the Constant button for continuous stimulation, up to a maximum of 12 seconds. Release the button to stop the stimulation. Use for more persistent behaviors.
- **Pager:** Press the Pager button to activate a non-stimulating vibration on the receiver collar. This can be used as a warning or for mild corrections.

MAINTENANCE

- **Cleaning:** Wipe the units with a damp cloth. Do not use harsh chemicals.
- **Battery Care:** For optimal battery life, avoid fully discharging the batteries. Recharge when the LED indicator shows low battery. If storing for extended periods, charge the units every 3-4 months.
- **Contact Points:** Regularly inspect the contact points and the dog's neck area for any signs of irritation.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit not turning on	Low battery; Unit not fully charged	Charge the unit for 2 hours. Ensure charger is properly connected.

Problem	Possible Cause	Solution
No stimulation/pager	Receiver collar not on; Low battery; Improper fit; Stimulation level too low	Ensure receiver is on. Charge units. Adjust collar for proper contact. Increase stimulation level gradually.
Dog shows no response	Stimulation level too low; Improper collar fit; Dog's temperament	Increase stimulation level. Adjust collar for snug fit. Consider professional training advice if dog is unresponsive.
Reduced range	Obstacles (hills, buildings); Electromagnetic interference; Low battery	Move to an open area. Avoid areas with strong electromagnetic fields. Charge units.

SPECIFICATIONS

- **Model:** Dogtra iQ Plus 2-Dog Remote Trainer
- **Dog Size:** For dogs 10 lbs and up
- **Range:** 400 yards
- **Stimulation Levels:** 0-100 (precise)
- **Stimulation Types:** Nick, Constant, Pager (non-stimulating vibration)
- **Battery:** 2-hour quick charge Lithium Polymer
- **Waterproof:** Receiver collars are fully waterproof; Transmitter is water-resistant
- **Item Weight:** 1.6 pounds (total package weight)
- **Product Dimensions:** 14.7 x 6.8 x 2.5 inches (package dimensions)

WARRANTY AND SUPPORT

Specific warranty details are not provided in this manual. For information regarding warranty coverage, product support, or service, please contact Dogtra directly through their official website or customer service channels. Keep your purchase receipt as proof of purchase.

Manufacturer: Dogtra

Website: [Visit the Dogtra Store on Amazon](#) (for general brand information)