

[Manuals.plus](#) /

› [Kastar](#) /

› Kastar 19V 3.16A 60W Laptop AC Adapter Charger User Manual

Kastar 19V316A-5530-1

Kastar 19V 3.16A 60W Laptop AC Adapter Charger

Model: 19V316A-5530-1

Brand: Kastar

INTRODUCTION

This manual provides essential information for the safe and effective use of your Kastar 19V 3.16A 60W Laptop AC Adapter Charger. Please read these instructions carefully before use and retain them for future reference.

The Kastar AC Adapter is designed to provide reliable power for a wide range of compatible Samsung laptops. It delivers a stable DC output of 19V 3.16A (60W) and accepts a universal AC input of 100-240V ~ 1.6A 50/60Hz, making it suitable for use in various regions.



Image: The Kastar 19V 3.16A 60W Laptop AC Adapter Charger with its included power cord.

PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x Kastar AC Adapter
- 1 x 3-Prong extended Power Cord



Image: A high-quality 3-prong power cord, designed for safe and reliable power delivery.

SETUP INSTRUCTIONS

Follow these steps to connect your AC adapter to your laptop:

1. Connect the 3-prong power cord to the AC adapter. Ensure a firm connection.
2. Plug the 3-prong power cord into a standard wall electrical outlet.
3. Connect the DC output connector of the AC adapter to the power input port on your Samsung laptop.

HIGH QUALITY 3-Prong Power Cord




Image: A detailed diagram illustrating the dimensions of the DC output connector: 3.0mm internal diameter and 5.5mm external diameter.

OPERATING INSTRUCTIONS

Once connected, your laptop should automatically begin charging. Observe the charging indicator light on your laptop to confirm it is receiving power. The adapter is designed for continuous use.

WARNING: The power adapter may become warm during operation. Ensure adequate ventilation and do not cover the adapter. Keep it away from your body during prolonged use to prevent discomfort or burns.

Video: An overview of a 60W 19V 3.15A laptop charger for Samsung laptops, demonstrating its features and use.

COMPATIBILITY

This Kastar AC Adapter is compatible with numerous Samsung laptop models. Please verify your laptop's power requirements and connector size before use.

Compatible Samsung Series:

- **Series 2:** NP200B4A, NP200A5B
- **Series 3:** NP300E4C, NP300E4E, NP300E5A, NP300E5AI, NP300E5C, NP300E5E, NP300V5A, NP305E5A, NP305E5AI, NP305E7A, NP305E7AI, NP305V5A, NP350U2A, NP350U2B, NP350V5C, NP355E5C, NP355V5C, NP365E5C
- **Specific Series 3 Models:** NP300E4C-A02US, NP300E4C-A03US, NP305E5A-A01US, NP300E5A-A02UB, NP300E5A-A05US, NP300E5C-A01UB, NP300E5C-A02US, NP300E5C-A03US, NP300E5C-A06US, NP300E5C-A07US, NP300E5C-A09US, NP300E5C-A0AUS, NP300E5C-A0BUS, NP300E5C-A0CUS, NP300E5E-A01US, NP300E5E-A02US, NP305E5A-A03US, NP305E5A-A05US, NP305E5A-A07US, NP305E5A-A08US, NP305E7A-A02US, NP305V5A-A0CUS, NP350V5C-A01US, NP350V5C-T01US, NP350U2A-W01UB, NP355E5C-A01US, NP365E5C-S01US, NP365E5C-S03US, NP365E5C-S05US
- **Series 4:** NP400B2B, NP400B4B
- **Series 5:** NP500P4C, NP510R5E, NP520U4C, NP530U4C, NP530U4B, NP535U4C
- **Specific Series 5 Models:** NP500P4C-S02US, NP510R5E-A01UB, NP510R5E-A02UB, NP520U4C-A01UB, NP530U4B-A01US, NP530U4C-A01US, NP535U4C-A01US
- **Series 6:** NP600B4B, NP600B5B
- **Series 7 Chronos:** NP700Z3A, NP700Z3AH (e.g., NP700Z3A-S06US, NP700Z3A-S07US)
- **7 Spin:** NP740U3L, NP740U5L
- **ATIV Book 2:** NP270E4E, NP270E5E, NP270E5G (e.g., NP270E5G-K02JM, NP270E5J-K01US)
- **ATIV Book 4:** NP470R5E (e.g., NP470R5E-K01UB, NP470R5E-K02UB)
- **Other Compatible Models:** Q330, Q430, Q530, QX410, QX411, R430, R440, R480, R519, R522, R530, R540, R580, R730, R780, RC512, RV510, RV511, RV515, RV520, RV711, RV720, SF310, SF410, SF510, X360, X460
- **Part Numbers:** CPA09-004A, AD-6019R, ADP-60ZH, BA44-00242A, AA-PA2N40W

SPECIFICATIONS

Brand	Kastar
Model Number	19V316A-5530-1
DC Output	19V 3.16A (60W)
AC Input	100-240V ~ 1.6A 50/60Hz
DC Connector Size	Internal Diameter: 3.0mm, External Diameter: 5.5mm
Item Weight	12 ounces
Product Dimensions (LxWxH)	7.4 x 4.7 x 2 inches
Power Source	Corded Electric

MAINTENANCE

To ensure the longevity and optimal performance of your AC adapter, follow these maintenance guidelines:

- Keep the adapter in a dry environment. Avoid exposure to moisture or liquids.
- Prevent the adapter from falling or being subjected to strong impacts.

- Do not cover the adapter during use to allow for proper heat dissipation.
- Regularly inspect the power cord and adapter for any signs of damage, such as frayed wires or cracks. Discontinue use if damage is found.
- Clean the adapter and connectors with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.

TROUBLESHOOTING

If you encounter issues with your AC adapter, consider the following:

- **No Power:** Ensure the power cord is securely connected to both the adapter and the wall outlet. Verify the wall outlet is functional by testing it with another device.
- **Laptop Not Charging:** Check that the DC connector is fully inserted into your laptop's power port. Confirm that the adapter's specifications (voltage and amperage) match your laptop's requirements.
- **Adapter Overheating:** Ensure the adapter is in a well-ventilated area and not covered. If overheating persists, discontinue use and contact support.
- **Loose Connection:** If the connection feels loose, ensure the correct DC connector size is being used for your laptop.

WARRANTY AND SUPPORT

Kastar offers a warranty and support policy for its electronic products. Please note the following conditions:

Warranty Coverage:

- **Within 7 days of purchase:** For specified product performance failures, you may be eligible for a full refund, replacement, or free repair.
- **Within 15 days of purchase:** For specified product performance failures, you may choose repair or replacement.
- **Over 15 days of purchase:** Free repair service is available for specified product performance failures.

Situations Not Covered by Free Maintenance:

- Inability to provide the purchase record and order number.
- Product exceeding its time limit for use.
- Damage caused by improper use, maintenance, or storage not in accordance with the instruction manual, or if the customer does not have a computer working environment. Customers may opt for paid maintenance services in these cases.
- Product damage due to falls, water immersion, or improper storage after purchase.
- Damage caused by human factors, irresistible natural disasters, abnormal voltage, or other external factors.
- Repairs performed at non-designated repair authorization points, unauthorized transformations, disassembly, or cleaning of products resulting in damage.

For technical support or warranty claims, please contact Kastar customer service with your purchase details.

IMPORTANT SAFETY INFORMATION

- This product is for indoor use only.
- Keep the adapter in a dry environment.
- To prevent electric shock, do not disassemble the adapter without authorization.

- Ensure the adapter is placed on a hard, flat surface to prevent it from falling.
- Only applicable to information technology equipment.



Image: The Kastar product packaging box, featuring a message encouraging customer feedback for product improvement.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B00MP4XJIO>

More documents and user manuals: <https://manuals.plus/>