

DELSEY PARIS 00207180111

DELSEY PARIS Titanium Hardside Expandable Carry-On Luggage

MODEL: 00207180111

Instruction Manual

1. Introduction

Thank you for choosing the DELSEY PARIS Titanium Hardside Expandable Carry-On Luggage. This manual provides essential information for the proper use, care, and maintenance of your new luggage. Designed for durability and convenience, this carry-on is built to resist impact and offers smart organization for your travels.

2. Key Features

- **Lightweight and Durable Polycarbonate Shell:** Extremely resilient to cracking or breaking, ensuring longevity.
- **Integrated Padded Laptop Sleeve:** Securely holds up to a 15.6-inch laptop in the front pocket.
- **Four Double Spinner Wheels:** Provides a stable base with multi-directional rolling, allowing for effortless 360-degree movement with zero weight on your hand.
- **Integrated 3-Dial TSA Approved Combination Lock:** Enhances security for your belongings.
- **Expandable Design:** Suitcase expands up to 2 inches for additional packing space.
- **Organized Interior:** Two large fully-lined packing compartments with a zippered divider, web straps, and zippered mesh pockets for delicate items and accessories.
- **Recessed "One-Button" Locking Handle:** Offers great maneuverability and comfortable grip.
- **Soft-Touch Top and Side Carry Handles:** For comfortable lifting and carrying.

3. Setup

Upon receiving your DELSEY PARIS luggage, inspect it for any signs of damage. Remove all packaging materials and tags. Familiarize yourself with the various features before your first trip.

3.1 Setting the TSA Combination Lock

1. The lock is preset to 0-0-0.
2. Locate the small reset button (usually recessed and requires a pen tip to press).
3. Press the reset button until you hear a click.
4. Set your desired 3-digit combination by turning the dials.
5. Push the release button (or slide the shackle release) firmly until you hear a click. This sets your new combination.
6. Test your new combination to ensure it works correctly. Remember your combination as DELSEY PARIS cannot provide it.



Figure 1: Integrated 3-dial TSA approved combination lock.

Text Description: This image shows a close-up of the luggage's side, highlighting the integrated 3-dial TSA approved combination lock. The lock features three numerical dials and a keyhole for TSA access. The zipper pullers are designed to securely clip into the lock mechanism.

4. Operating Instructions

4.1 Using the Telescopic Handle

To extend the telescopic handle, press the button located on the top of the handle and pull upwards. Release the button at your desired height. To retract, press the button and push the handle downwards until it is fully recessed.

4.2 Maneuvering with Spinner Wheels

Your luggage is equipped with four double spinner wheels, allowing for smooth 360-degree rotation. This enables you to push, pull, or roll the luggage alongside you with minimal effort, reducing strain on your arm and shoulder.



Figure 2: Double spinner wheel for smooth mobility.

Text Description: This image provides a close-up view of one of the luggage's double spinner wheels. The wheel is black with a silver hub featuring the 'DELSEY' logo, designed for robust and multi-directional movement.

4.3 Utilizing the Expansion Feature

For additional packing capacity, locate the expansion zipper running along the perimeter of the luggage. Unzip this section to expand the suitcase by up to 2 inches. Zip it back up when the extra space is no longer needed or to meet airline size restrictions.

4.4 Packing and Organization

The interior of your luggage is designed for efficient packing:

- **Main Compartments:** Two large, fully-lined compartments allow for organized separation of your belongings.
- **Zippered Divider:** A central zippered divider helps keep contents secure and wrinkle-free.
- **Web Straps:** Adjustable web straps in one compartment compress clothing and prevent shifting during transit.
- **Zippered Mesh Pockets:** Ideal for storing smaller items, toiletries, or delicate garments.

- **Front Pocket with Laptop Sleeve:** The exterior front pocket features an integrated padded sleeve for a 15.6-inch laptop and two zippered mesh pockets for quick access to essentials.



Figure 3: Organized interior with packing straps and zippered divider.

Text Description: This image displays the interior of the open luggage. It shows two main packing compartments. One side features adjustable criss-cross packing straps to secure clothing, while the other side has a zippered divider with additional mesh pockets for smaller items.

5. Maintenance

To ensure the longevity of your DELSEY PARIS luggage, follow these maintenance tips:

- **Cleaning the Exterior:** Wipe the polycarbonate shell with a soft, damp cloth and mild soap. Avoid abrasive cleaners that may scratch the surface.
- **Cleaning the Interior:** The interior lining can be spot cleaned with a damp cloth and mild detergent. Allow to air dry completely before closing.

- **Wheel Maintenance:** Regularly check the spinner wheels for debris. Clean them with a brush or cloth to ensure smooth rolling. Avoid excessive force or impact on the wheels.
- **Zipper Care:** Keep zippers clean and free of obstructions. If a zipper becomes stiff, apply a small amount of zipper lubricant or wax.
- **Storage:** Store your luggage in a cool, dry place away from direct sunlight when not in use.

6. Troubleshooting

If you encounter any issues with your luggage, consider the following:

- **Stuck Telescopic Handle:** Ensure no items are obstructing the handle mechanism inside the lining. Apply gentle, even pressure when extending or retracting.
- **Stiff Wheels:** Clean wheels thoroughly to remove any trapped dirt or debris. If the issue persists, contact customer support.
- **Zipper Malfunction:** Check for fabric caught in the zipper teeth. Gently pull the fabric free. If the zipper is damaged, professional repair may be needed.
- **Lock Issues:** Double-check your combination. If the lock is jammed or you've forgotten the combination, refer to the lock's specific instructions or contact customer support.

7. Specifications

Specification	Detail
Product Dimensions	19 x 13 x 9.75 inches
Item Weight	7.9 pounds
Capacity	41 Liters
Item Model Number	00207180111
Material	Polycarbonate
Wheels	Four Double Spinner Wheels
Lock Type	Integrated 3-Dial TSA Approved Combination Lock

8. Official Product Videos

DELSEY Paris Titanium Hardside Expandable Luggage

Your browser does not support the video tag.

Text Description: This video, provided by Delsey Paris Luggage, showcases the DELSEY Paris Titanium Hardside Expandable Luggage, highlighting its key features and design.

9. Warranty and Support

For warranty information, product registration, or further support, please visit the official DELSEY PARIS website or contact their customer service. Keep your purchase receipt as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question