

Pyramis 095201001

Pyramis Festivo 095201001 Kitchen Sink Faucet with Pull-Out Spout - Instruction Manual

Model: 095201001 | Brand: Pyramis

[Introduction](#) [Safety Information](#) [Package Contents](#) [Setup & Installation](#) [Operating Instructions](#)
[Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Pyramis Festivo 095201001 kitchen sink faucet. Please read this manual thoroughly before installation and use to ensure proper function and longevity of your product. Keep this manual for future reference.

2. SAFETY INFORMATION

- Always turn off the main water supply before beginning any installation or maintenance work.
- Ensure all connections are secure to prevent leaks.
- If you are unsure about any part of the installation process, consult a qualified plumber.
- Do not use abrasive cleaners or harsh chemicals on the faucet's chrome finish, as this may cause damage.
- Keep small parts out of reach of children.

3. PACKAGE CONTENTS

Verify that all components are present before starting the installation:

- 1 x Pyramis Festivo 095201001 Chrome Kitchen Sink Faucet with Pull-Out Spout
- Mounting Kit
- User Guide

4. SETUP & INSTALLATION

This faucet is designed for deck mounting. Follow these general steps for installation. Specific details may vary based on your sink and countertop configuration.

4.1 Required Tools (Not Included)

- Adjustable wrench
- Screwdriver
- Plumber's putty or silicone sealant
- Drill (if creating a new mounting hole)

4.2 Installation Steps

1. **Prepare the Sink:** Ensure the mounting hole on your sink or countertop is clean and has a diameter between \varnothing 35 mm and \varnothing 42 mm.
2. **Install the Faucet:** Insert the faucet body into the mounting hole. Ensure the base gasket is properly seated.
3. **Secure the Faucet:** From underneath the sink, attach the mounting hardware (washer, nut) to the faucet shank. Tighten securely with an adjustable wrench.
4. **Connect Water Lines:** Connect the hot and cold water supply lines to the corresponding inlets on the faucet. Ensure connections are tight but do not overtighten.
5. **Connect Pull-Out Spout Hose:** Connect the pull-out spout hose to the designated connection point under the faucet. Attach the counterweight to the hose as instructed in the mounting kit to ensure smooth retraction.
6. **Test for Leaks:** Slowly turn on the main water supply and check all connections for leaks. Run water through the faucet for a few minutes to flush out any debris.

4.3 Dimensional Drawing




Image Description: A technical line drawing illustrating the dimensions of the Pyramis Festivo 095201001 kitchen faucet. Key dimensions include:

Total faucet height: 185 mm

Height to spout outlet: 134 mm

Spout reach: 205 mm

Mounting hole diameter: Ø 35-42 mm

Base diameter: Ø 54.6 mm

Maximum countertop thickness: 49.4 mm These measurements are crucial for proper installation and fit.

5. OPERATING INSTRUCTIONS

5.1 Water Flow and Temperature Control

The Pyramis Festivo 095201001 faucet features a single handle for controlling both water flow and temperature.

- **To Turn On/Off:** Lift the handle upwards to start the water flow and push it downwards to stop.
- **To Adjust Temperature:** Move the handle to the left for hot water and to the right for cold water. The further you move it, the hotter or colder the water will be.
- **To Adjust Flow:** The height to which you lift the handle controls the water flow rate.

5.2 Using the Pull-Out Spout

The pull-out spout provides extended reach and flexibility for various kitchen tasks.

- **To Extend:** Gently pull the spout head away from the main faucet body. The hose will extend, allowing you to direct water where needed.
- **To Retract:** Once finished, guide the spout head back towards the main faucet body. The counterweight on the hose will assist in smooth retraction and docking.

6. MAINTENANCE

6.1 Cleaning the Faucet

To maintain the chrome finish of your Pyramis Festivo faucet, follow these cleaning guidelines:

- Use a soft cloth and mild soap or a non-abrasive liquid cleaner specifically designed for chrome finishes.
- Wipe the faucet gently to remove water spots and grime.
- Rinse thoroughly with clean water and dry with a soft cloth to prevent water spots.
- **Do not use:** Abrasive cleaners, scouring pads, ammonia-based cleaners, bleach, or any acidic or harsh chemical cleaners, as these can damage the finish.

6.2 Aerator Cleaning

Periodically, mineral deposits can build up in the aerator, affecting water flow. To clean:

1. Unscrew the aerator from the tip of the spout (you may need a wrench or aerator key).
2. Disassemble the aerator components.
3. Rinse all parts under running water and gently scrub away any mineral deposits with a soft brush. For stubborn deposits, soak in a solution of equal parts white vinegar and water.
4. Reassemble the aerator and screw it back onto the spout.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Low Water Flow	<ul style="list-style-type: none"> • Clogged aerator • Partially closed shut-off valve • Debris in water lines 	<ul style="list-style-type: none"> • Clean the aerator (see Section 6.2). • Ensure hot and cold water shut-off valves are fully open. • Flush water lines.
Leaks from Faucet Base	<ul style="list-style-type: none"> • Loose mounting nut • Damaged O-rings or gaskets 	<ul style="list-style-type: none"> • Tighten the mounting nut under the sink. • Inspect and replace O-rings or gaskets if damaged.
Leaks from Spout	<ul style="list-style-type: none"> • Worn cartridge 	<ul style="list-style-type: none"> • Replace the faucet cartridge.

Problem	Possible Cause	Solution
Pull-Out Spout Does Not Retract Smoothly	<ul style="list-style-type: none"> Counterweight improperly positioned or missing Hose obstructed 	<ul style="list-style-type: none"> Check and adjust the position of the counterweight on the hose. Ensure the hose is not tangled or obstructed by items under the sink.

8. SPECIFICATIONS

Feature	Detail
Model Number	095201001
Brand	Pyramis
Color	Grey
Finish Type	Chrome
Faucet Type	Kitchen Sink Faucet with Pull-Out Spout
Mounting Type	Deck Mount
Number of Handles	1
Total Faucet Height	185 mm
Height to Spout Outlet	134 mm
Spout Reach	205 mm
Mounting Hole Diameter	Ø 35 - Ø 42 mm
Product Dimensions (L x W x H)	22 x 20 x 5 cm
Item Weight	1.9 kilograms
Components Included	Faucet, Mounting Kit, User Guide

9. WARRANTY & SUPPORT

Pyramis products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your product or visit the official Pyramis website.

For technical support, replacement parts, or any questions not covered in this manual, please contact Pyramis customer service through their official channels.

