Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Munchkin /
- Munchkin Miracle 360 Sippy Cup (Model 47022) Instruction Manual

Munchkin 47022

Munchkin Miracle 360 Sippy Cup Instruction Manual

Model: 47022 | Brand: Munchkin

INTRODUCTION

The Munchkin Miracle 360 Sippy Cup is designed to help toddlers transition to open-cup drinking while minimizing spills. Its unique 360-degree drinking edge allows sipping from any side, promoting normal muscle development in a child's mouth. This manual provides essential information for the safe and effective use, cleaning, and maintenance of your Miracle 360 Sippy Cup.

This product is suitable for children 6 months and older.

PRODUCT COMPONENTS

The Munchkin Miracle 360 Sippy Cup consists of three main parts:

- Cup: The main container for liquids.
- Lid: Screws onto the cup and holds the silicone valve.
- Silicone Valve: The spill-proof mechanism that allows drinking from any edge.



Image: The three components of the Munchkin Miracle 360 Sippy Cup: the cup, the lid, and the removable silicone valve.

SETUP AND INITIAL USE

- 1. **Unpack:** Remove all packaging materials and labels from the cup.
- 2. **Disassemble:** Separate the cup, lid, and silicone valve. The silicone valve can be gently pulled out from the underside of the lid.
- 3. **Initial Cleaning:** Before first use, wash all components thoroughly in warm, soapy water or place them on the top rack of a dishwasher. Rinse all parts completely.
- 4. **Reassemble:** Insert the silicone valve back into the lid, ensuring it is seated firmly and evenly. The valve should snap into place.
- 5. Fill: Pour the desired liquid into the cup. Do not overfill.
- 6. **Secure Lid:** Screw the lid onto the cup until it is tight. Ensure the lid is properly aligned to prevent leaks.

OPERATING INSTRUCTIONS

The Miracle 360 Sippy Cup is designed for easy use by toddlers:

- **Drinking:** Your child can drink from any point around the rim of the cup, just like a regular open cup. The valve automatically seals when the child stops drinking.
- **Handles:** The integrated handles are designed for small hands to grip comfortably, aiding in independent drinking.



Image: A toddler demonstrating how to drink from the 360-degree edge of the Munchkin Miracle 360 Sippy Cup.



Image: A visual representation of the 360-degree drinking edge, highlighting its functionality.

MAINTENANCE AND CLEANING

Proper cleaning is essential for hygiene and product longevity.

- 1. **Disassembly:** Unscrew the lid from the cup. Gently pull the silicone valve from the underside of the lid.
- 2. **Washing:** Wash all three components (cup, lid, and silicone valve) thoroughly after each use. They are dishwasher safe (top rack only) or can be hand-washed with warm, soapy water.
- 3. Rinsing: Ensure all soap residue is completely rinsed off.
- 4. Drying: Allow all parts to air dry completely before reassembling or storing to prevent mold growth.
- 5. **Deep Cleaning (Optional):** For thorough cleaning, especially of tiny holes in the valve, occasional soaking in a white vinegar solution may be beneficial. Rinse thoroughly afterward.

TROUBLESHOOTING

· Leaking:

- Ensure the silicone valve is correctly and firmly seated in the lid.
- · Verify the lid is screwed on tightly and evenly.
- Avoid overfilling the cup.
- Note that while spill-proof, extreme impacts (e.g., throwing the cup forcefully) may cause minor splatters.

• Difficulty Drinking:

- Check if the silicone valve is properly installed and not obstructed.
- Ensure the child is sipping from the rim rather than biting or chewing the valve.

Mold/Odor:

- Always disassemble and clean all parts after each use.
- Allow parts to air dry completely before storage.
- Regularly inspect the silicone valve for any signs of wear or residue.

SPECIFICATIONS

Brand	Munchkin
Model Number	47022
Capacity	7 Ounces (207 ml)
Material	BPA Free
Color	Blue/Green (as a 2-pack)
Special Feature	Spill-Proof, Dentist-Recommended Spoutless Design
Recommended Age	6 Months and Up
Care Instructions	Top Rack Dishwasher Safe

SAFETY INFORMATION


- Burn Hazard: Do not microwave or use with hot liquids.
- Choking Hazard: Do not allow the child to play, bite, or chew on the valve.
- Injury Risk: Do not let the child walk or run while carrying the cup.
- **Product Damage:** Do not use with carbonated beverages or pulpy juices, as this may affect the valve's performance.
- · Always supervise children during use.
- Inspect the cup and valve before each use for signs of wear or damage. Discard and replace if damaged.

WARRANTY AND SUPPORT

Munchkin products are manufactured with quality and safety in mind. For specific warranty information or

customer support, please refer to the product packaging or visit the official Munchkin website. You can also visit the Munchkin Store on Amazon for more information and contact options.

Related Documents - 47022



Documents - Munchkin - 47022

no relevant documents